

SOUND4 IMPACT.CL Library [1.2.0]

Generated by Doxygen 1.9.1

1 SOUND4 IMPACT.CL Library	1
1.1 General usage	1
1.2 Examples	1
2 Deprecated List	3
3 Module Index	5
3.1 Modules	5
4 Namespace Index	7
4.1 Namespace List	7
5 Hierarchical Index	9
5.1 Class Hierarchy	9
6 Class Index	11
6.1 Class List	11
7 File Index	13
7.1 File List	13
8 Module Documentation	15
8.1 Sample using C interface	15
8.1.1 Sample to create the processing instance	15
8.1.2 Sample processing loop	16
8.1.3 Sample to stop the processing instance	16
8.2 Environment variables and parameters	17
8.2.1 Parameters defaulting from environment	17
8.2.1.1 Webserver authentication setup :	17
8.2.1.2 Webserver secure :	17
8.2.1.3 Network access :	17
8.2.2 Parameters	17
8.2.3 Preset sharing	18
8.3 Global setup	18
8.3.1 Detailed Description	18
8.3.2 Macro Definition Documentation	19
8.3.2.1 IMPACT_AUDIO_INPUT_COUNT	19
8.3.2.2 IMPACT_AUDIO_OUTPUT_COUNT	19
8.3.2.3 IMPACT_AUDIOFRAME_COUNT	19
8.3.2.4 IMPACT_CHANNEL_COUNT	20
8.3.2.5 IMPACT_SAMPLE_RATE	20
8.3.3 Typedef Documentation	20
8.3.3.1 impact_loggerfn	20
8.3.4 Enumeration Type Documentation	20
8.3.4.1 impact_LogSeverity	20

8.3.5 Function Documentation	21
8.3.5.1 impact_GetAudioInputCount()	21
8.3.5.2 impact_GetAudioOutputCount()	21
8.3.5.3 impact_GetChannelCount()	22
8.3.5.4 impact_GetChunkSizeInFrames()	22
8.3.5.5 impact_GetPossibleChunkSizeInFrames()	22
8.3.5.6 impact_GetSampleRate()	23
8.3.5.7 impact_GetVersion()	23
8.3.5.8 impact_SetLoggerCallback()	23
8.3.5.9 impact_SetLogSeverity()	24
8.4 Process creation/destruction	24
8.4.1 Detailed Description	24
8.4.2 Function Documentation	24
8.4.2.1 impact_ExitProcess()	24
8.4.2.2 impact_FreeParameters()	25
8.4.2.3 impact_FreeParameterValue()	25
8.4.2.4 impact_GetParameter()	25
8.4.2.5 impact_GetProcessChunkFrames()	25
8.4.2.6 impact_InitProcess()	26
8.4.2.7 impact_InitProcess2()	26
8.4.2.8 impact_InitProcess3()	27
8.4.2.9 impact_NewParameters()	28
8.4.2.10 impact_SetParameter()	28
8.4.2.11 impact_TerminateProcess()	28
8.5 Custom preset management	29
8.5.1 Detailed Description	30
8.5.2 Typedef Documentation	30
8.5.2.1 fs_char	30
8.5.2.2 impact_storage_exists	30
8.5.2.3 impact_storage_getall	31
8.5.2.4 impact_storage_getall_free	31
8.5.2.5 impact_storage_reader	31
8.5.2.6 impact_storage_reader_free	32
8.5.2.7 impact_storage_remove	32
8.5.2.8 impact_storage_rename	33
8.5.2.9 impact_storage_writer	33
8.5.3 Enumeration Type Documentation	33
8.5.3.1 impact_PresetChange_Kind	33
8.5.4 Function Documentation	34
8.5.4.1 impact_PresetManager_InformChange()	34
8.5.4.2 impact_SetPresetManager()	34
8.6 Metadata Management	35

8.6.1 Detailed Description	35
8.6.2 Function Documentation	35
8.6.2.1 impact_FreeMetadataInfos()	35
8.6.2.2 impact_GetMetadataInfos()	36
8.6.2.3 impact_SetMetadata()	36
8.7 Update Management	36
8.7.1 Detailed Description	36
8.7.2 Function Documentation	37
8.7.2.1 impact_StartUpdateThread()	37
8.7.2.2 impact_StopUpdateThread()	37
8.7.2.3 impact_WaitUpdateThreadReady()	37
8.8 Direct processing	38
8.8.1 Detailed Description	38
8.8.2 Function Documentation	38
8.8.2.1 impact_GetBufferIn()	38
8.8.2.2 impact_GetBufferOut()	39
8.8.2.3 impact_GetEstimatedDelay()	39
8.8.2.4 impact_ProcessAudio()	40
8.8.2.5 impact_ProcessAudio_Planar()	40
8.9 Audio managing (any audio)	41
8.9.1 Detailed Description	41
8.9.2 Enumeration Type Documentation	41
8.9.2.1 impact_SampleFormat	41
8.9.3 Function Documentation	42
8.9.3.1 impact_AddAudio()	42
8.9.3.2 impact_AddPadAudio()	43
8.9.3.3 impact_GetAudio()	43
8.9.3.4 impact_GetBytesFromFormat()	43
8.9.3.5 impact_GetFormatFromName()	44
8.9.3.6 impact_GetFormatName()	44
8.9.3.7 impact_GetMaxPacketFrame()	44
8.9.3.8 impact_GetOutputCount()	46
8.10 Audio convert helpers	46
8.10.1 Detailed Description	46
8.10.2 Function Documentation	46
8.10.2.1 impact_AudioConvertFrom()	47
8.10.2.2 impact_AudioConvertTo()	47
8.10.2.3 impact_AudioMonoFromLiveStereo()	47
8.10.2.4 impact_AudioMonoToLiveStereo()	48
8.10.2.5 impact_MonoToStereo()	48
8.10.2.6 impact_MonoToStereo_Planar()	49
8.10.2.7 impact_StereoToMono()	49

8.10.2.8 impact_StereoToMono_Planar()	49
8.11 Client's JSon config interfacing	50
8.11.1 Detailed Description	50
8.11.2 Function Documentation	50
8.11.2.1 impact_DeleteClient()	50
8.11.2.2 impact_FreeJsonAnswer()	51
8.11.2.3 impact_NewClient()	51
8.11.2.4 impact_ProcessJson()	51
8.11.2.5 impact_SaveState()	52
8.12 JSON syntax	52
8.12.1 Commands	53
8.12.2 Answers	53
8.12.3 Examples	54
8.12.3.1 Get status	54
8.12.3.2 Get all changes since last request	54
8.12.3.3 Check license	54
8.12.3.4 Set Processor name	54
8.12.3.5 Get presetlist	54
8.12.3.6 Load a preset	54
8.12.3.7 Get information on preset on air	54
8.12.3.8 Set input gain	55
8.12.3.9 Set bypass	55
8.12.3.10 Export a preset	55
8.12.3.11 Import a preset	55
8.13 JSON syntax for internal setup	55
8.13.1 Get process and modules information	56
8.13.2 Authentication management	56
8.13.2.1 Difference between setup and admin account	56
8.13.2.2 Access encoding	56
8.13.2.3 Change setup account	56
8.13.2.4 Get user info	57
8.13.2.5 Add or modify a user	57
8.13.2.6 Removes a user	57
8.13.2.7 List users	57
8.13.2.8 Get/set unlogged access	57
8.13.2.9 Get realm	57
8.13.2.10 Get API version	58
8.13.2.11 Get setup is admin	58
8.13.2.12 Get/set setup account	58
8.13.2.13 Get/set custom storage	58
8.13.3 Get process' interface description	58
8.13.3.1 Get XML decription	58

8.13.3.2 Get Process Image	58
8.13.3.3 Get Process Ico	59
8.14 Web server	59
8.14.1 Detailed Description	59
8.14.2 Macro Definition Documentation	59
8.14.2.1 SOUND4_INVALID_WEBSERVER_ID	59
8.14.2.2 SOUND4_WEBSERVER_HTTP_OK	60
8.14.2.3 SOUND4_WEBSERVER_HTTPS_OK	60
8.14.3 Function Documentation	60
8.14.3.1 impact_Webserver()	60
8.14.3.2 impact_Webserver_Status()	61
8.14.3.3 impact_Webserver_Stop()	61
8.14.3.4 impact_Webserver_tcp()	62
8.14.3.5 impact_Webserver_tcp2()	62
8.15 Sample using C++ interface wrapper	63
8.15.1 Setup and sanity checks	63
8.15.2 Sample to create the processing instance	63
8.15.3 Communicating with the instance	63
8.15.4 Starting a web-server	63
8.15.5 Sample processing loop	64
8.16 Sample using C++ interface wrapper with dynamic library loading	64
8.16.1 Dynamic loading	64
8.16.2 Setup and sanity checks	64
8.16.3 Sample to create the processing instance	64
8.16.4 Communicating with the instance	64
8.16.5 Starting a web-server	64
8.16.6 Sample processing loop	65
8.16.7 Custom preset manager	65
8.16.8 Custom preset manager loading	66
9 Namespace Documentation	67
9.1 dyn Namespace Reference	67
9.1.1 Detailed Description	67
9.2 sound4 Namespace Reference	67
9.2.1 Detailed Description	67
9.3 sound4::impact Namespace Reference	67
9.3.1 Detailed Description	68
9.3.2 Typedef Documentation	68
9.3.2.1 log_cb_t	68
9.3.2.2 LogSeverity	68
9.3.2.3 PresetChange_Kind	69
9.3.2.4 SampleFormat	69

9.3.3 Variable Documentation	69
9.3.3.1 ChunkFrames	69
9.3.3.2 InputChannels	69
9.3.3.3 InputSampleSize	69
9.3.3.4 OutputChannels	70
9.3.3.5 OutputSampleSize	70
9.3.3.6 SampleRate	70
9.4 sound4::impact::dyn Namespace Reference	70
9.4.1 Typedef Documentation	71
9.4.1.1 log_cb_t	71
9.4.1.2 LogSeverity	71
9.4.1.3 PresetChange_Kind	71
9.4.1.4 SampleFormat	71
9.4.2 Variable Documentation	72
9.4.2.1 ChunkFrames	72
9.4.2.2 InputChannels	72
9.4.2.3 InputSampleSize	72
9.4.2.4 OutputChannels	72
9.4.2.5 OutputSampleSize	72
9.4.2.6 SampleRate	73
9.5 sound4::impact::dyn::helper Namespace Reference	73
9.5.1 Detailed Description	73
9.5.2 Typedef Documentation	73
9.5.2.1 DynFunc_t	73
9.5.2.2 DynLib_t	74
9.6 sound4::impact::helper Namespace Reference	74
9.6.1 Detailed Description	74
9.7 std Namespace Reference	74
10 Class Documentation	75
10.1 sound4::impact::CInstance::CClient Class Reference	75
10.1.1 Detailed Description	75
10.1.2 Constructor & Destructor Documentation	75
10.1.2.1 CClient() [1/2]	75
10.1.2.2 CClient() [2/2]	76
10.1.2.3 ~CClient()	76
10.1.3 Member Function Documentation	76
10.1.3.1 operator=()	76
10.1.3.2 ProcessJson()	76
10.2 sound4::impact::dyn::CInstance::CClient Class Reference	77
10.2.1 Detailed Description	77
10.2.2 Constructor & Destructor Documentation	77

10.2.2.1 CClient() [1/2]	77
10.2.2.2 CClient() [2/2]	78
10.2.2.3 ~CClient()	78
10.2.3 Member Function Documentation	78
10.2.3.1 operator=()	78
10.2.3.2 ProcessJson()	78
10.3 sound4::impact::dyn::CDynLib Class Reference	79
10.3.1 Detailed Description	80
10.3.2 Constructor & Destructor Documentation	80
10.3.2.1 CDynLib()	80
10.3.3 Member Function Documentation	80
10.3.3.1 IsOk()	81
10.3.3.2 Load()	81
10.3.4 Member Data Documentation	81
10.3.4.1 AddAudio	81
10.3.4.2 AddPadAudio	81
10.3.4.3 AudioConvertFrom	82
10.3.4.4 AudioConvertTo	82
10.3.4.5 AudioMonoFromLiveStereo	82
10.3.4.6 AudioMonoToLiveStereo	82
10.3.4.7 DeleteClient	82
10.3.4.8 ExitProcess	82
10.3.4.9 FreeJsonAnswer	83
10.3.4.10 FreeMetadataInfos	83
10.3.4.11 FreeParameters	83
10.3.4.12 FreeParameterValue	83
10.3.4.13 GetAudio	83
10.3.4.14 GetAudioInputCount	83
10.3.4.15 GetAudioOutputCount	84
10.3.4.16 GetBufferIn	84
10.3.4.17 GetBufferOut	84
10.3.4.18 GetBytesFromFormat	84
10.3.4.19 GetChannelCount	84
10.3.4.20 GetChunkSizeInFrames	84
10.3.4.21 GetEstimatedDelay	85
10.3.4.22 GetFormatFromName	85
10.3.4.23 GetFormatName	85
10.3.4.24 GetMaxPacketFrame	85
10.3.4.25 GetMetadataInfos	85
10.3.4.26 GetOutputCount	85
10.3.4.27 GetParameter	86
10.3.4.28 GetPossibleChunkSizeInFrames	86

10.3.4.29 GetProcessChunkFrames	86
10.3.4.30 GetSampleRate	86
10.3.4.31 GetVersion	86
10.3.4.32 InitProcess	86
10.3.4.33 InitProcess2	87
10.3.4.34 InitProcess3	87
10.3.4.35 MonoToStereo	87
10.3.4.36 MonoToStereo_Planar	87
10.3.4.37 NewClient	87
10.3.4.38 NewParameters	87
10.3.4.39 PresetManager_InformChange	88
10.3.4.40 ProcessAudio	88
10.3.4.41 ProcessAudio_Planar	88
10.3.4.42 ProcessJson	88
10.3.4.43 SaveState	88
10.3.4.44 SetLoggerCallback	88
10.3.4.45 SetLogSeverity	89
10.3.4.46 SetMetadata	89
10.3.4.47 SetParameter	89
10.3.4.48 SetPresetManager	89
10.3.4.49 StartUpdateThread	89
10.3.4.50 StereoToMono	89
10.3.4.51 StereoToMono_Planar	90
10.3.4.52 StopUpdateThread	90
10.3.4.53 TerminateProcess	90
10.3.4.54 WaitUpdateThreadReady	90
10.3.4.55 Webserver	90
10.3.4.56 Webserver_Status	90
10.3.4.57 Webserver_Stop	91
10.3.4.58 Webserver_tcp	91
10.3.4.59 Webserver_tcp2	91
10.4 sound4::impact::dyn::helper::CDynLoader Class Reference	91
10.4.1 Detailed Description	92
10.4.2 Constructor & Destructor Documentation	92
10.4.2.1 CDynLoader() [1/3]	92
10.4.2.2 CDynLoader() [2/3]	92
10.4.2.3 CDynLoader() [3/3]	92
10.4.2.4 ~CDynLoader()	92
10.4.3 Member Function Documentation	92
10.4.3.1 Close()	93
10.4.3.2 GetSymbol()	93
10.4.3.3 GetSymbol_safe()	93

10.4.3.4	GetThisLibraryPath()	93
10.4.3.5	IsOk()	93
10.4.3.6	Load()	94
10.4.3.7	operator bool()	94
10.4.3.8	operator=()	94
10.5	sound4::impact::CInstance Class Reference	94
10.5.1	Detailed Description	95
10.5.2	Constructor & Destructor Documentation	95
10.5.2.1	CInstance() [1/2]	96
10.5.2.2	CInstance() [2/2]	96
10.5.2.3	~CInstance()	96
10.5.3	Member Function Documentation	96
10.5.3.1	AddAudio()	96
10.5.3.2	Create()	96
10.5.3.3	GetAudio()	97
10.5.3.4	GetBufferIn()	97
10.5.3.5	GetBufferOut()	98
10.5.3.6	GetChunkFrames()	98
10.5.3.7	GetEstimatedDelay()	98
10.5.3.8	GetMetadataInfos()	99
10.5.3.9	GetParam()	99
10.5.3.10	IsOk()	99
10.5.3.11	NewClient()	99
10.5.3.12	OnUpdateThreadStart()	100
10.5.3.13	OnUpdateThreadStop()	100
10.5.3.14	operator=()	100
10.5.3.15	PresetManager_InformChange()	100
10.5.3.16	ProcessAnyAudio()	100
10.5.3.17	ProcessAudio()	101
10.5.3.18	ProcessAudio_Planar()	101
10.5.3.19	SetMetadata()	102
10.5.3.20	SetParam()	102
10.5.3.21	SetPresetManager()	103
10.5.3.22	StartWebServer()	103
10.5.3.23	Stop()	103
10.5.3.24	StopWebServer()	104
10.5.3.25	Terminate()	104
10.6	sound4::impact::dyn::CInstance Class Reference	104
10.6.1	Detailed Description	105
10.6.2	Constructor & Destructor Documentation	105
10.6.2.1	CInstance() [1/2]	106
10.6.2.2	CInstance() [2/2]	106

10.6.2.3 ~CInstance()	106
10.6.3 Member Function Documentation	106
10.6.3.1 AddAudio()	106
10.6.3.2 Create()	106
10.6.3.3 GetAudio()	107
10.6.3.4 GetBufferIn()	107
10.6.3.5 GetBufferOut()	108
10.6.3.6 GetChunkFrames()	108
10.6.3.7 GetEstimatedDelay()	108
10.6.3.8 GetMetadataInfos()	109
10.6.3.9 GetParam()	109
10.6.3.10 IsOk()	109
10.6.3.11 NewClient()	109
10.6.3.12 OnUpdateThreadStart()	110
10.6.3.13 OnUpdateThreadStop()	110
10.6.3.14 operator=()	110
10.6.3.15 PresetManager_InformChange()	110
10.6.3.16 ProcessAnyAudio()	110
10.6.3.17 ProcessAudio()	111
10.6.3.18 ProcessAudio_Planar()	111
10.6.3.19 SetMetadata()	112
10.6.3.20 SetParam()	112
10.6.3.21 SetPresetManager()	113
10.6.3.22 StartWebServer()	113
10.6.3.23 Stop()	113
10.6.3.24 StopWebServer()	114
10.6.3.25 Terminate()	114
10.7 sound4::impact::CPresetLoader Class Reference	114
10.7.1 Detailed Description	115
10.7.2 Constructor & Destructor Documentation	115
10.7.2.1 CPresetLoader()	115
10.7.2.2 ~CPresetLoader()	115
10.7.3 Member Function Documentation	115
10.7.3.1 Exists()	115
10.7.3.2 GetAll()	115
10.7.3.3 IsReadOnly()	115
10.7.3.4 Read()	116
10.7.3.5 Remove()	116
10.7.3.6 Rename()	116
10.7.3.7 Write()	116
10.8 sound4::impact::dyn::CPresetLoader Class Reference	116
10.8.1 Detailed Description	117

10.8.2 Constructor & Destructor Documentation	117
10.8.2.1 CPresetLoader()	117
10.8.2.2 ~CPresetLoader()	117
10.8.3 Member Function Documentation	117
10.8.3.1 Exists()	117
10.8.3.2 GetAll()	117
10.8.3.3 IsReadOnly()	118
10.8.3.4 Read()	118
10.8.3.5 Remove()	118
10.8.3.6 Rename()	118
10.8.3.7 Write()	118
10.9 sound4::impact::dyn::helper::DynFuncHolder< T > Class Template Reference	119
10.9.1 Detailed Description	119
10.9.2 Constructor & Destructor Documentation	119
10.9.2.1 DynFuncHolder() [1/2]	119
10.9.2.2 DynFuncHolder() [2/2]	119
10.9.3 Member Function Documentation	120
10.9.3.1 IsOk()	120
10.9.3.2 operator bool()	120
10.9.3.3 operator T*()	120
10.10 impact_CClientInstance Struct Reference	120
10.10.1 Detailed Description	120
10.11 impact_CInstance Struct Reference	121
10.11.1 Detailed Description	121
10.12 impact_CParameters Struct Reference	121
10.12.1 Detailed Description	121
10.13 MyPresetManager Class Reference	121
10.13.1 Detailed Description	122
10.13.2 Constructor & Destructor Documentation	122
10.13.2.1 MyPresetManager()	122
10.13.2.2 ~MyPresetManager()	122
10.13.3 Member Function Documentation	122
10.13.3.1 Exists()	122
10.13.3.2 GetAll()	122
10.13.3.3 IsReadOnly()	123
10.13.3.4 Read()	123
10.13.3.5 Remove()	123
10.13.3.6 Rename()	123
10.13.3.7 SetupPath()	123
10.13.3.8 Write()	124
10.14 sound4::impact::dyn::helper::SampleFormat< T > Struct Template Reference	124
10.14.1 Detailed Description	124

10.15 sound4::impact::helper::SampleFormat< T > Struct Template Reference	124
10.15.1 Detailed Description	124
10.16 sound4::impact::dyn::helper::SampleFormat< float > Struct Reference	125
10.16.1 Detailed Description	125
10.16.2 Member Data Documentation	125
10.16.2.1 format	125
10.17 sound4::impact::helper::SampleFormat< float > Struct Reference	125
10.17.1 Detailed Description	126
10.17.2 Member Data Documentation	126
10.17.2.1 format	126
10.18 sound4::impact::dyn::helper::SampleFormat< int16_t > Struct Reference	126
10.18.1 Detailed Description	126
10.18.2 Member Data Documentation	126
10.18.2.1 format	127
10.19 sound4::impact::helper::SampleFormat< int16_t > Struct Reference	127
10.19.1 Detailed Description	127
10.19.2 Member Data Documentation	127
10.19.2.1 format	127
10.20 sound4::impact::dyn::helper::SampleFormat< int32_t > Struct Reference	127
10.20.1 Detailed Description	128
10.20.2 Member Data Documentation	128
10.20.2.1 format	128
10.21 sound4::impact::helper::SampleFormat< int32_t > Struct Reference	128
10.21.1 Detailed Description	128
10.21.2 Member Data Documentation	128
10.21.2.1 format	128
11 File Documentation	129
11.1 sound4.impact.cl-pipe-cxx.cpp File Reference	129
11.1.1 Function Documentation	129
11.1.1.1 GetEnv()	129
11.1.1.2 main()	130
11.1.1.3 MyLogger()	130
11.1.1.4 ProcessLoop()	130
11.1.1.5 Usage()	130
11.2 sound4.impact.cl-pipe-cxx.cpp	131
11.3 sound4.impact.cl-pipe-dyn.cpp File Reference	132
11.3.1 Function Documentation	133
11.3.1.1 GetEnv()	133
11.3.1.2 main()	134
11.3.1.3 MyLogger()	134
11.3.1.4 ProcessLoop()	134

11.3.1.5 Usage()	135
11.4 sound4.impact.cl-pipe-dyn.cpp	135
11.5 sound4.impact.cl-pipe.cpp File Reference	138
11.5.1 Macro Definition Documentation	138
11.5.1.1 CHANNEL_COUNT	139
11.5.1.2 CHUNK_SIZE	139
11.5.1.3 SAMPLE_RATE	139
11.5.2 Function Documentation	139
11.5.2.1 main()	139
11.5.2.2 MyLogger()	140
11.5.2.3 ProcessLoop()	140
11.5.2.4 Usage()	140
11.6 sound4.impact.cl-pipe.cpp	140
11.7 sound4.impact.cl.h File Reference	143
11.7.1 Macro Definition Documentation	146
11.7.1.1 IMPACT_DECL	146
11.7.1.2 IMPACT_HAS_CLOUDBUS	146
11.7.1.3 IMPACT_HAS_WEBSERVER	146
11.8 sound4.impact.cl.h	146
11.9 sound4.impact.cl.hpp File Reference	150
11.9.1 Macro Definition Documentation	151
11.9.1.1 fs_strdup	151
11.10 sound4.impact.cl.hpp	152
11.11 sound4.impact.cl_dyn.hpp File Reference	159
11.11.1 Detailed Description	160
11.11.2 Macro Definition Documentation	160
11.11.2.1 fs_strdup	160
11.12 sound4.impact.cl_dyn.hpp	160
Index	173

Chapter 1

SOUND4 IMPACT.CL Library

1.1 General usage

You may check library configuration and setup logging [Global setup](#) and [Environment variables and parameters](#)

You have to create/destroy an instance [Process creation/destruction](#).

For audio, you can either use direct optimized form with [Direct processing](#) or you can use [Audio managing \(any audio\)](#) to have any format. You may use [Audio convert helpers](#).

You need to start a thread calling [impact_StartUpdateThread](#) see [Update Management](#)

You can start a web server for configuration, see [Web server](#)

If it is needed, you can use metadata : see [Metadata Management](#)

If you need, you may use your own custom preset manager for saving files and presets. See [Custom preset management](#)

To access the presets/settings, you can either use JSON socket from [Update Management](#) or do all manually with [Client's JSon config interfacing](#) using [JSON syntax](#)

See full example [cpp/sound4.impact.cl-pipe.cpp](#)

You can also use the C++ wrapper from header [sound4.impact.cl.hpp](#) or the one with dynamic library loading [sound4.impact.cl_dyn.hpp](#).

Note

In all library, all `char*` are **UTF-8** encoded

1.2 Examples

See [Sample using C interface](#)

See [Sample using C++ interface wrapper](#)

See [Sample using C++ interface wrapper with dynamic library loading](#)

Chapter 2

Deprecated List

Member [impact_GetChunkSizeInFrames](#) ()

Use [impact_GetPossibleChunkSizeInFrames](#)

Member [impact_InitProcess](#) (const char *LoginKey, const char *RadioName, const char *AWS_Access_ID, const char *AWS_Access_Secret, const char *save_path)

Use [impact_InitProcess3](#)

Member [impact_InitProcess2](#) (const char *LoginKey, const char *RadioName, const char *AWS_Access_ID, const char *AWS_Access_Secret, const char *save_path, const struct [impact_CParameters](#) *parameters)

Use [impact_InitProcess3](#)

Chapter 3

Module Index

3.1 Modules

Here is a list of all modules:

Sample using C interface	15
Environment variables and parameters	17
Global setup	18
Process creation/destruction	24
Custom preset managagement	29
Metadata Management	35
Update Management	36
Direct processing	38
Audio managing (any audio)	41
Audio convert helpers	46
Client's JSon config interfacing	50
JSON syntax	52
JSON syntax for internal setup	55
Web server	59
Sample using C++ interface wrapper	63
Sample using C++ interface wrapper with dynamic library loading	64

Chapter 4

Namespace Index

4.1 Namespace List

Here is a list of all namespaces with brief descriptions:

dyn	67
sound4	67
sound4::impact	67
sound4::impact::dyn	70
sound4::impact::dyn::helper	73
sound4::impact::helper	74
std	74

Chapter 5

Hierarchical Index

5.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

sound4::impact::CInstance::CClient	75
sound4::impact::dyn::CInstance::CClient	77
sound4::impact::dyn::CDynLib	79
sound4::impact::dyn::helper::CDynLoader	91
sound4::impact::CInstance	94
sound4::impact::dyn::CInstance	104
sound4::impact::CPresetLoader	114
sound4::impact::dyn::CPresetLoader	116
MyPresetManager	121
sound4::impact::dyn::helper::DynFuncHolder< T >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_AddAudio) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_AddPadAudio) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_AudioConvertFrom) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_AudioConvertTo) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_AudioMonoFromLiveStereo) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_AudioMonoToLiveStereo) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_DeleteClient) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_ExitProcess) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_FreeJsonAnswer) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_FreeMetadataInfos) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_FreeParameters) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_FreeParameterValue) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetAudio) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetAudioInputCount) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetAudioOutputCount) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetBufferIn) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetBufferOut) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetBytesFromFormat) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetChannelCount) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetChunkSizeInFrames) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetEstimatedDelay) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetFormatFromName) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetFormatName) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetMaxPacketFrame) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetMetadataInfos) >	119

sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetOutputCount) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetParameter) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetPossibleChunkSizeInFrames) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetProcessChunkFrames) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetSampleRate) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_GetVersion) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_InitProcess) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_InitProcess2) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_InitProcess3) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_MonoToStereo) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_MonoToStereo_Planar) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_NewClient) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_NewParameters) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_PresetManager_InformChange) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_ProcessAudio) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_ProcessAudio_Planar) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_ProcessJson) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_SaveState) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_SetLoggerCallback) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_SetLogSeverity) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_SetMetadata) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_SetParameter) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_SetPresetManager) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_StartUpdateThread) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_StereoToMono) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_StereoToMono_Planar) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_StopUpdateThread) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_TerminateProcess) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_WaitUpdateThreadReady) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_Webserver) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_Webserver_Status) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_Webserver_Stop) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_Webserver_tcp) >	119
sound4::impact::dyn::helper::DynFuncHolder< decltype(impact_Webserver_tcp2) >	119
impact_CClientInstance	120
impact_CInstance	121
impact_CParameters	121
sound4::impact::dyn::helper::SampleFormat< T >	124
sound4::impact::helper::SampleFormat< T >	124
sound4::impact::dyn::helper::SampleFormat< float >	125
sound4::impact::helper::SampleFormat< float >	125
sound4::impact::dyn::helper::SampleFormat< int16_t >	126
sound4::impact::helper::SampleFormat< int16_t >	127
sound4::impact::dyn::helper::SampleFormat< int32_t >	127
sound4::impact::helper::SampleFormat< int32_t >	128

Chapter 6

Class Index

6.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

sound4::impact::CInstance::CClient	75
sound4::impact::dyn::CInstance::CClient	77
sound4::impact::dyn::CDynLib	
Dynamic library interface	79
sound4::impact::dyn::helper::CDynLoader	
Helper to load dynamic library	91
sound4::impact::CInstance	94
sound4::impact::dyn::CInstance	104
sound4::impact::CPresetLoader	114
sound4::impact::dyn::CPresetLoader	116
sound4::impact::dyn::helper::DynFuncHolder< T >	
Helper to wrap a function pointer	119
impact_CClientInstance	120
impact_CInstance	121
impact_CParameters	121
MyPresetManager	
[Custom preset manager]	121
sound4::impact::dyn::helper::SampleFormat< T >	
Helper for Sample format types	124
sound4::impact::helper::SampleFormat< T >	
Helper for Sample format types	124
sound4::impact::dyn::helper::SampleFormat< float >	125
sound4::impact::helper::SampleFormat< float >	125
sound4::impact::dyn::helper::SampleFormat< int16_t >	126
sound4::impact::helper::SampleFormat< int16_t >	127
sound4::impact::dyn::helper::SampleFormat< int32_t >	127
sound4::impact::helper::SampleFormat< int32_t >	128

Chapter 7

File Index

7.1 File List

Here is a list of all files with brief descriptions:

sound4.impact.cl-pipe-cxx.cpp	
C++ sample using C++ interface wrapper	129
sound4.impact.cl-pipe-dyn.cpp	
C++ sample using C++ interface wrapper with dynamic library loading	132
sound4.impact.cl-pipe.cpp	
C++ sample using only C interface	138
sound4.impact.cl.h	
C interface for library	143
sound4.impact.cl.hpp	
C++ wrapper for library	150
sound4.impact.cl_dyn.hpp	
C++ wrapper for dynamic loading library	159

Chapter 8

Module Documentation

8.1 Sample using C interface

See full example [cpp/sound4.impact.cl-pipe.cpp](#)

8.1.1 Sample to create the processing instance

see [Process creation/destruction](#) and [Update Management](#)

```
// Setup parameters
struct impact_CParameters *params = impact_NewParameters();
// Optional: activate web authentication, set admin password
// This creates the authentication only for a new storage path
impact_SetParameter(params, "ADMIN_USER", "admin");
impact_SetParameter(params, "ADMIN_SECRET", "admin");

// Create the processing instance
pInstance=impact_InitProcess2(pLoginKey, pRadioName, pKeyId, pAccessKey, store_path.c_str(), params);
impact_FreeParameters(params);
if (!pInstance) {
    std::cerr << "Failed to create the process instance" << std::endl;
    return 1;
}
// Start the update thread, without JSON server (low priority)
std::thread updater([pInstance]() {
    // will returned when stopped or destroyed
    std::cerr << "impact_StartUpdateThread (no json port)" << std::endl;
    impact_StartUpdateThread(pInstance, 0);
    std::cerr << "impact_StartUpdateThread END" << std::endl;
});
// This is not mandatory, but better be sure we are ready right now
std::cerr << "Waiting update thread" << std::endl;
if (impact_WaitUpdateThreadReady(pInstance, 5000)<0) {
    std::cerr << "Timeout to create the process instance" << std::endl;
}
std::cerr << "Waiting update thread DONE" << std::endl;
#ifdef IMPACT_HAS_WEBSERVER
// Starts a web server, listening on port http://localhost:8080, https://localhost:8443
std::cerr << "Starting web server" << std::endl;
int listenport= 8080;
int listenport_secure= 8443;
uint64_t webserver= SOUND4_INVALID_WEBSERVER_ID;
if (listenport || listenport_secure) {
    webserver = impact_Webserver(listenport, listenport_secure, pInstance);
    if (webserver==SOUND4_INVALID_WEBSERVER_ID) {
        std::cerr << "Starting web server FAILED" << std::endl;
    } else {
        int web_status=impact_Webserver_Status(webserver);
        if (listenport) {
            if (web_status & SOUND4_WEBSERVER_HTTP_OK) {
                std::cerr << "Web server listening on port " << listenport;
            } else {
                std::cerr << "Web server failed to listen on port " << listenport;
            }
        }
    }
}
```

```

        if (listenport_secure) {
            if (web_status & SOUND4_WEBSERVER_HTTPS_OK) {
                std::cerr << "Web server listening on secure port " << listenport_secure;
            } else {
                std::cerr << "Web server failed to listen on secure port " << listenport_secure;
            }
        }
        std::cerr << "Starting web server DONE" << std::endl;
    }
}
#endif // (IMPACT_HAS_WEBSERVER)

// Force load a factory preset now
// Could be used instead of setting a store_path
/*{
    impact_CClientInstance *pClient=impact_NewClient(pInstance);
    const char *answer=impact_ProcessJson(pClient, "{ \"factoryload\": \"All Programs\" }", NULL);
    std::cerr << "Loaded factory preset answer: " << answer<< std::endl;
    impact_FreeJsonAnswer(answer);
    impact_DeleteClient(pClient);
}*/

```

8.1.2 Sample processing loop

see [Direct processing](#)

```

bool stopthread=false;
alignas(64) float audio_in[CHUNK_SIZE*CHANNEL_COUNT];
alignas(64) float audio_out[CHUNK_SIZE*CHANNEL_COUNT];
#ifdef _WIN32 || defined(WIN32)
    // Windows: The stdin, stdout, and stderr streams always open in text mode by default
    _setmode(_fileno(stdin), _O_BINARY);
    _setmode(_fileno(stdout), _O_BINARY);
#endif

while (!stopthread)
{
    // Read a chunk from stdin
    if (std::fread(&audio_in[0], sizeof(float), CHUNK_SIZE*CHANNEL_COUNT, stdin) !=
        CHUNK_SIZE*CHANNEL_COUNT) {
        std::cerr << "ProcessLoop: input stopped" << std::endl;
        stopthread=true;
        break;
    }
    if (stopthread) break;
    // Process it
    impact_ProcessAudio(pInstance, audio_in, audio_out);
    // Write it to stdout
    if (fwrite(&audio_out[0], sizeof(float), CHUNK_SIZE*CHANNEL_COUNT, stdout) !=
        CHUNK_SIZE*CHANNEL_COUNT) {
        std::cerr << "Failed to write audio output" << std::endl;
        stopthread=true;
    }
}

```

8.1.3 Sample to stop the processing instance

see [Process creation/destruction](#)

```

#ifdef (IMPACT_HAS_WEBSERVER)
    // Stopping the webserver
    std::cerr << "Stopping web server" << std::endl;
    impact_Webserver_Stop(webserver, 1000);
    std::cerr << "Stopping web server DONE" << std::endl;
#endif // (IMPACT_HAS_WEBSERVER)

// Stopping the processing instance
std::cerr << "Stopping Update thread" << std::endl;
impact_StopUpdateThread(pInstance); // this will exit the update thread
std::cerr << "Stopping Update thread DONE" << std::endl;
updater.join();
impact_ExitProcess(pInstance);

```

8.2 Environment variables and parameters

8.2.1 Parameters defaulting from environment

The following environment variables are used by software library:

Note

Those variables can be passed as parameters with [impact_InitProcess2](#)

8.2.1.1 Webserver authentication setup :

- `SETUP_USER` see [impact_InitProcess](#)
- `SETUP_SECRET` see [impact_InitProcess](#)
- `ADMIN_USER` see [impact_InitProcess](#)
- `ADMIN_SECRET` see [impact_InitProcess](#)

8.2.1.2 Webserver secure :

- `SSL_CERTIFICATE_PATH` : path to the SSL public certificate
- `SSL_PRIVATE_PATH` : path to the SSL private certificate

8.2.1.3 Network access :

- `LICENSE_SERVER` : the SOUND4 license server's URL
- `LICENSE_SERVER_PROXY` : proxy server to use for licenses [user:pass@]host:port
- `LICENSE_CERT_DIR` : optional certificates dirs for HTTPS verification
- `LICENSE_CERT_CHECK` : if "false", do not check HTTPS certificates

8.2.2 Parameters

The following parameters can be set before creating instance, but are never taken from environment.

Run mode:

- `FILE_MODE=seconds` : force file mode, settings the maximum estimated audio duration (non realtime, wait license ok to process)
- `STATE_FILENAME=filename` : force this instance to store its state in file named `filename.json` (instead of `state.json`)
- `STATE_ONAIR=filename` : force this instance to store its on air preset name in file named `filename.onair` (instead of none). Used for sharing between instances.
- `STORAGE_RO=notempty` : force the storage in read-only mode
- `STATE_RO=notempty` : force the state in read-only mode (but can save presets/auth)
- `WAIT_LICENSE=notempty` : force to wait the license load before starting (always in file mode)

8.2.3 Preset sharing

You can use the same folder for multiple instances so they share their presets.

In this case, you should use a different `STATE_FILENAME` per instance so they keep their settings and on air presets separated. If not, each time settings or onair preset are changed, the changes will be reflected to the other instances using same `STATE_FILENAME`.

You may use the same `STATE_ONAIR` for multiple instances sharing the folder, so that changing the on air preset on one immediately changes the on air preset on other instances using the same `STATE_ONAIR`. If the instance has pending unsaved changes in the on air preset, it will not be updated automatically to avoid losing changes.

8.3 Global setup

Macros

- `#define IMPACT_AUDIOFRAME_COUNT 64`
- `#define IMPACT_CHANNEL_COUNT 2`
- `#define IMPACT_AUDIO_INPUT_COUNT 1`
- `#define IMPACT_AUDIO_OUTPUT_COUNT 1`
- `#define IMPACT_SAMPLE_RATE 48000`

Typedefs

- `typedef void(* impact_loggerfn) (enum impact_LogSeverity, const char *)`

Enumerations

- `enum impact_LogSeverity {
 none = 0 , fatal = 1 , error = 2 , warning = 3 ,
 info = 4 , verbose = 5 , verbose2 = 6 , verbose3 = 7 ,
 verbose4 = 8 , verbose5 = 9 }`

Functions

- `const char * impact_GetVersion ()`
- `unsigned int impact_GetChunkSizeInFrames ()`
- `unsigned int * impact_GetPossibleChunkSizeInFrames ()`
- `unsigned int impact_GetChannelCount ()`
- `unsigned int impact_GetAudioInputCount ()`
- `unsigned int impact_GetAudioOutputCount ()`
- `unsigned int impact_GetSampleRate ()`
- `void impact_SetLoggerCallback (impact_loggerfn logger)`
- `void impact_SetLogSeverity (enum impact_LogSeverity severity)`

8.3.1 Detailed Description

Get information on the library. Set logging mode

8.3.2 Macro Definition Documentation

8.3.2.1 IMPACT_AUDIO_INPUT_COUNT

```
#define IMPACT_AUDIO_INPUT_COUNT 1
```

This version number of inputs for this process.

Remarks

For binary compatibility, this should be runtime checked to be the same as [impact_GetAudioInputCount\(\)](#)

Definition at line 166 of file [sound4.impact.cl.h](#).

8.3.2.2 IMPACT_AUDIO_OUTPUT_COUNT

```
#define IMPACT_AUDIO_OUTPUT_COUNT 1
```

This version number of outputs for this process.

Remarks

For binary compatibility, this should be runtime checked to be the same as [impact_GetAudioOutputCount\(\)](#)

Definition at line 172 of file [sound4.impact.cl.h](#).

8.3.2.3 IMPACT_AUDIOFRAME_COUNT

```
#define IMPACT_AUDIOFRAME_COUNT 64
```

This version number of frames in a process chunk.

Remarks

For binary compatibility, this should be runtime checked to be the same as [impact_GetChunkSizeInFrames\(\)](#)

Definition at line 154 of file [sound4.impact.cl.h](#).

8.3.2.4 IMPACT_CHANNEL_COUNT

```
#define IMPACT_CHANNEL_COUNT 2
```

This version number of channels.

Remarks

For binary compatibility, this should be runtime checked to be the same as [impact_GetChannelCount\(\)](#)

Definition at line 160 of file [sound4.impact.cl.h](#).

8.3.2.5 IMPACT_SAMPLE_RATE

```
#define IMPACT_SAMPLE_RATE 48000
```

This input/output sample-rate.

Remarks

For binary compatibility, this should be runtime checked to be the same as [impact_GetSampleRate\(\)](#)

Definition at line 178 of file [sound4.impact.cl.h](#).

8.3.3 Typedef Documentation

8.3.3.1 impact_loggerfn

```
typedef void(* impact_loggerfn) (enum impact\_LogSeverity, const char *)
```

The logging callback format

Warning

Do not block/wait in the callback, it can be called from any place in code

Note

In all library, all `char*` are **UTF-8** encoded

Definition at line 271 of file [sound4.impact.cl.h](#).

8.3.4 Enumeration Type Documentation

8.3.4.1 impact_LogSeverity

```
enum impact\_LogSeverity
```

The logging levels

Enumerator

none	
fatal	
error	
warning	
info	
verbose	
verbose2	
verbose3	
verbose4	
verbose5	

Definition at line 252 of file [sound4.impact.cl.h](#).

8.3.5 Function Documentation

8.3.5.1 `impact_GetAudioInputCount()`

```
unsigned int impact_GetAudioInputCount ( )
```

Get the number of inputs for this process

Remarks

All inputs have [impact_GetChannelCount\(\)](#) channels
Fixed to 1, but should be checked for backward compatibility

Returns

The process input count

8.3.5.2 `impact_GetAudioOutputCount()`

```
unsigned int impact_GetAudioOutputCount ( )
```

Get the number of outputs for this process

Remarks

All outputs have [impact_GetChannelCount\(\)](#) channels
Fixed to 1, but should be checked for backward compatibility

Returns

The process outputs count

8.3.5.3 `impact_GetChannelCount()`

```
unsigned int impact_GetChannelCount ( )
```

Get the number of channels needed by this process

Remarks

Fixed to 2, but should be checked for backward compatibility

Returns

The process channels count

8.3.5.4 `impact_GetChunkSizeInFrames()`

```
unsigned int impact_GetChunkSizeInFrames ( )
```

Get the number of frames in a process chunk.

The output will be available only by chunks of this size.

Note

A Frame is a set of [impact_GetChannelCount](#) samples

Remarks

Fixed to 64, but should be checked for backward compatibility

Returns

The process chunk size in frame

Deprecated Use [impact_GetPossibleChunkSizeInFrames](#)

8.3.5.5 `impact_GetPossibleChunkSizeInFrames()`

```
unsigned int* impact_GetPossibleChunkSizeInFrames ( )
```

Get the possibles number of frames in a process chunk.

The output will be available only by chunks of this size.

Note

A Frame is a set of [impact_GetChannelCount](#) samples

Returns

An array of possible process chunk size in frame, ending with 0

8.3.5.6 `impact_GetSampleRate()`

```
unsigned int impact_GetSampleRate ( )
```

Get the processing sample-rate

Remarks

For now, always return 48000, but should be checked for backward compatibility

Returns

The process sample-rate in Hz

8.3.5.7 `impact_GetVersion()`

```
const char* impact_GetVersion ( )
```

Get the process version string

Returns

version string

8.3.5.8 `impact_SetLoggerCallback()`

```
void impact_SetLoggerCallback (
    impact_loggerfn logger )
```

Set a callback for logging

If not set, a default logger prints to stderr.

Warning

Do not block/wait in the callback, it can be called from any place in code

Parameters

<i>logger</i>	A C callback called for logging.
---------------	----------------------------------

8.3.5.9 impact_SetLogSeverity()

```
void impact_SetLogSeverity (
    enum impact_LogSeverity severity )
```

Change the global log severity

Logs above this level will not be printed.

Parameters

<i>severity</i>	Log severity
-----------------	--------------

8.4 Process creation/destruction

Classes

- struct [impact_CInstance](#)
- struct [impact_CParameters](#)

Functions

- struct [impact_CParameters](#) * [impact_NewParameters](#) ()
- void [impact_FreeParameters](#) (struct [impact_CParameters](#) *params)
- void [impact_SetParameter](#) (struct [impact_CParameters](#) *params, const char *name, const char *value)
- const char * [impact_GetParameter](#) (struct [impact_CParameters](#) *params, const char *name)
- void [impact_FreeParameterValue](#) (const char *value)
- struct [impact_CInstance](#) * [impact_InitProcess](#) (const char *LoginKey, const char *RadioName, const char *AWS_Access_ID, const char *AWS_Access_Secret, const char *save_path)
- struct [impact_CInstance](#) * [impact_InitProcess2](#) (const char *LoginKey, const char *RadioName, const char *AWS_Access_ID, const char *AWS_Access_Secret, const char *save_path, const struct [impact_CParameters](#) *parameters)
- struct [impact_CInstance](#) * [impact_InitProcess3](#) (const char *LoginKey, const char *RadioName, const char *AWS_Access_ID, const char *AWS_Access_Secret, const char *save_path, const struct [impact_CParameters](#) *parameters, unsigned int frames_per_chunk)
- unsigned int [impact_GetProcessChunkFrames](#) (struct [impact_CInstance](#) *instance)
- int [impact_TerminateProcess](#) (struct [impact_CInstance](#) *instance)
- void [impact_ExitProcess](#) (struct [impact_CInstance](#) *instance)

8.4.1 Detailed Description

Create and destroy a process instance, and retrieve some general information about the process.

8.4.2 Function Documentation

8.4.2.1 impact_ExitProcess()

```
void impact_ExitProcess (
    struct impact_CInstance * instance )
```

Quit and destroy the instance

Parameters

<i>instance</i>	the instance to destroy
-----------------	-------------------------

8.4.2.2 `impact_FreeParameters()`

```
void impact_FreeParameters (
    struct impact\_CParameters * params )
```

Free the parameters created with [impact_NewParameters](#).

8.4.2.3 `impact_FreeParameterValue()`

```
void impact_FreeParameterValue (
    const char * value )
```

Free a parameter value returned by [impact_GetParameter](#)

Parameters

<i>value</i>	the returned value
--------------	--------------------

8.4.2.4 `impact_GetParameter()`

```
const char* impact_GetParameter (
    struct impact\_CParameters * params,
    const char * name )
```

Get current parameter value.

Returned value must be freed with [impact_FreeParameterValue](#)

8.4.2.5 `impact_GetProcessChunkFrames()`

```
unsigned int impact_GetProcessChunkFrames (
    struct impact\_CInstance * instance )
```

Get the number of audio frames in each chunk of processing.

The value reflects the `frames_per_chunk` parameter passed to [impact_InitProcess3](#)

Parameters

<i>instance</i>	the instance to destroy
-----------------	-------------------------

Returns

the number of audio frames in each chunk of processing

Note

A Frame is a set of [impact_GetChannelCount](#) samples

8.4.2.6 impact_InitProcess()

```
struct impact\_CInstance* impact_InitProcess (
    const char * LoginKey,
    const char * RadioName,
    const char * AWS_Access_ID,
    const char * AWS_Access_Secret,
    const char * save_path )
```

Create a process instance with default parameters (from env)

Same as [impact_InitProcess2](#), but with default parameters (from env)

Deprecated Use [impact_InitProcess3](#)

8.4.2.7 impact_InitProcess2()

```
struct impact\_CInstance* impact_InitProcess2 (
    const char * LoginKey,
    const char * RadioName,
    const char * AWS_Access_ID,
    const char * AWS_Access_Secret,
    const char * save_path,
    const struct impact\_CParameters * parameters )
```

Create a process instance with default frames_per_chunk (64)

Same as [impact_InitProcess3](#), but with default frames_per_chunk

Deprecated Use [impact_InitProcess3](#)

8.4.2.8 impact_InitProcess3()

```
struct impact_CInstance* impact_InitProcess3 (
    const char * LoginKey,
    const char * RadioName,
    const char * AWS_Access_ID,
    const char * AWS_Access_Secret,
    const char * save_path,
    const struct impact_CParameters * parameters,
    unsigned int frames_per_chunk )
```

Create a process instance

The output will have to be freed with `impact_ExitProcess`

Attention

The **save_path** must be an existing folder with R/W access, or be NULL (then it uses volatile memory storage)

If the `save_path` is NULL or the folder is empty, a default configuration with a default preset will be loaded, unless using [Custom preset management](#).

If used in a container, we recommend to put a volume for this path, so it will survive updates.

Web login initialization

If the storage is not yet initialized, you can choose how to protect the web access.
There are 2 modes:

1. Setup mode: you define a setup account, which can then create an administrator account.
The setup account always keeps the access and can delete the administrator.
2. Admin mode: you define the administrator, which will be the single administrator.

To select the mode, you have to put in the parameters

1. `SETUP_USER` (and optionally `SETUP_SECRET`) to select Setup mode
2. `ADMIN_USER` (and optionally `ADMIN_SECRET`) to select Admin mode
3. none: the web access is opened, no login will be asked

If you do not set the `xxx_SECRET`, then the setuppassword will be randomly generated and print in logs (at info severity).

You can also use the JSON api to change this after the storage is created : see [Change setup account](#)

License access

The licenses are retrieved via Internet and access some servers. You may use an alternate server by changing `LICENSE_SERVER` in the parameters.

Parameters

<i>LoginKey</i>	SOUND4 Login key (was User ID)
<i>RadioName</i>	SOUND4 RadioName
<i>AWS_Access_ID</i>	SOUND4 AWS access ID
<i>AWS_Access_Secret</i>	SOUND4 AWS access Secret
<i>save_path</i>	Path where we can load/save the configuration. If NULL, memory storage will be used.
<i>parameters</i>	Parameters
<i>frames_per_chunk</i>	The number of audio frames in each chunk of processing. Must be in the list returned by impact_GetPossibleChunkSizeInFrames

Returns

A new process instance

8.4.2.9 impact_NewParameters()

```
struct impact\_CParameters* impact_NewParameters ( )
```

Create parameters to use with [impact_InitProcess2](#).

The output will have to be freed with [impact_FreeParameters](#)

The default values are taken from environment (for compatibility).

8.4.2.10 impact_SetParameter()

```
void impact_SetParameter (
    struct impact\_CParameters * params,
    const char * name,
    const char * value )
```

Set a new parameter.

Some values are in taken from env, so see [Environment variables and parameters](#) for usable variables

See also [Custom preset manangement](#)

8.4.2.11 impact_TerminateProcess()

```
int impact_TerminateProcess (
    struct impact\_CInstance * instance )
```

Terminate the processing

This is useful only with file processing, to get the final status. For some plugins, this is mandatory

Parameters

<i>instance</i>	the instance to terminate
-----------------	---------------------------

Returns

0 is success, <0 if error, >0 if some status

8.5 Custom preset management

This allows to provide a customized preset management.

Typedefs

- typedef wchar_t [fs_char](#)
- typedef char *(* [impact_storage_reader](#)) (const [fs_char](#) *filename, void *userdata)
- typedef void(* [impact_storage_reader_free](#)) (char *content, void *userdata)
- typedef int(* [impact_storage_writer](#)) (const [fs_char](#) *filename, const char *content, void *userdata)
- typedef int(* [impact_storage_exists](#)) (const [fs_char](#) *filename, void *userdata)
- typedef [fs_char](#) *(* [impact_storage_getall](#)) (void *userdata)
- typedef void(* [impact_storage_getall_free](#)) ([fs_char](#) **all, void *userdata)
- typedef int(* [impact_storage_remove](#)) (const [fs_char](#) *filename, void *userdata)
- typedef int(* [impact_storage_rename](#)) (const [fs_char](#) *from, const [fs_char](#) *to, void *userdata)

Enumerations

- enum [impact_PresetChange_Kind](#) { [change_kind_created](#) = 1 , [change_kind_modified](#) , [change_kind_deleted](#) }

Functions

- void [impact_SetPresetManager](#) (struct [impact_CParameters](#) *params, [impact_storage_reader](#) reader, [impact_storage_reader_free](#), [impact_storage_writer](#) writer, [impact_storage_exists](#) exists, [impact_storage_getall](#) getall, [impact_storage_getall_free](#) getall_free, [impact_storage_remove](#) remove, [impact_storage_rename](#) rename, int IsReadOnly, void *userdata)
- void [impact_PresetManager_InformChange](#) (struct [impact_CInstance](#) *instance, const [fs_char](#) *relative_path, enum [impact_PresetChange_Kind](#) change_kind)

8.5.1 Detailed Description

This allows to provide a customized storage for presets and settings.

By default, the library store data on disk or in memory (see `save_path` parameter in [impact_InitProcess2](#)), but you may use these functions to store data.

It can be used for remote storage, database storage, ...

Known files:

- Files with name ending with `.pst` are presets
- `state.json` is the instance state file, holding settings and unsaved preset changes.
- `auth.json` is the storage for web authentication settings.
- `*.onair` are used for sharing preset on air name between instances (see `STATE_ONAIR` in [Parameters](#)).

Attention

`state.json` name can be overridden per instance with `STATE_FILENAME` in parameters, see [Parameters](#).

File names are in OS native characters (`wchar_t` for Windows, `char` in **UTF-8** for others)

8.5.2 Typedef Documentation

8.5.2.1 fs_char

```
typedef wchar_t fs_char
```

Definition at line 539 of file [sound4.impact.cl.h](#).

8.5.2.2 impact_storage_exists

```
typedef int(* impact_storage_exists) (const fs_char *filename, void *userdata)
```

Function to call to test if a stored file exists.

Parameters

<i>filename</i>	the name of the file to test.
<i>userdata</i>	the userdata passed to impact_SetPresetManager

Returns

-1 if not exists, 0 if it exists

Definition at line 578 of file [sound4.impact.cl.h](#).

8.5.2.3 impact_storage_getall

```
typedef fs_char**(* impact_storage_getall) (void *userdata)
```

Function to call to get all stored files' name. Result has to be freed with [impact_storage_getall_free](#) callback

Parameters

<i>userdata</i>	the userdata passed to impact_SetPresetManager
-----------------	--

Returns

A NULL terminated array of file names

Definition at line 587 of file [sound4.impact.cl.h](#).

8.5.2.4 impact_storage_getall_free

```
typedef void(* impact_storage_getall_free) (fs_char **all, void *userdata)
```

Function to call to free the result of `getall`.

Parameters

<i>all</i>	the returned value from <code>impact_storage_getall</code>
<i>userdata</i>	the userdata passed to impact_SetPresetManager

Definition at line 595 of file [sound4.impact.cl.h](#).

8.5.2.5 impact_storage_reader

```
typedef char*(* impact_storage_reader) (const fs_char *filename, void *userdata)
```

Function to call to read a stored file, returning its content.

Parameters

<i>filename</i>	the name of the file to read.
<i>userdata</i>	the userdata passed to impact_SetPresetManager

Returns

the **UTF-8** content of the file

Definition at line 551 of file [sound4.impact.cl.h](#).

8.5.2.6 impact_storage_reader_free

```
typedef void(* impact_storage_reader_free) (char *content, void *userdata)
```

Function to call to free the result of `impact_storage_reader`.

Parameters

<i>content</i>	the returned value from <code>impact_storage_reader</code>
<i>userdata</i>	the userdata passed to impact_SetPresetManager

Definition at line 559 of file [sound4.impact.cl.h](#).

8.5.2.7 impact_storage_remove

```
typedef int(* impact_storage_remove) (const fs_char *filename, void *userdata)
```

Function to call to remove a stored file.

Parameters

<i>filename</i>	the name of the file to remove.
<i>userdata</i>	the userdata passed to impact_SetPresetManager

Returns

-1 if failed, 0 if OK

Definition at line 604 of file [sound4.impact.cl.h](#).

8.5.2.8 impact_storage_rename

```
typedef int(* impact_storage_rename) (const fs_char *from, const fs_char *to, void *userdata)
```

Function to call to rename a stored file.

Parameters

<i>from</i>	The source file name (must exist)
<i>to</i>	The destination file name (must not exist)
<i>userdata</i>	the userdata passed to impact_SetPresetManager

Returns

-1 if failed, 0 if OK

Definition at line 614 of file [sound4.impact.cl.h](#).

8.5.2.9 impact_storage_writer

```
typedef int(* impact_storage_writer) (const fs_char *filename, const char *content, void *userdata)
```

Function to call to write a stored file.

Parameters

<i>filename</i>	the name of the file to write.
<i>content</i>	the UTF-8 content to write to the file
<i>userdata</i>	the userdata passed to impact_SetPresetManager

Returns

-1 if failed, 0 if OK

Definition at line 569 of file [sound4.impact.cl.h](#).

8.5.3 Enumeration Type Documentation

8.5.3.1 impact_PresetChange_Kind

```
enum impact_PresetChange_Kind
```

Kind of change on a storage path

Enumerator

<code>change_kind_created</code>	Path has been created.
<code>change_kind_modified</code>	Path has been modified.
<code>change_kind_deleted</code>	Path has been deleted.

Definition at line 647 of file [sound4.impact.cl.h](#).

8.5.4 Function Documentation

8.5.4.1 `impact_PresetManager_InformChange()`

```
void impact_PresetManager_InformChange (
    struct impact\_CInstance * instance,
    const fs\_char * relative_path,
    enum impact\_PresetChange\_Kind change_kind )
```

Inform that a change happened in the storage. This must be used only in conjunction with [impact_SetPresetManager](#)

Parameters

<i>instance</i>	the processing instance
<i>relative_path</i>	The path which changed, relative to the root storage
<i>change_kind</i>	What happened to this path

8.5.4.2 `impact_SetPresetManager()`

```
void impact_SetPresetManager (
    struct impact\_CParameters * params,
    impact\_storage\_reader reader,
    impact\_storage\_reader\_free ,
    impact\_storage\_writer writer,
    impact\_storage\_exists exists,
    impact\_storage\_getall getall,
    impact\_storage\_getall\_free getall_free,
    impact\_storage\_remove remove,
    impact\_storage\_rename rename,
    int IsReadOnly,
    void * userdata )
```

Setup a custom preset manager. This overrides the `save_path` in [impact_InitProcess2](#)

To dynamically update when storage change, see [impact_PresetManager_InformChange](#)

Parameters

<i>params</i>	The params to set up
<i>reader</i>	The function to read a file
<i>writer</i>	The function to write a file
<i>exists</i>	The function to test for a file presence
<i>getall</i>	The function to get all files in storage
<i>getall_free</i>	The function to free the result from getall
<i>remove</i>	The function to remove a file from storage
<i>rename</i>	The function to rename a file
<i>IsReadOnly</i>	Set to 1 if storage is read-only
<i>userdata</i>	The userdata parameter for callbacks

8.6 Metadata Management

Functions

- void [impact_SetMetadata](#) (struct [impact_CInstance](#) *instance, const char *key, const char *value)
- const char ** [impact_GetMetadataInfos](#) (struct [impact_CInstance](#) *instance)
- void [impact_FreeMetadataInfos](#) (struct [impact_CInstance](#) *instance, const char **infos)

8.6.1 Detailed Description

Metadata handling.

Metadata is used on-need, and might be used by extensions modules (Watermarking, Streaming, ...)

8.6.2 Function Documentation

8.6.2.1 [impact_FreeMetadataInfos\(\)](#)

```
void impact_FreeMetadataInfos (
    struct impact\_CInstance * instance,
    const char ** infos )
```

Frees the information returned by [impact_GetMetadataInfos](#).

Parameters

<i>instance</i>	the instance
<i>infos</i>	the infos

8.6.2.2 `impact_GetMetadataInfos()`

```
const char** impact_GetMetadataInfos (
    struct impact\_CInstance * instance )
```

Get information on known metadata keys.

Parameters

<i>instance</i>	the instance
-----------------	--------------

Returns

a list of key,descriptions, null terminated, of known metadata keys used in process and extensions. May be null. Should be freed with [impact_FreeMetadataInfos](#)

8.6.2.3 `impact_SetMetadata()`

```
void impact_SetMetadata (
    struct impact\_CInstance * instance,
    const char * key,
    const char * value )
```

Adds the specific metadata to the process.

It can come from any thread, and will be used as soon as possible. Setting a null value erase the metadata, which is different from setting an empty string. Initial metadata might be set as soon as instance is created (and before update thread).

Parameters

<i>instance</i>	the instance
<i>key</i>	the metadata key. If key contains a dot (like wm.KEY), it will be sent only to the matching plugin (ie wm here) without the prefix (ie KEY here). Use empty prefix for routing to main only.
<i>value</i>	the metadata value or nullptr to erase it.

8.7 Update Management

Functions

- void [impact_StartUpdateThread](#) (struct [impact_CInstance](#) *instance, unsigned int port)
- void [impact_StopUpdateThread](#) (struct [impact_CInstance](#) *instance)
- int [impact_WaitUpdateThreadReady](#) (struct [impact_CInstance](#) *instance, int milliseconds)

8.7.1 Detailed Description

Manage the process update.

8.7.2 Function Documentation

8.7.2.1 `impact_StartUpdateThread()`

```
void impact_StartUpdateThread (
    struct impact_CInstance * instance,
    unsigned int port )
```

Update function

This needs to run in a thread, which can have low priority. It will also allow the JSON access via TCP.

Remarks

This function does not return until it is stopped with `impact_StopUpdateThread`

Parameters

<i>instance</i>	the instance
<i>port</i>	the port to listen for incoming JSON connections. If 0, the JSON server is not accessible

8.7.2.2 `impact_StopUpdateThread()`

```
void impact_StopUpdateThread (
    struct impact_CInstance * instance )
```

Stop the update thread

Parameters

<i>instance</i>	the processing instance
-----------------	-------------------------

8.7.2.3 `impact_WaitUpdateThreadReady()`

```
int impact_WaitUpdateThreadReady (
    struct impact_CInstance * instance,
    int milliseconds )
```

Wait for the update thread to be ready

Parameters

<i>instance</i>	the processing instance
<i>milliseconds</i>	maximum time to wait in milliseconds

Returns

-1 if timeout waiting for the thread, 0 if OK

8.8 Direct processing

Functions

- void [impact_ProcessAudio](#) (struct [impact_CInstance](#) *instance, const float *input, float *output)
- void [impact_ProcessAudio_Planar](#) (struct [impact_CInstance](#) *instance, float const *const *input, float *const *output)
- float * [impact_GetBufferIn](#) (struct [impact_CInstance](#) *instance)
- float * [impact_GetBufferOut](#) (struct [impact_CInstance](#) *instance)
- unsigned int [impact_GetEstimatedDelay](#) (struct [impact_CInstance](#) *instance)

8.8.1 Detailed Description

Optimized processing with direct in->out.

8.8.2 Function Documentation

8.8.2.1 [impact_GetBufferIn\(\)](#)

```
float* impact_GetBufferIn (
    struct impact\_CInstance * instance )
```

Get preallocated aligned buffer for audio input for [impact_ProcessAudio\(\)](#)

The buffer is a float[256 * [impact_GetAudioInputCount\(\)](#) * [impact_GetChannelCount\(\)](#)]

So for this process/version : float[256*1*2]

Note

The calling process can allocate the buffer itself, but it must be aligned.

Parameters

<i>instance</i>	the processing instance
-----------------	-------------------------

Returns

An audio input dedicated buffer.

8.8.2.2 impact_GetBufferOut()

```
float* impact_GetBufferOut (
    struct impact_CInstance * instance )
```

Get preallocated aligned buffer for audio output for `impact_ProcessAudio()`

The buffer is a `float[256 * impact_GetAudioOutputCount() * impact_GetChannelCount()]`

So for this process/version : `float[256*1*2]`

Note

The calling process can allocate the buffer itself, but it must be aligned.

Parameters

<i>instance</i>	the processing instance
-----------------	-------------------------

Returns

An audio output dedicated buffer.

8.8.2.3 impact_GetEstimatedDelay()

```
unsigned int impact_GetEstimatedDelay (
    struct impact_CInstance * instance )
```

Get the delay (estimated) of current processing algorithm

Remarks

This is not very accurate, it does not take into account group delays.

Returns

Estimated delay in frames

8.8.2.4 `impact_ProcessAudio()`

```
void impact_ProcessAudio (
    struct impact\_CInstance * instance,
    const float * input,
    float * output )
```

Process an audio chunk

A chunk contains [impact_GetProcessChunkFrames](#) frames, set at init by `frames_per_chunk` in [impact_InitProcess3](#)

Input has [impact_GetAudioInputCount\(\)](#) * [impact_GetChannelCount\(\)](#) channels

Output has [impact_GetAudioOutputCount\(\)](#) * [impact_GetChannelCount\(\)](#) channels

Each sample is a native 32-bit floating-point number where 1.0 is full scale. Channels are interlaced, so the buffers are [L0,R0,L1,R1,...,Ln,Rn] (L=Left, R=Right)

In case of multiple audio input/output, buffer is [aL0,aR0,bL0,bR0,...,aLn,aRn,bLn,bRn]

Warning

Buffers must be 64-byte aligned

Note

With 64 frames per chunk and 2 channels and 1 audio input, input buffer size is 64*1*2*4=512 bytes

Parameters

<i>instance</i>	the processing instance
<i>input</i>	audio input buffer (64 byte aligned) or NULL to use internal buffer impact_GetBufferIn
<i>output</i>	audio output buffer (64 byte aligned) or NULL to use internal buffer impact_GetBufferOut

8.8.2.5 `impact_ProcessAudio_Planar()`

```
void impact_ProcessAudio_Planar (
    struct impact\_CInstance * instance,
    float const *const * input,
    float *const * output )
```

Process an audio chunk of planar audio

A chunk contains [impact_GetProcessChunkFrames](#) frames, set at init by `frames_per_chunk` in [impact_InitProcess3](#)

Input has [impact_GetAudioInputCount\(\)](#) * [impact_GetChannelCount\(\)](#) channels

Output has [impact_GetAudioOutputCount\(\)](#) * [impact_GetChannelCount\(\)](#) channels

Each sample is a native 32-bit floating-point number where 1.0 is full scale. Channels are NOT interlaced, so the buffers are arrays of planar audio : [[L0,L1,...,Ln] , [R0,R1,...,Rn]] (L=Left, R=Right)

In case of multiple audio input/output, buffer are [[aL...], [aR...], [bL...], [bR...], ...]

Parameters

<i>instance</i>	the processing instance
<i>input</i>	array of audio input buffers for each input channel (no alignment required)
<i>output</i>	array of audio output buffers for each input channel (no alignment required)

8.9 Audio managing (any audio)

Enumerations

- enum `impact_SampleFormat` {
`INVALID_FORMAT` = 0, `S16_LE`, `S16_BE`, `S24_LE`,
`S24_BE`, `S32_LE`, `S32_BE`, `F32_LE`,
`F32_BE`, `S16_NATIVE` = `S16_LE`, `S24_NATIVE` = `S24_LE`, `S32_NATIVE` = `S32_LE`,
`F32_NATIVE` = `F32_LE` }

Functions

- const char * `impact_GetFormatName` (const enum `impact_SampleFormat` fmt)
- enum `impact_SampleFormat` `impact_GetFormatFromName` (const char *name)
- unsigned int `impact_GetBytesFromFormat` (const enum `impact_SampleFormat` fmt)
- unsigned int `impact_GetMaxPacketFrame` (struct `impact_CInstance` *instance)
- unsigned int `impact_AddAudio` (struct `impact_CInstance` *instance, const uint8_t *payload, unsigned int n↔
Frame, enum `impact_SampleFormat` fmt)
- unsigned int `impact_AddPadAudio` (struct `impact_CInstance` *instance)
- unsigned int `impact_GetOutputCount` (struct `impact_CInstance` *instance)
- unsigned int `impact_GetAudio` (struct `impact_CInstance` *instance, uint8_t *payload, unsigned int max_n↔
Frame, enum `impact_SampleFormat` fmt)

8.9.1 Detailed Description

This allows various payload size and formats, at the expense of internal conversions. This can be useful when receiving audio from network.

Remarks

It is more optimized to use [Direct processing](#).

8.9.2 Enumeration Type Documentation

8.9.2.1 impact_SampleFormat

```
enum impact_SampleFormat
```

Supported formats for audio I/O

Enumerator

INVALID_FORMAT	Invalid.
S16_LE	16-bit signed integer, little-endian
S16_BE	16-bit signed integer, big-endian
S24_LE	24-bit signed integer, little-endian
S24_BE	24-bit signed integer, big-endian
S32_LE	32-bit signed integer, little-endian
S32_BE	32-bit signed integer, big-endian
F32_LE	32-bit floating-point, little-endian
F32_BE	32-bit floating-point, big-endian
S16_NATIVE	16-bit signed integer, native
S24_NATIVE	24-bit signed integer, native
S32_NATIVE	32-bit signed integer, native
F32_NATIVE	32-bit floating-point, native

Definition at line 855 of file [sound4.impact.cl.h](#).

8.9.3 Function Documentation

8.9.3.1 `impact_AddAudio()`

```
unsigned int impact_AddAudio (
    struct impact\_CInstance * instance,
    const uint8_t * payload,
    unsigned int nFrame,
    enum impact\_SampleFormat fmt )
```

Convert and process the payload.

Parameters

<i>instance</i>	the processing instance
<i>payload</i>	the binary raw audio buffer
<i>nFrame</i>	the number of frames in the payload
<i>fmt</i>	the format of the payload

Returns

number of unprocessed frames (if can not store output) if non zero, consume output and restart where it stopped

8.9.3.2 `impact_AddPadAudio()`

```
unsigned int impact_AddPadAudio (
    struct impact_CInstance * instance )
```

Add silence to finish the current audio chunk and process it

Parameters

<i>instance</i>	the processing instance
-----------------	-------------------------

Returns

number of added silence frame

8.9.3.3 `impact_GetAudio()`

```
unsigned int impact_GetAudio (
    struct impact_CInstance * instance,
    uint8_t * payload,
    unsigned int max_nFrame,
    enum impact_SampleFormat fmt )
```

Consume the output

Parameters

<i>instance</i>	the processing instance
<i>payload</i>	the binary raw audio buffer to store output
<i>max_nFrame</i>	the maximum number of frames that can be stored in the payload
<i>fmt</i>	the wanted format of the payload

Returns

number of frames put in the buffer

8.9.3.4 `impact_GetBytesFromFormat()`

```
unsigned int impact_GetBytesFromFormat (
    const enum impact_SampleFormat fmt )
```

Get the format byte size

Parameters

<i>fmt</i>	the format
------------	------------

Returns

the number of bytes used by this format for a single channel audio sample

8.9.3.5 impact_GetFormatFromName()

```
enum impact\_SampleFormat impact_GetFormatFromName (
    const char * name )
```

Convert string to format

Parameters

<i>name</i>	the format string
-------------	-------------------

Returns

the matching format, or INVALID_FORMAT if invalid.

8.9.3.6 impact_GetFormatName()

```
const char* impact_GetFormatName (
    const enum impact\_SampleFormat fmt )
```

Convert format to string

Parameters

<i>fmt</i>	the format
------------	------------

Returns

the string name of the format

8.9.3.7 impact_GetMaxPacketFrame()

```
unsigned int impact_GetMaxPacketFrame (
    struct impact\_CInstance * instance )
```

Maximum packet size (in frames) that can be queued at output.

Parameters

<i>instance</i>	The process instance
-----------------	----------------------

Returns

Maximum packet size (in frames) that can be queued at output.

8.9.3.8 impact_GetOutputCount()

```
unsigned int impact_GetOutputCount (
    struct impact\_CInstance * instance )
```

Get the available output size

Parameters

<i>instance</i>	the processing instance
-----------------	-------------------------

Returns

number of available frames at output

8.10 Audio convert helpers**Functions**

- void [impact_AudioConvertFrom](#) (const uint8_t *payload, float *output, size_t nSpl, enum [impact_SampleFormat](#) fmt)
- void [impact_AudioConvertTo](#) (const float *input, uint8_t *payload, size_t nSpl, enum [impact_SampleFormat](#) fmt)
- void [impact_StereoToMono](#) (const float *input, float *output, size_t nFrame)
- void [impact_MonoToStereo](#) (const float *input, float *output, size_t nFrame)
- void [impact_StereoToMono_Planar](#) (const float *inputL, const float *inputR, float *output, size_t nFrame)
- void [impact_MonoToStereo_Planar](#) (const float *input, float *outputL, float *outputR, size_t nFrame)
- void [impact_AudioMonoFromLiveStereo](#) (const uint8_t *payload, float *output)
- void [impact_AudioMonoToLiveStereo](#) (const float *input, uint8_t *payload)

8.10.1 Detailed Description**8.10.2 Function Documentation**

8.10.2.1 impact_AudioConvertFrom()

```
void impact_AudioConvertFrom (
    const uint8_t * payload,
    float * output,
    size_t nSpl,
    enum impact_SampleFormat fmt )
```

Convert the payload to floating-point array

Warning

Output buffer must be 64-byte aligned

Parameters

<i>payload</i>	the binary raw audio buffer
<i>output</i>	audio output buffer (64 byte aligned)
<i>nSpl</i>	the number of samples (not frames)
<i>fmt</i>	the format of the payload

8.10.2.2 impact_AudioConvertTo()

```
void impact_AudioConvertTo (
    const float * input,
    uint8_t * payload,
    size_t nSpl,
    enum impact_SampleFormat fmt )
```

Convert floating-point array to payload

Warning

Input buffer must be 64-byte aligned

Parameters

<i>input</i>	audio input buffer (64 byte aligned)
<i>payload</i>	the binary raw audio buffer
<i>nSpl</i>	the number of samples (not frames)
<i>fmt</i>	the format of the payload

8.10.2.3 impact_AudioMonoFromLiveStereo()

```
void impact_AudioMonoFromLiveStereo (
```

```
const uint8_t * payload,
float * output )
```

Convert Livewire Livestereo payload to floating-point Mono (12 samples)

Parameters

<i>payload</i>	Livewire Live Stereo raw buffer
<i>output</i>	audio output mono buffer (64 byte aligned)

8.10.2.4 `impact_AudioMonoToLiveStereo()`

```
void impact_AudioMonoToLiveStereo (
    const float * input,
    uint8_t * payload )
```

Convert floating-point Mono (12 samples) to Livewire Livestereo payload

Parameters

<i>input</i>	audio input mono buffer (64 byte aligned)
<i>payload</i>	Livewire Live Stereo raw buffer

8.10.2.5 `impact_MonoToStereo()`

```
void impact_MonoToStereo (
    const float * input,
    float * output,
    size_t nFrame )
```

Convert floating-point Mono to Stereo (L,L)

Warning

Buffers must be 64-byte aligned

Parameters

<i>input</i>	audio input mono buffer (64 byte aligned)
<i>output</i>	audio output stereo buffer (64 byte aligned)
<i>nFrame</i>	the number of frames

8.10.2.6 impact_MonoToStereo_Planar()

```
void impact_MonoToStereo_Planar (
    const float * input,
    float * outputL,
    float * outputR,
    size_t nFrame )
```

Convert floating-point Mono to Stereo (planar) (L,L)

Warning

Buffers must be 64-byte aligned

Parameters

<i>input</i>	audio input mono buffer (64 byte aligned)
<i>outputL</i>	audio output left buffer (64 byte aligned)
<i>outputR</i>	audio output right buffer (64 byte aligned)
<i>nFrame</i>	the number of frames

8.10.2.7 impact_StereoToMono()

```
void impact_StereoToMono (
    const float * input,
    float * output,
    size_t nFrame )
```

Convert floating-point Stereo to Mono (L+R)/2

Warning

Buffers must be 64-byte aligned

Parameters

<i>input</i>	audio input stereo buffer (64 byte aligned)
<i>output</i>	audio output mono buffer (64 byte aligned)
<i>nFrame</i>	the number of frames

8.10.2.8 impact_StereoToMono_Planar()

```
void impact_StereoToMono_Planar (
    const float * inputL,
```

```

    const float * inputR,
    float * output,
    size_t nFrame )

```

Convert floating-point Stereo (planar) to Mono (L+R)/2

Warning

Buffers must be 64-byte aligned

Parameters

<i>inputL</i>	audio input left buffer (64 byte aligned)
<i>inputR</i>	audio input right buffer (64 byte aligned)
<i>output</i>	audio output mono buffer (64 byte aligned)
<i>nFrame</i>	the number of frames

8.11 Client's JSon config interfacing

Classes

- struct [impact_CClientInstance](#)

Functions

- struct [impact_CClientInstance](#) * [impact_NewClient](#) (struct [impact_CInstance](#) *instance)
- void [impact_DeleteClient](#) (struct [impact_CClientInstance](#) *client)
- const char * [impact_ProcessJson](#) (struct [impact_CClientInstance](#) *client, const char *json_str, int *need_save)
- void [impact_FreeJsonAnswer](#) (const char *json_str)
- int [impact_SaveState](#) (struct [impact_CInstance](#) *instance)

8.11.1 Detailed Description

Allow low-level JSON configuration. see also [JSON syntax](#)

8.11.2 Function Documentation

8.11.2.1 [impact_DeleteClient\(\)](#)

```

void impact_DeleteClient (
    struct impact\_CClientInstance * client )

```

Deletes a client

Parameters

<i>client</i>	the client instance
---------------	---------------------

8.11.2.2 impact_FreeJsonAnswer()

```
void impact_FreeJsonAnswer (
    const char * json_str )
```

Free a JSON answer returned by [impact_ProcessJson](#)

Parameters

<i>json_str</i>	the JSON request
-----------------	------------------

8.11.2.3 impact_NewClient()

```
struct impact_CClientInstance* impact_NewClient (
    struct impact_CInstance * instance )
```

Creates a new client

Remarks

not needed if using a port for JSON socket in [Update Management](#)

Parameters

<i>instance</i>	the processing instance
-----------------	-------------------------

Returns

A new client instance

8.11.2.4 impact_ProcessJson()

```
const char* impact_ProcessJson (
    struct impact_CClientInstance * client,
    const char * json_str,
    int * need_save )
```

Process a JSON request

For syntax, see [JSON syntax](#)

Note

In all library, all `char*` are **UTF-8** encoded

Attention

the return value needs to be freed with [impact_FreeJsonAnswer](#)

Parameters

<i>client</i>	the client instance
<i>json_str</i>	the JSON request
<i>need_save</i>	on return will be 1 if saving is required (maybe delayed)

Returns

a JSON answer (to be freed with [impact_FreeJsonAnswer](#))

8.11.2.5 impact_SaveState()

```
int impact_SaveState (
    struct impact\_CInstance * instance )
```

Save the current state

Needed when `impact_ProcessJson` returned with `need_save` to 1. However it can be postponed as much as wanted.

Remarks

Works only when update thread is running

Parameters

<i>instance</i>	the processing instance
-----------------	-------------------------

Returns

0 if success, <0 on error

8.12 JSON syntax

JSON protocol to configure the process

8.12.1 Commands

```
{ "get" : 'object' }
```

get values.

If `object` is null, get all parameters, and so show the possibilities

```
{ "set" : 'object' }
```

set values.

`object` can be any subpart, only those will be changed

```
{ "change" : 'object' }
```

like get, but shows only changes since last request.

If `object` is null, get all changes.

Each call resets the state for this connection to current.

Note

In Impact.cl version $\leq 1.1.7$, the state resetted also for filtered out objects. So avoid alternating `object filter` between calls, or you will miss some changes.

```
{ "load" : "'presetname'" }
```

load the preset

```
{ "save" : "'presetname'" }
```

save the preset.

If null is given, save onair preset

```
{ "delete" : "'presetname'" }
```

delete the preset.

can also be an array of presetnames

```
{ "factoryload" : "'presetname'" }
```

Create a preset from factory and load it

```
{ "rename" : { "preset" : "'presetname'", "name": "'newname'" } }
```

Rename a preset

```
{ "import" : { "preset" : "'presetname'", "content": 'presetcontent' } }
```

Import a preset

```
{ "export" : "'presetname'" }
```

Export a preset: get preset's content so it can be imported later

```
{ "new" : { "name": "'presetname'", "factory": "'presetname'" } }
```

Create a new preset from a factory.

Can use array for multiple.

```
{ "undo" : 'count' }
```

Undo last(s) `count` preset change

```
{ "redo" : 'count' }
```

Redo last(s) `count` preset change

See also [JSON syntax for internal setup](#)

8.12.2 Answers

Answer is also a JSON object, starting with the command for `get` and `change`.

```
{ "get" : ... }
{ "change" : ... }
```

For other commands, if there is no error the answer is

```
{ "OK" : { "command" : "original command" } }
```

If there is an error, answer has the syntax

```
{ "ERROR" : { "command" : "faulty command", "message" : "explaining" } }
```

and may have more properties. The message may be empty.

8.12.3 Examples

8.12.3.1 Get status

```
{"get":{"status":null}}
```

answer:

```
{"get":{"status":{"preset_changed":false,"license_valid":true,"version":"1.1.19"}}
```

8.12.3.2 Get all changes since last request

```
{"change":null}
```

answer:

```
{"change":{"processorname":"Best Radio of the world",  
  "settings":{"general":{"operate":true,...},  
  "preset":{"setup":{"gate_on": true, ...},...},  
  "vu":{"setup": null,"in":{...}},  
  ...  
}}
```

8.12.3.3 Check license

```
{"get":{"status":{"license_valid":null}}}
```

answer:

```
{"get":{"status":{"license_valid":true}}}
```

8.12.3.4 Set Processor name

```
{"set":{"processorname":"Best Radio of the world"}}
```

answer:

```
{"OK":"set"}
```

8.12.3.5 Get presetlist

```
{"get":{"presetlist":null}}
```

answer:

```
{"get":{"presetlist":[{"name":"Urban","factory_name":"Urban","create":"2020-10-15 16:19:17","modify":"2020-10-15 16:19:17"},  
  {"name":"Rock Classic","factory_name":"Rock Classic","create":"2020-10-15 16:19:17","modify":"2020-10-15 16:19:17"},  
  {"name":"Rock","factory_name":"Rock","create":"2020-10-15 16:19:17","modify":"2020-10-15 16:19:17"},  
  ...  
]}}
```

8.12.3.6 Load a preset

```
{"load":"Rock Classic"}
```

answer:

```
{"OK":"load"}
```

8.12.3.7 Get information on preset on air

```
{"get":{"presetinfo":null}}
```

answer:

```
{"get":{"presetinfo":{"name":"Rock Classic","factory_name":"Rock Classic","create":"2020-10-15 16:19:17","modify":"2020-10-15 16:19:17"}}
```

8.12.3.8 Set input gain

```
{"set":{"settings":{"gain":{"in":-3.0}}}}
```

answer:

```
{"OK":"set"}
```

8.12.3.9 Set bypass

```
{"set":{"settings":{"general":{"operate":false}}}}
```

answer:

```
{"OK":"set"}
```

8.12.3.10 Export a preset

```
{"export":"MyPresetName"}
```

answer:

```
{"export":{"processor":"Best Radio of the world","presets":{"MyPresetName":{"presetinfo":{"name":"MyPresetName","factory_name":"Open Sound","create":"2020-10-16 06:53:20","modify":"2020-10-16 06:53:26"},"preset":{"setup":{"gate":-39.0},"undoredo":{"undo":[{"time":"2020-10-16 06:53:23","action":{"preset":{"setup":{"gate":-30.0}}}}],"redo":[],"has_undo":true,"has_redo":false}}}}}}
```

Note

the object `export.presets["MyPresetName"]` in the answer is the one to use as *content* in [Import a preset](#)

8.12.3.11 Import a preset

```
{"import":{"preset":"MyNewPreset","content":{"presetinfo":{"name":"MyPresetName","factory_name":"Open Sound","create":"2020-10-16 06:53:20","modify":"2020-10-16 06:53:26"},"preset":{"setup":{"gate":-39.0},"undoredo":{"undo":[{"time":"2020-10-16 06:53:23","action":{"preset":{"setup":{"gate":-30.0}}}}],"redo":[],"has_undo":true,"has_redo":false}}}}}}
```

answer:

```
{"OK":"import"}
```

8.13 JSON syntax for internal setup

JSON commands for internal setup and information.

This is used internally for the web server.

This API might change in the future.

Those commands can be used when directly interfacing to the process (see [Client's JSON config interfacing](#)). They are blocked web going through web server (<http://.../json>)

The Authentication is effective only through the web server. The direct JSON commands are not filtered.

8.13.1 Get process and modules information

```
{"_info": null}
```

answer:

```
{"_info":{"product":"SOUND4 x1.CLOUD","version": "1.3.7","title": "x1
.CLOUD","preset_extension":"clx1","use_presets":true,"use_undoredo":true,
"_modules_":["","wm"],
"_modules_infos_":{"
  "wm":{"product":"SOUND4 WM","version": "0.1.0","title":"SOUND4
WM","use_presets":false,"use_undoredo":false}
}}}
```

8.13.2 Authentication management

Some API are available only if there is a setup/admin account.

Secret stored is

```
MD5(username+"."+realm+"."+password)
```

8.13.2.1 Difference between setup and admin account

There are 2 modes:

1. Setup mode: you define a setup account, which can then create an administrator account.
The setup account always keeps the access and can delete the administrator.
2. Admin mode: you define the administrator, which will be the single administrator.

From JSON, changing `setup_is_admin` can change the mode.

8.13.2.2 Access encoding

Access is a combinaison of letters.

- **'S'** Setup account : Allow Admin and delete admin
- **'A'** Admin access : Access to all overrides any other except setup
- **'x'** eXecute : change preset, list presets and preset infos and access settings.general fields
- **'v'** View : read preset and settings values
- **'w'** Write : change preset/settings (and undo/redo)
- **'s'** Save : create/save/delete/rename/import preset
- **'p'** Password : change own password
- **'-'** inactive : account is inactive

8.13.2.3 Change setup account

Allows to setup a setup account (even when is was not configured) or to remove it

8.13.2.3.1 Set the setup/admin account

```
{"_auth":{"init":{"setup_account":{"user":"admin","secret":"be666f22c03f199e05d3805430d69599"},"setup_is_admin":true,"u
```

answer:

```
{"OK":{"command":"_auth"}}
```

8.13.2.3.2 Set the setup/admin account with clear password

```
{"_auth":{"init":{"setup_account":{"user":"admin","secret_clear":"admin"},"setup_is_admin":true,"unlogged_access":"rx"}}
```

answer:

```
{"OK":{"command":"_auth"}}
```

8.13.2.3.3 Remove the setup/admin account

```
{"_auth":{"init":{"setup_account":null}}}
```

answer:

```
{"OK":{"command":"_auth"}}
```

8.13.2.4 Get user info

```
{"_auth":{"get":{"user":"username"}}}
```

answer:

```
{"_auth":{"get":{"user":"username","secret":"secrethash","access":"rwx"}}}
```

8.13.2.5 Add or modify a user

```
{"_auth":{"add":{"user":"username","secret":"secrethash","access":"rwx"}}}
```

answer:

```
{"_auth":{"add":{"user":"username","secret":"secrethash","access":"rwx"}}}
```

8.13.2.6 Removes a user

```
{"_auth":{"remove":{"user":"username"}}}
```

answer:

```
{"_auth":{"remove":{"user":"username"}}}
```

8.13.2.7 List users

```
{"_auth":{"list":null}}
```

answer:

```
{"_auth":{"list":["user1","user2",...]}}
```

8.13.2.8 Get/set unlogged access

```
{"_auth":{"get":{"unlogged_access":null}}}
```

answer:

```
{"_auth":{"get":{"unlogged_access":"rwx"}}}
```

8.13.2.9 Get realm

```
{"_auth":{"get":{"realm":null}}}
```

answer:

```
{"_auth":{"get":{"realm":"Authentication is required"}}}
```

8.13.2.10 Get API version

```
{"_auth":{"get":{"api_version":null}}}
```

answer:

```
{"_auth":{"get":{"api_version":2}}}
```

8.13.2.11 Get setup is admin

```
{"_auth":{"get":{"setup_is_admin":null}}}
```

answer:

```
{"_auth":{"get":{"setup_is_admin":true}}}
```

8.13.2.12 Get/set setup account

```
{"_auth":{"get":{"setup_account":null}}}
```

answer:

```
{"_auth":{"get":{"setup_account":{"user":"setup","secret":"secrethash","access":"sarwx"}}}}
```

8.13.2.13 Get/set custom storage

Implementation defined extra storage, stored in auth.json

```
{"_auth":{"get":{"storage":null}}}
```

answer:

```
{"_auth":{"get":{"storage":"whateverjson...}}}
```

8.13.3 Get process' interface description

8.13.3.1 Get XML decription

```
{"_vars_xml": null}
```

answer:

```
<?xml version="1.0"?>
<Process title="x1 .CLOUD" default_name="" preset_extension="clx1">
...
</Process>
```

Attention

The answer is XML, not JSON !

8.13.3.2 Get Process Image

```
{"_image": null}
```

answer:

```
{"_image":"iVBORw0KGgoAA..." }
```

The string is the base64 encoding of the image (png format)

8.13.3.3 Get Process Ico

```
{"_ico": null}
```

answer:

```
{"_ico": "AABAAUAEBAAAAEAIBo..." }
```

The string is the base64 encoding of the icon (ico format)

8.14 Web server

Macros

- #define [SOUND4_INVALID_WEBSERVER_ID](#) ((uint64_t)-1)
- #define [SOUND4_WEBSERVER_HTTP_OK](#) (1<<0)
- #define [SOUND4_WEBSERVER_HTTPS_OK](#) (1<<1)

Functions

- uint64_t [impact_Webserver_tcp](#) (unsigned int listenport, unsigned int listenport_secure, const char *socket_ip, unsigned int socket_port)
- uint64_t [impact_Webserver_tcp2](#) (unsigned int listenport, unsigned int listenport_secure, const char *socket_ip, unsigned int socket_port, const struct [impact_CParameters](#) *parameters)
- uint64_t [impact_Webserver](#) (unsigned int listenport, unsigned int listenport_secure, struct [impact_CInstance](#) *instance)
- int [impact_Webserver_Stop](#) (uint64_t id, int timeout_ms)
- int [impact_Webserver_Status](#) (uint64_t id)

8.14.1 Detailed Description

Run a web server to configure the processor

See also how to setup authentication with [Environment variables and parameters](#). Their use is documented in [impact_InitProcess](#).

8.14.2 Macro Definition Documentation

8.14.2.1 SOUND4_INVALID_WEBSERVER_ID

```
#define SOUND4_INVALID_WEBSERVER_ID ((uint64_t)-1)
```

This represents an invalid webserver id [impact_Webserver](#) and [impact_Webserver_tcp](#) will never return this value

Definition at line [1502](#) of file [sound4.impact.cl.h](#).

8.14.2.2 SOUND4_WEBSERVER_HTTP_OK

```
#define SOUND4_WEBSERVER_HTTP_OK (1<<0)
```

If this bit is set in the return value from [impact_Webserver_Status](#), then HTTP server is OK

Definition at line 1507 of file [sound4.impact.cl.h](#).

8.14.2.3 SOUND4_WEBSERVER_HTTPS_OK

```
#define SOUND4_WEBSERVER_HTTPS_OK (1<<1)
```

If this bit is set in the return value from [impact_Webserver_Status](#), then HTTPS server is OK

Definition at line 1511 of file [sound4.impact.cl.h](#).

8.14.3 Function Documentation

8.14.3.1 impact_Webserver()

```
uint64_t impact_Webserver (
    unsigned int listenport,
    unsigned int listenport_secure,
    struct impact_CInstance * instance )
```

Run a web server, connecting to local instance internally (no expose port needed)

This function returns after connecting to the process, and continue to run in background See [impact_Webserver_Stop](#) too stop it gracefully

For secure connection, it will use `privatekey.pem` and `certificate.pem` from current directory. Environment variables `SSL_PRIVATE_PATH` and `SSL_CERTIFICATE_PATH` can override those (see [Environment variables and parameters](#)). If none is valid, it will try also `/etc/ssl/certs/server.key` and `/etc/ssl/certs/server.crt`.

Warning

On Windows, calling this from Go<1.20 code will crash.

Parameters

<i>listenport</i>	The port to listen for HTTP connections (0 to disable)
<i>listenport_secure</i>	The port to listen for HTTPS connections (0 to disable)
<i>instance</i>	The process instance to connect to

Returns

id of webserver (starting at 0), to use with `impact_Webserver_Stop`

8.14.3.2 `impact_Webserver_Status()`

```
int impact_Webserver_Status (
    uint64_t id )
```

Get the web server status

Warning

On Windows, calling this from Go<1.20 code will crash.

Parameters

<i>id</i>	The web server Id, returned by impact_Webserver_tcp or impact_Webserver
-----------	---

Returns

a combinaison of [SOUND4_WEBSERVER_HTTP_OK](#) and [SOUND4_WEBSERVER_HTTPS_OK](#) depending on the server status

8.14.3.3 `impact_Webserver_Stop()`

```
int impact_Webserver_Stop (
    uint64_t id,
    int timeout_ms )
```

Stop a web server started with [impact_Webserver_tcp](#)

Warning

On Windows, calling this from Go<1.20 code will crash.

Parameters

<i>id</i>	The web server Id, returned by impact_Webserver_tcp or impact_Webserver
<i>timeout_ms</i>	The timeout to wait gracefull shutdown

Returns

0 if succeed, -1 if the id is not found

8.14.3.4 `impact_Webserver_tcp()`

```
uint64_t impact_Webserver_tcp (
    unsigned int listenport,
    unsigned int listenport_secure,
    const char * socket_ip,
    unsigned int socket_port )
```

Run a web server, connecting to process with JSON over TCP

This function returns after connecting to the process, and continue to run in background See [impact_Webserver_Stop](#) too stop it gracefully

For secure connection, it will use `privatekey.pem` and `certificate.pem` from current directory. Environment variables `SSL_PRIVATE_PATH` and `SSL_CERTIFICATE_PATH` can override those (see [Environment variables and parameters](#)). If none is valid, it will try also `/etc/ssl/certs/server.key` and `/etc/ssl/certs/server.crt`.

Warning

On Windows, calling this from Go<1.20 code will crash.

Parameters

<i>listenport</i>	The port to listen for HTTP connections
<i>listenport_secure</i>	The port to listen for HTTPS connections
<i>socket_ip</i>	The ip of the process to connect to
<i>socket_port</i>	The port of the process's JSON server to connect to

Returns

id of webserver (starting at 0), to use with `impact_Webserver_Stop`

8.14.3.5 `impact_Webserver_tcp2()`

```
uint64_t impact_Webserver_tcp2 (
    unsigned int listenport,
    unsigned int listenport_secure,
    const char * socket_ip,
    unsigned int socket_port,
    const struct impact\_CParameters * parameters )
```

Run a web server, connecting to process with JSON over TCP, using parameters

This function returns after connecting to the process, and continue to run in background See [impact_Webserver_Stop](#) too stop it gracefully

For secure connection, it will use `privatekey.pem` and `certificate.pem` from current directory. Environment variables `SSL_PRIVATE_PATH` and `SSL_CERTIFICATE_PATH` can override those (see [Environment variables and parameters](#)). If none is valid, it will try also `/etc/ssl/certs/server.key` and `/etc/ssl/certs/server.crt`.

Warning

On Windows, calling this from Go<1.20 code will crash.

Parameters

<i>listenport</i>	The port to listen for HTTP connections
<i>listenport_secure</i>	The port to listen for HTTPS connections
<i>socket_ip</i>	The ip of the process to connect to
<i>socket_port</i>	The port of the process's JSON server to connect to
<i>parameters</i>	The parameters to use, created with impact_NewParameters

Returns

id of webserver (starting at 0), to use with `impact_Webserver_Stop`

8.15 Sample using C++ interface wrapper

See full example [cpp/sound4.impact.cl-pipe-cxx.cpp](#)

8.15.1 Setup and sanity checks

```
sound4::impact::SetLogSeverity(verbose5);
sound4::impact::SetLoggerCallback(MyLogger);
sound4::impact::CInstance instance;
instance.SetParam("ADMIN_USER", "admin");
instance.SetParam("ADMIN_SECRET", "admin");
```

8.15.2 Sample to create the processing instance

```
if (!instance.Create(LoginKey, RadioName, KeyId, AccessKey, store_path)) {
    std::cerr << "Failed to create the processing instance" << std::endl;
    return 1;
}
```

8.15.3 Communicating with the instance

See also[JSON syntax](#)

```
auto client = instance.NewClient();
auto answer = client->ProcessJson(R"JSON({"get":{"processorname":null}})JSON");
std::cerr << "Request for processor name returned " << answer << std::endl;
```

8.15.4 Starting a web-server

```
if (!instance.StartWebServer(listen_port, 0)) {
    std::cerr << "Failed to create the web server on port " << listen_port << std::endl;
    return 1;
}
```

8.15.5 Sample processing loop

```
while (!stopthread)
{
    // Read a chunk from stdin
    if (std::fread(instance.GetBufferIn().data(), sizeof(float), sound4::impact::InputSampleSize, stdin)
    != sound4::impact::InputSampleSize) {
        std::cerr << "ProcessLoop: input stopped" << std::endl;
        stopthread=true;
        break;
    }
    if (stopthread) break;
    // Process it
    instance.ProcessAudio();
    // Write it to stdout
    if (fwrite(instance.GetBufferOut().data(), sizeof(float), sound4::impact::OutputSampleSize, stdout)
    != sound4::impact::OutputSampleSize) {
        std::cerr << "Failed to write audio output" << std::endl;
        stopthread=true;
    }
}
```

8.16 Sample using C++ interface wrapper with dynamic library loading

See full example [cpp/sound4.impact.cl-pipe-dyn.cpp](#)

8.16.1 Dynamic loading

```
sound4::impact::dyn::CDynLib dynlib;
if (!dynlib.Load()) {
    std::cerr << "Failed to load processing library" << std::endl;
    return 1;
}
```

8.16.2 Setup and sanity checks

```
sound4::impact::dyn::SetLogSeverity(dynlib, verbose5);
sound4::impact::dyn::SetLoggerCallback(dynlib, MyLogger);
sound4::impact::dyn::CInstance instance(dynlib);
instance.SetParam("ADMIN_USER", "admin");
instance.SetParam("ADMIN_SECRET", "admin");
```

8.16.3 Sample to create the processing instance

```
if (!instance.Create(LoginKey, RadioName, KeyId, AccessKey, {})) {
    std::cerr << "Failed to create the processing instance" << std::endl;
    return 1;
}
```

8.16.4 Communicating with the instance

See also

JSON syntax

```
auto client = instance.NewClient();
auto answer = client->ProcessJson(R"JSON({"get":{"processorname":null}})JSON");
std::cerr << "Request for processor name returned " << answer << std::endl;
```

8.16.5 Starting a web-server

```
if (!instance.StartWebServer(listen_port, 0)) {
    std::cerr << "Failed to create the web server on port " << listen_port << std::endl;
    return 1;
}
```

8.16.6 Sample processing loop

```

while (!stopthread)
{
    // Read a chunk from stdin
    if (std::fread(instance.GetBufferIn().data(), sizeof(float), sound4::impact::dyn::InputSampleSize,
        stdin) != sound4::impact::dyn::InputSampleSize) {
        std::cerr << "ProcessLoop: input stopped" << std::endl;
        stopthread=true;
        break;
    }
    if (stopthread) break;
    // Process it
    instance.ProcessAudio();
    // Write it to stdout
    if (fwrite(instance.GetBufferOut().data(), sizeof(float), sound4::impact::dyn::OutputSampleSize,
        stdout) != sound4::impact::dyn::OutputSampleSize) {
        std::cerr << "Failed to write audio output" << std::endl;
        stopthread=true;
    }
}

```

8.16.7 Custom preset manager

```

class MyPresetManager : public sound4::impact::dyn::CPresetLoader {
public:
    MyPresetManager() = default;
    virtual ~MyPresetManager() = default;
    bool SetupPath(const std::filesystem::path& a_preset_path)
    {
        m_preset_path=a_preset_path;
        if ( !std::filesystem::exists(m_preset_path) ) {
            return false;
        }
        std::error_code ec;
        if ( !std::filesystem::is_directory(m_preset_path, ec) ) {
            return false;
        }
        return true;
    }
    virtual bool IsReadOnly() override { return false; };
    virtual bool Exists(const std::filesystem::path &name) override
    {
        std::error_code ec;
        return std::filesystem::exists(GetRealPath(name), ec);
    }
    virtual bool Remove(const std::filesystem::path &name) override
    {
        std::error_code ec;
        return std::filesystem::remove(GetRealPath(name), ec);
    }
    virtual bool Rename(const std::filesystem::path &from, const std::filesystem::path &to) override
    {
        std::error_code ec;
        std::filesystem::rename(GetRealPath(from), GetRealPath(to), ec);
        return (!ec);
    }
    virtual std::vector<std::filesystem::path> GetAll() override
    {
        std::vector<std::filesystem::path> list;
        for (const auto & entry : std::filesystem::directory_iterator(m_preset_path.c_str(),
            std::filesystem::directory_options::skip_permission_denied)) {
            if (entry.is_regular_file()) {
                list.push_back(std::filesystem::relative(entry.path(), m_preset_path).native());
            }
        }
        return list;
    }
    virtual std::string Read(const std::filesystem::path &filename) override
    {
        std::ifstream f(GetRealPath(filename));
        if ( f.fail() ) {
            return std::string();
        }
        std::ostringstream ss;
        ss << f.rdbuf();
        return ss.str();
    }
    virtual bool Write(const std::filesystem::path &filename, const std::string &content) override
    {
        std::ofstream f(GetRealPath(filename));
        if ( f.fail() ) {
            return false;
        }
    }
}

```

```
        f « content;
        if ( f.fail() ) {
            return false;
        }
        return true;
    }
private:
    std::filesystem::path m_preset_path;
    std::filesystem::path GetRealPath(const std::filesystem::path &name)
    {
        return m_preset_path / name;
    }
};
```

8.16.8 Custom preset manager loading

```
MyPresetManager preset_manager;
if (!store_path.empty()) {
    if (!preset_manager.SetupPath(store_path)) {
        std::cerr « "Failed to setup the custom preset manager on path " « store_path.c_str() «
        std::endl;
        return 1;
    }
    instance.SetPresetManager(&preset_manager);
}
```

Chapter 9

Namespace Documentation

9.1 dyn Namespace Reference

9.1.1 Detailed Description

Dynamic loading namespace

9.2 sound4 Namespace Reference

Namespaces

- [impact](#)

9.2.1 Detailed Description

SOUND4 namespace

9.3 sound4::impact Namespace Reference

Namespaces

- [dyn](#)
- [helper](#)

Classes

- class [CPresetLoader](#)
- class [CInstance](#)

Typedefs

- using [SampleFormat](#) = [impact_SampleFormat](#)
- using [LogSeverity](#) = [impact_LogSeverity](#)
- using [log_cb_t](#) = std::function< void([LogSeverity](#), const std::string &)>
- using [PresetChange_Kind](#) = [impact_PresetChange_Kind](#)

Variables

- const size_t [ChunkFrames](#) = [IMPACT_AUDIOFRAME_COUNT](#)
- const size_t [InputChannels](#) = [IMPACT_CHANNEL_COUNT](#)*[IMPACT_AUDIO_INPUT_COUNT](#)
- const size_t [OutputChannels](#) = [IMPACT_CHANNEL_COUNT](#)*[IMPACT_AUDIO_OUTPUT_COUNT](#)
- const size_t [InputSampleSize](#) = [ChunkFrames](#)*[InputChannels](#)
- const size_t [OutputSampleSize](#) = [ChunkFrames](#)*[OutputChannels](#)
- const size_t [SampleRate](#) = [IMPACT_SAMPLE_RATE](#)

9.3.1 Detailed Description

impact namespace

9.3.2 Typedef Documentation

9.3.2.1 log_cb_t

```
using sound4::impact::log\_cb\_t = typedef std::function<void(LogSeverity, const std::string&)>
```

Log callback type

Definition at line 320 of file [sound4.impact.cl.hpp](#).

9.3.2.2 LogSeverity

```
using sound4::impact::LogSeverity = typedef impact\_LogSeverity
```

Log Severity levels

Definition at line 316 of file [sound4.impact.cl.hpp](#).

9.3.2.3 PresetChange_Kind

```
using sound4::impact::PresetChange_Kind = typedef impact_PresetChange_Kind
```

Definition at line 380 of file [sound4.impact.cl.hpp](#).

9.3.2.4 SampleFormat

```
using sound4::impact::SampleFormat = typedef impact_SampleFormat
```

Definition at line 53 of file [sound4.impact.cl.hpp](#).

9.3.3 Variable Documentation

9.3.3.1 ChunkFrames

```
const size_t sound4::impact::ChunkFrames =IMPACT_AUDIOFRAME_COUNT
```

Number of frames in a chunk

Definition at line 57 of file [sound4.impact.cl.hpp](#).

9.3.3.2 InputChannels

```
const size_t sound4::impact::InputChannels =IMPACT_CHANNEL_COUNT*IMPACT_AUDIO_INPUT_COUNT
```

Number of float values in an input frame

Definition at line 61 of file [sound4.impact.cl.hpp](#).

9.3.3.3 InputSampleSize

```
const size_t sound4::impact::InputSampleSize =ChunkFrames*InputChannels
```

Number of float values for an input chunk

Definition at line 69 of file [sound4.impact.cl.hpp](#).

9.3.3.4 OutputChannels

```
const size_t sound4::impact::OutputChannels =IMPACT_CHANNEL_COUNT*IMPACT_AUDIO_OUTPUT_COUNT
```

Number of float values in an output frame

Definition at line 65 of file [sound4.impact.cl.hpp](#).

9.3.3.5 OutputSampleSize

```
const size_t sound4::impact::OutputSampleSize =ChunkFrames*OutputChannels
```

Number of float values for an output chunk

Definition at line 73 of file [sound4.impact.cl.hpp](#).

9.3.3.6 SampleRate

```
const size_t sound4::impact::SampleRate =IMPACT_SAMPLE_RATE
```

Sample rate of library

Definition at line 77 of file [sound4.impact.cl.hpp](#).

9.4 sound4::impact::dyn Namespace Reference

Namespaces

- [helper](#)

Classes

- class [CDynLib](#)
Dynamic library interface.
- class [CPresetLoader](#)
- class [CInstance](#)

Typedefs

- using [SampleFormat](#) = [impact_SampleFormat](#)
- using [LogSeverity](#) = [impact_LogSeverity](#)
- using [log_cb_t](#) = std::function< void([LogSeverity](#), const std::string &)>
- using [PresetChange_Kind](#) = [impact_PresetChange_Kind](#)

Variables

- const size_t [ChunkFrames](#) = IMPACT_AUDIOFRAME_COUNT
- const size_t [InputChannels](#) = IMPACT_CHANNEL_COUNT*IMPACT_AUDIO_INPUT_COUNT
- const size_t [OutputChannels](#) = IMPACT_CHANNEL_COUNT*IMPACT_AUDIO_OUTPUT_COUNT
- const size_t [InputSampleSize](#) = ChunkFrames*InputChannels
- const size_t [OutputSampleSize](#) = ChunkFrames*OutputChannels
- const size_t [SampleRate](#) = IMPACT_SAMPLE_RATE

9.4.1 Typedef Documentation

9.4.1.1 log_cb_t

```
using sound4::impact::dyn::log_cb_t = typedef std::function<void(LogSeverity, const std::string&)>
```

Log callback type

Definition at line 697 of file [sound4.impact.cl_dyn.hpp](#).

9.4.1.2 LogSeverity

```
using sound4::impact::dyn::LogSeverity = typedef impact_LogSeverity
```

Log Severity levels

Definition at line 693 of file [sound4.impact.cl_dyn.hpp](#).

9.4.1.3 PresetChange_Kind

```
using sound4::impact::dyn::PresetChange_Kind = typedef impact_PresetChange_Kind
```

Definition at line 765 of file [sound4.impact.cl_dyn.hpp](#).

9.4.1.4 SampleFormat

```
using sound4::impact::dyn::SampleFormat = typedef impact_SampleFormat
```

Definition at line 426 of file [sound4.impact.cl_dyn.hpp](#).

9.4.2 Variable Documentation

9.4.2.1 ChunkFrames

```
const size_t sound4::impact::dyn::ChunkFrames =IMPACT_AUDIOFRAME_COUNT
```

Number of frames in a chunk

Definition at line 430 of file [sound4.impact.cl_dyn.hpp](#).

9.4.2.2 InputChannels

```
const size_t sound4::impact::dyn::InputChannels =IMPACT_CHANNEL_COUNT*IMPACT_AUDIO_INPUT_COUNT
```

Number of float values in an input frame

Definition at line 434 of file [sound4.impact.cl_dyn.hpp](#).

9.4.2.3 InputSampleSize

```
const size_t sound4::impact::dyn::InputSampleSize =ChunkFrames*InputChannels
```

Number of float values for an input chunk

Definition at line 442 of file [sound4.impact.cl_dyn.hpp](#).

9.4.2.4 OutputChannels

```
const size_t sound4::impact::dyn::OutputChannels =IMPACT_CHANNEL_COUNT*IMPACT_AUDIO_OUTPUT_COUNT
```

Number of float values in an output frame

Definition at line 438 of file [sound4.impact.cl_dyn.hpp](#).

9.4.2.5 OutputSampleSize

```
const size_t sound4::impact::dyn::OutputSampleSize =ChunkFrames*OutputChannels
```

Number of float values for an output chunk

Definition at line 446 of file [sound4.impact.cl_dyn.hpp](#).

9.4.2.6 SampleRate

```
const size_t sound4::impact::dyn::SampleRate = IMPACT_SAMPLE_RATE
```

Sample rate of library

Definition at line 450 of file [sound4.impact.cl_dyn.hpp](#).

9.5 sound4::impact::dyn::helper Namespace Reference

Classes

- class [DynFuncHolder](#)
Helper to wrap a function pointer.
- class [CDynLoader](#)
Helper to load dynamic library.
- struct [SampleFormat](#)
Helper for Sample format types.
- struct [SampleFormat< int16_t >](#)
- struct [SampleFormat< int32_t >](#)
- struct [SampleFormat< float >](#)

Typedefs

- using [DynLib_t](#) = HMODULE
- using [DynFunc_t](#) = FARPROC

9.5.1 Detailed Description

helper functions for unicode strings in Windows

9.5.2 Typedef Documentation

9.5.2.1 DynFunc_t

```
using sound4::impact::dyn::helper::DynFunc_t = typedef FARPROC
```

Definition at line 77 of file [sound4.impact.cl_dyn.hpp](#).

9.5.2.2 DynLib_t

```
using sound4::impact::dyn::helper::DynLib_t = typedef HMODULE
```

Definition at line 76 of file [sound4.impact.cl_dyn.hpp](#).

9.6 sound4::impact::helper Namespace Reference

Classes

- struct [SampleFormat](#)
Helper for Sample format types.
- struct [SampleFormat< int16_t >](#)
- struct [SampleFormat< int32_t >](#)
- struct [SampleFormat< float >](#)

9.6.1 Detailed Description

helper functions for unicode strings in Windows

9.7 std Namespace Reference

Chapter 10

Class Documentation

10.1 sound4::impact::CInstance::CClient Class Reference

```
#include <sound4.impact.cl.hpp>
```

Public Member Functions

- [CClient](#) ([impact_CInstance](#) *instance)
- [CClient](#) (const [CInstance](#) &)=delete
- [CClient](#) & [operator=](#) (const [CInstance](#) &)=delete
- [~CClient](#) ()
- std::string [ProcessJson](#) (const std::string &request, bool *NeedSave=nullptr)

Process a JSON request and returns the answer.

10.1.1 Detailed Description

Low-level JSON client.

See also

[JSON syntax](#)

Definition at line [770](#) of file [sound4.impact.cl.hpp](#).

10.1.2 Constructor & Destructor Documentation

10.1.2.1 CClient() [1/2]

```
sound4::impact::CInstance::CClient::CClient (
    impact\_CInstance * instance ) [inline]
```

Definition at line [772](#) of file [sound4.impact.cl.hpp](#).

10.1.2.2 CClient() [2/2]

```
sound4::impact::CInstance::CClient::CClient (
    const CInstance & ) [delete]
```

10.1.2.3 ~CClient()

```
sound4::impact::CInstance::CClient::~~CClient ( ) [inline]
```

Definition at line 781 of file [sound4.impact.cl.hpp](#).

10.1.3 Member Function Documentation

10.1.3.1 operator=()

```
CClient& sound4::impact::CInstance::CClient::operator= (
    const CInstance & ) [delete]
```

10.1.3.2 ProcessJson()

```
std::string sound4::impact::CInstance::CClient::ProcessJson (
    const std::string & request,
    bool * NeedSave = nullptr ) [inline]
```

Parameters

<i>request</i>	the JSON request.
----------------	-------------------

See also

[JSON syntax](#)

Parameters

<i>NeedSave</i>	if non null, returns if the saving is required (maybe delayed)
-----------------	--

Returns

the JSON answer

Definition at line 795 of file [sound4.impact.cl.hpp](#).

The documentation for this class was generated from the following file:

- [sound4.impact.cl.hpp](#)

10.2 sound4::impact::dyn::CInstance::CClient Class Reference

```
#include <sound4.impact.cl_dyn.hpp>
```

Public Member Functions

- [CClient](#) ([impact_CInstance](#) *instance, [CDynLib](#) &dynlib)
- [CClient](#) (const [CInstance](#) &)=delete
- [CClient](#) & [operator=](#) (const [CInstance](#) &)=delete
- [~CClient](#) ()
- [std::string ProcessJson](#) (const [std::string](#) &request, [bool](#) *NeedSave=nullptr)
Process a JSON request and returns the answer.

10.2.1 Detailed Description

Low-level JSON client.

See also

[JSON syntax](#)

Definition at line 1170 of file [sound4.impact.cl_dyn.hpp](#).

10.2.2 Constructor & Destructor Documentation

10.2.2.1 CClient() [1/2]

```
sound4::impact::dyn::CInstance::CClient::CClient (
    impact\_CInstance * instance,
    CDynLib & dynlib ) [inline]
```

Definition at line 1172 of file [sound4.impact.cl_dyn.hpp](#).

10.2.2.2 CClient() [2/2]

```
sound4::impact::dyn::CInstance::CClient::CClient (
    const CInstance & ) [delete]
```

10.2.2.3 ~CClient()

```
sound4::impact::dyn::CInstance::CClient::~~CClient ( ) [inline]
```

Definition at line 1182 of file [sound4.impact.cl_dyn.hpp](#).

10.2.3 Member Function Documentation

10.2.3.1 operator=()

```
CClient& sound4::impact::dyn::CInstance::CClient::operator= (
    const CInstance & ) [delete]
```

10.2.3.2 ProcessJson()

```
std::string sound4::impact::dyn::CInstance::CClient::ProcessJson (
    const std::string & request,
    bool * NeedSave = nullptr ) [inline]
```

Parameters

<i>request</i>	the JSON request.
----------------	-------------------

See also

[JSON syntax](#)

Parameters

<i>NeedSave</i>	if non null, returns if the saving is required (maybe delayed)
-----------------	--

Returns

the JSON answer

Definition at line 1196 of file [sound4.impact.cl_dyn.hpp](#).

The documentation for this class was generated from the following file:

- [sound4.impact.cl_dyn.hpp](#)

10.3 sound4::impact::dyn::CDynLib Class Reference

Dynamic library interface.

```
#include <sound4.impact.cl_dyn.hpp>
```

Public Member Functions

- [CDynLib](#) ()=default
- bool [Load](#) (const std::filesystem::path &path=std::filesystem::current_path())
Loads the library.
- bool [IsOK](#) () const
Check if the library was loaded correctly.

Public Attributes

- [helper::DynFuncHolder](#)< decltype(impact_GetVersion) > [GetVersion](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetChunkSizeInFrames) > [GetChunkSizeInFrames](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetChannelCount) > [GetChannelCount](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetAudioInputCount) > [GetAudioInputCount](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetAudioOutputCount) > [GetAudioOutputCount](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetSampleRate) > [GetSampleRate](#)
- [helper::DynFuncHolder](#)< decltype(impact_SetLoggerCallback) > [SetLoggerCallback](#)
- [helper::DynFuncHolder](#)< decltype(impact_SetLogSeverity) > [SetLogSeverity](#)
- [helper::DynFuncHolder](#)< decltype(impact_NewParameters) > [NewParameters](#)
- [helper::DynFuncHolder](#)< decltype(impact_FreeParameters) > [FreeParameters](#)
- [helper::DynFuncHolder](#)< decltype(impact_SetParameter) > [SetParameter](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetParameter) > [GetParameter](#)
- [helper::DynFuncHolder](#)< decltype(impact_FreeParameterValue) > [FreeParameterValue](#)
- [helper::DynFuncHolder](#)< decltype(impact_InitProcess) > [InitProcess](#)
- [helper::DynFuncHolder](#)< decltype(impact_InitProcess2) > [InitProcess2](#)
- [helper::DynFuncHolder](#)< decltype(impact_TerminateProcess) > [TerminateProcess](#)
- [helper::DynFuncHolder](#)< decltype(impact_ExitProcess) > [ExitProcess](#)
- [helper::DynFuncHolder](#)< decltype(impact_StartUpdateThread) > [StartUpdateThread](#)
- [helper::DynFuncHolder](#)< decltype(impact_StopUpdateThread) > [StopUpdateThread](#)
- [helper::DynFuncHolder](#)< decltype(impact_WaitUpdateThreadReady) > [WaitUpdateThreadReady](#)
- [helper::DynFuncHolder](#)< decltype(impact_ProcessAudio) > [ProcessAudio](#)
- [helper::DynFuncHolder](#)< decltype(impact_ProcessAudio_Planar) > [ProcessAudio_Planar](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetBufferIn) > [GetBufferIn](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetBufferOut) > [GetBufferOut](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetEstimatedDelay) > [GetEstimatedDelay](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetFormatName) > [GetFormatName](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetFormatFromName) > [GetFormatFromName](#)
- [helper::DynFuncHolder](#)< decltype(impact_GetBytesFromFormat) > [GetBytesFromFormat](#)

- [helper::DynFuncHolder< decltype\(impact_GetMaxPacketFrame\) > GetMaxPacketFrame](#)
- [helper::DynFuncHolder< decltype\(impact_AddAudio\) > AddAudio](#)
- [helper::DynFuncHolder< decltype\(impact_AddPadAudio\) > AddPadAudio](#)
- [helper::DynFuncHolder< decltype\(impact_GetOutputCount\) > GetOutputCount](#)
- [helper::DynFuncHolder< decltype\(impact_GetAudio\) > GetAudio](#)
- [helper::DynFuncHolder< decltype\(impact_AudioConvertFrom\) > AudioConvertFrom](#)
- [helper::DynFuncHolder< decltype\(impact_AudioConvertTo\) > AudioConvertTo](#)
- [helper::DynFuncHolder< decltype\(impact_StereoToMono\) > StereoToMono](#)
- [helper::DynFuncHolder< decltype\(impact_MonoToStereo\) > MonoToStereo](#)
- [helper::DynFuncHolder< decltype\(impact_AudioMonoFromLiveStereo\) > AudioMonoFromLiveStereo](#)
- [helper::DynFuncHolder< decltype\(impact_AudioMonoToLiveStereo\) > AudioMonoToLiveStereo](#)
- [helper::DynFuncHolder< decltype\(impact_NewClient\) > NewClient](#)
- [helper::DynFuncHolder< decltype\(impact_DeleteClient\) > DeleteClient](#)
- [helper::DynFuncHolder< decltype\(impact_ProcessJson\) > ProcessJson](#)
- [helper::DynFuncHolder< decltype\(impact_FreeJsonAnswer\) > FreeJsonAnswer](#)
- [helper::DynFuncHolder< decltype\(impact_SaveState\) > SaveState](#)
- [helper::DynFuncHolder< decltype\(impact_Webserver_tcp\) > Webserver_tcp](#)
- [helper::DynFuncHolder< decltype\(impact_Webserver_tcp2\) > Webserver_tcp2](#)
- [helper::DynFuncHolder< decltype\(impact_Webserver\) > Webserver](#)
- [helper::DynFuncHolder< decltype\(impact_Webserver_Stop\) > Webserver_Stop](#)
- [helper::DynFuncHolder< decltype\(impact_Webserver_Status\) > Webserver_Status](#)
- [helper::DynFuncHolder< decltype\(impact_StereoToMono_Planar\) > StereoToMono_Planar](#)
- [helper::DynFuncHolder< decltype\(impact_MonoToStereo_Planar\) > MonoToStereo_Planar](#)
- [helper::DynFuncHolder< decltype\(impact_SetMetadata\) > SetMetadata](#)
- [helper::DynFuncHolder< decltype\(impact_GetMetadataInfos\) > GetMetadataInfos](#)
- [helper::DynFuncHolder< decltype\(impact_FreeMetadataInfos\) > FreeMetadataInfos](#)
- [helper::DynFuncHolder< decltype\(impact_SetPresetManager\) > SetPresetManager](#)
- [helper::DynFuncHolder< decltype\(impact_PresetManager_InformChange\) > PresetManager_InformChange](#)
- [helper::DynFuncHolder< decltype\(impact_GetPossibleChunkSizeInFrames\) > GetPossibleChunkSizeInFrames](#)
- [helper::DynFuncHolder< decltype\(impact_GetProcessChunkFrames\) > GetProcessChunkFrames](#)
- [helper::DynFuncHolder< decltype\(impact_InitProcess3\) > InitProcess3](#)

10.3.1 Detailed Description

Once you loaded the library with [Load\(\)](#), if it succeed you can use all the standard C functions from this library.

Definition at line 210 of file [sound4.impact.cl_dyn.hpp](#).

10.3.2 Constructor & Destructor Documentation

10.3.2.1 CDynLib()

```
sound4::impact::dyn::CDynLib::CDynLib ( ) [default]
```

10.3.3 Member Function Documentation

10.3.3.1 IsOk()

```
bool sound4::impact::dyn::CDynLib::IsOk ( ) const [inline]
```

Returns

true if OK.
false if not OK.

Definition at line 416 of file [sound4.impact.cl_dyn.hpp](#).

10.3.3.2 Load()

```
bool sound4::impact::dyn::CDynLib::Load (
    const std::filesystem::path & path = std::filesystem::current_path() ) [inline]
```

Parameters

<i>path</i>	the path of the library to load.
-------------	----------------------------------

Returns

true if library was loaded correctly.
false if library load failed. Do not use in this case !

Definition at line 302 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4 Member Data Documentation

10.3.4.1 AddAudio

```
helper::DynFuncHolder< decltype(impact_AddAudio) > sound4::impact::dyn::CDynLib::AddAudio
```

Definition at line 247 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.2 AddPadAudio

```
helper::DynFuncHolder< decltype(impact_AddPadAudio) > sound4::impact::dyn::CDynLib::AddPadAudio
```

Definition at line 248 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.3 AudioConvertFrom

```
helper::DynFuncHolder< decltype(impact_AudioConvertFrom) > sound4::impact::dyn::CDynLib::↵  
AudioConvertFrom
```

Definition at line 251 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.4 AudioConvertTo

```
helper::DynFuncHolder< decltype(impact_AudioConvertTo) > sound4::impact::dyn::CDynLib::↵  
AudioConvertTo
```

Definition at line 252 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.5 AudioMonoFromLiveStereo

```
helper::DynFuncHolder< decltype(impact_AudioMonoFromLiveStereo) > sound4::impact::dyn::CDyn↵  
Lib::AudioMonoFromLiveStereo
```

Definition at line 255 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.6 AudioMonoToLiveStereo

```
helper::DynFuncHolder< decltype(impact_AudioMonoToLiveStereo) > sound4::impact::dyn::CDyn↵  
Lib::AudioMonoToLiveStereo
```

Definition at line 256 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.7 DeleteClient

```
helper::DynFuncHolder< decltype(impact_DeleteClient) > sound4::impact::dyn::CDynLib::Delete↵  
Client
```

Definition at line 258 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.8 ExitProcess

```
helper::DynFuncHolder< decltype(impact_ExitProcess) > sound4::impact::dyn::CDynLib::Exit↵  
Process
```

Definition at line 234 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.9 FreeJsonAnswer

```
helper::DynFuncHolder< decltype(impact_FreeJsonAnswer ) > sound4::impact::dyn::CDynLib::Free↔  
JsonAnswer
```

Definition at line 260 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.10 FreeMetadataInfos

```
helper::DynFuncHolder< decltype(impact_FreeMetadataInfos ) > sound4::impact::dyn::CDynLib::↔  
FreeMetadataInfos
```

Definition at line 277 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.11 FreeParameters

```
helper::DynFuncHolder< decltype(impact_FreeParameters ) > sound4::impact::dyn::CDynLib::Free↔  
Parameters
```

Definition at line 227 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.12 FreeParameterValue

```
helper::DynFuncHolder< decltype(impact_FreeParameterValue ) > sound4::impact::dyn::CDynLib::↔  
FreeParameterValue
```

Definition at line 230 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.13 GetAudio

```
helper::DynFuncHolder< decltype(impact_GetAudio ) > sound4::impact::dyn::CDynLib::GetAudio
```

Definition at line 250 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.14 GetAudioInputCount

```
helper::DynFuncHolder< decltype(impact_GetAudioInputCount ) > sound4::impact::dyn::CDynLib::↔  
GetAudioInputCount
```

Definition at line 221 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.15 GetAudioOutputCount

```
helper::DynFuncHolder< decltype(impact_GetAudioOutputCount ) > sound4::impact::dyn::CDynLib↔  
::GetAudioOutputCount
```

Definition at line 222 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.16 GetBufferIn

```
helper::DynFuncHolder< decltype(impact_GetBufferIn ) > sound4::impact::dyn::CDynLib::Get↔  
BufferIn
```

Definition at line 240 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.17 GetBufferOut

```
helper::DynFuncHolder< decltype(impact_GetBufferOut ) > sound4::impact::dyn::CDynLib::Get↔  
BufferOut
```

Definition at line 241 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.18 GetBytesFromFormat

```
helper::DynFuncHolder< decltype(impact_GetBytesFromFormat ) > sound4::impact::dyn::CDynLib::↔  
GetBytesFromFormat
```

Definition at line 245 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.19 GetChannelCount

```
helper::DynFuncHolder< decltype(impact_GetChannelCount ) > sound4::impact::dyn::CDynLib::Get↔  
ChannelCount
```

Definition at line 220 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.20 GetChunkSizeInFrames

```
helper::DynFuncHolder< decltype(impact_GetChunkSizeInFrames ) > sound4::impact::dyn::CDynLib↔  
::GetChunkSizeInFrames
```

Definition at line 219 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.21 GetEstimatedDelay

```
helper::DynFuncHolder< decltype(impact_GetEstimatedDelay ) > sound4::impact::dyn::CDynLib::↔  
GetEstimatedDelay
```

Definition at line 242 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.22 GetFormatFromName

```
helper::DynFuncHolder< decltype(impact_GetFormatFromName ) > sound4::impact::dyn::CDynLib::↔  
GetFormatFromName
```

Definition at line 244 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.23 GetFormatName

```
helper::DynFuncHolder< decltype(impact_GetFormatName ) > sound4::impact::dyn::CDynLib::Get↔  
FormatName
```

Definition at line 243 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.24 GetMaxPacketFrame

```
helper::DynFuncHolder< decltype(impact_GetMaxPacketFrame ) > sound4::impact::dyn::CDynLib::↔  
GetMaxPacketFrame
```

Definition at line 246 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.25 GetMetadataInfos

```
helper::DynFuncHolder< decltype(impact_GetMetadataInfos ) > sound4::impact::dyn::CDynLib::↔  
GetMetadataInfos
```

Definition at line 276 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.26 GetOutputCount

```
helper::DynFuncHolder< decltype(impact_GetOutputCount ) > sound4::impact::dyn::CDynLib::Get↔  
OutputCount
```

Definition at line 249 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.27 GetParameter

```
helper::DynFuncHolder< decltype(impact_GetParameter ) > sound4::impact::dyn::CDynLib::Get↵  
Parameter
```

Definition at line 229 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.28 GetPossibleChunkSizeInFrames

```
helper::DynFuncHolder< decltype(impact_GetPossibleChunkSizeInFrames ) > sound4::impact::dyn::CDyn↵  
::CDynLib::GetPossibleChunkSizeInFrames
```

Definition at line 284 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.29 GetProcessChunkFrames

```
helper::DynFuncHolder< decltype(impact_GetProcessChunkFrames ) > sound4::impact::dyn::CDyn↵  
Lib::GetProcessChunkFrames
```

Definition at line 285 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.30 GetSampleRate

```
helper::DynFuncHolder< decltype(impact_GetSampleRate ) > sound4::impact::dyn::CDynLib::Get↵  
SampleRate
```

Definition at line 223 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.31 GetVersion

```
helper::DynFuncHolder< decltype(impact_GetVersion ) > sound4::impact::dyn::CDynLib::GetVersion
```

Definition at line 218 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.32 InitProcess

```
helper::DynFuncHolder< decltype(impact_InitProcess ) > sound4::impact::dyn::CDynLib::Init↵  
Process
```

Definition at line 231 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.33 InitProcess2

```
helper::DynFuncHolder< decltype(impact_InitProcess2 ) > sound4::impact::dyn::CDynLib::Init↵  
Process2
```

Definition at line 232 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.34 InitProcess3

```
helper::DynFuncHolder< decltype(impact_InitProcess3 ) > sound4::impact::dyn::CDynLib::Init↵  
Process3
```

Definition at line 286 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.35 MonoToStereo

```
helper::DynFuncHolder< decltype(impact_MonoToStereo ) > sound4::impact::dyn::CDynLib::MonoTo↵  
Stereo
```

Definition at line 254 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.36 MonoToStereo_Planar

```
helper::DynFuncHolder< decltype(impact_MonoToStereo_Planar ) > sound4::impact::dyn::CDynLib↵  
::MonoToStereo_Planar
```

Definition at line 272 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.37 NewClient

```
helper::DynFuncHolder< decltype(impact_NewClient ) > sound4::impact::dyn::CDynLib::NewClient
```

Definition at line 257 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.38 NewParameters

```
helper::DynFuncHolder< decltype(impact_NewParameters ) > sound4::impact::dyn::CDynLib::New↵  
Parameters
```

Definition at line 226 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.39 PresetManager_InformChange

```
helper::DynFuncHolder< decltype(impact_PresetManager_InformChange ) > sound4::impact::dyn::CDynLib::PresetManager_InformChange
```

Definition at line 281 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.40 ProcessAudio

```
helper::DynFuncHolder< decltype(impact_ProcessAudio ) > sound4::impact::dyn::CDynLib::ProcessAudio
```

Definition at line 238 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.41 ProcessAudio_Planar

```
helper::DynFuncHolder< decltype(impact_ProcessAudio_Planar ) > sound4::impact::dyn::CDynLib::ProcessAudio_Planar
```

Definition at line 239 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.42 ProcessJson

```
helper::DynFuncHolder< decltype(impact_ProcessJson ) > sound4::impact::dyn::CDynLib::ProcessJson
```

Definition at line 259 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.43 SaveState

```
helper::DynFuncHolder< decltype(impact_SaveState ) > sound4::impact::dyn::CDynLib::SaveState
```

Definition at line 261 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.44 SetLoggerCallback

```
helper::DynFuncHolder< decltype(impact_SetLoggerCallback ) > sound4::impact::dyn::CDynLib::SetLoggerCallback
```

Definition at line 224 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.45 SetLogSeverity

```
helper::DynFuncHolder< decltype(impact_SetLogSeverity) > sound4::impact::dyn::CDynLib::Set↔  
LogSeverity
```

Definition at line 225 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.46 SetMetadata

```
helper::DynFuncHolder< decltype(impact_SetMetadata) > sound4::impact::dyn::CDynLib::Set↔  
Metadata
```

Definition at line 275 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.47 SetParameter

```
helper::DynFuncHolder< decltype(impact_SetParameter) > sound4::impact::dyn::CDynLib::Set↔  
Parameter
```

Definition at line 228 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.48 SetPresetManager

```
helper::DynFuncHolder< decltype(impact_SetPresetManager) > sound4::impact::dyn::CDynLib::↔  
SetPresetManager
```

Definition at line 280 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.49 StartUpdateThread

```
helper::DynFuncHolder< decltype(impact_StartUpdateThread) > sound4::impact::dyn::CDynLib::↔  
StartUpdateThread
```

Definition at line 235 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.50 StereoToMono

```
helper::DynFuncHolder< decltype(impact_StereoToMono) > sound4::impact::dyn::CDynLib::Stereo↔  
ToMono
```

Definition at line 253 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.51 StereoToMono_Planar

```
helper::DynFuncHolder< decltype(impact_StereoToMono_Planar ) > sound4::impact::dyn::CDynLib↔  
::StereoToMono_Planar
```

Definition at line 271 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.52 StopUpdateThread

```
helper::DynFuncHolder< decltype(impact_StopUpdateThread ) > sound4::impact::dyn::CDynLib::↔  
StopUpdateThread
```

Definition at line 236 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.53 TerminateProcess

```
helper::DynFuncHolder< decltype(impact_TerminateProcess ) > sound4::impact::dyn::CDynLib::↔  
TerminateProcess
```

Definition at line 233 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.54 WaitUpdateThreadReady

```
helper::DynFuncHolder< decltype(impact_WaitUpdateThreadReady ) > sound4::impact::dyn::CDyn↔  
Lib::WaitUpdateThreadReady
```

Definition at line 237 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.55 Webserver

```
helper::DynFuncHolder< decltype(impact_Webserver ) > sound4::impact::dyn::CDynLib::Webserver
```

Definition at line 265 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.56 Webserver_Status

```
helper::DynFuncHolder< decltype(impact_Webserver_Status ) > sound4::impact::dyn::CDynLib::↔  
Webserver_Status
```

Definition at line 267 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.57 Webserver_Stop

```
helper::DynFuncHolder< decltype(impact_Webserver_Stop) > sound4::impact::dyn::CDynLib::↔
Webserver_Stop
```

Definition at line 266 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.58 Webserver_tcp

```
helper::DynFuncHolder< decltype(impact_Webserver_tcp) > sound4::impact::dyn::CDynLib::↔
Webserver_tcp
```

Definition at line 263 of file [sound4.impact.cl_dyn.hpp](#).

10.3.4.59 Webserver_tcp2

```
helper::DynFuncHolder< decltype(impact_Webserver_tcp2) > sound4::impact::dyn::CDynLib::↔
Webserver_tcp2
```

Definition at line 264 of file [sound4.impact.cl_dyn.hpp](#).

The documentation for this class was generated from the following file:

- [sound4.impact.cl_dyn.hpp](#)

10.4 sound4::impact::dyn::helper::CDynLoader Class Reference

Helper to load dynamic library.

```
#include <sound4.impact.cl_dyn.hpp>
```

Public Member Functions

- [CDynLoader](#) ()=default
- [CDynLoader](#) ([CDynLoader](#) &&)=default
- [CDynLoader](#) (const [CDynLoader](#) &)=delete
- [CDynLoader](#) & [operator=](#) ([CDynLoader](#) const &)=delete
- [operator bool](#) () const
- bool [isOk](#) () const
- bool [Load](#) (const std::filesystem::path &dynlib, uint32_t loadflags=LOAD_LIBRARY_SEARCH_DLL_LOAD_↔
_DIR|LOAD_LIBRARY_SEARCH_APPLICATION_DIR|LOAD_LIBRARY_SEARCH_USER_DIRS|LOAD_↔
LIBRARY_SEARCH_SYSTEM32)
- void [Close](#) ()
- template<typename T>
[DynFuncHolder](#)< T > [GetSymbol](#) (const std::string &name)
- template<typename T>
[DynFuncHolder](#)< T > [GetSymbol_safe](#) (const std::string &name)
- virtual ~[CDynLoader](#) ()

Static Public Member Functions

- static std::filesystem::path [GetThisLibraryPath](#) (void)

10.4.1 Detailed Description

Definition at line 101 of file [sound4.impact.cl_dyn.hpp](#).

10.4.2 Constructor & Destructor Documentation

10.4.2.1 CDynLoader() [1/3]

```
sound4::impact::dyn::helper::CDynLoader::CDynLoader ( ) [default]
```

10.4.2.2 CDynLoader() [2/3]

```
sound4::impact::dyn::helper::CDynLoader::CDynLoader (
    CDynLoader && ) [default]
```

10.4.2.3 CDynLoader() [3/3]

```
sound4::impact::dyn::helper::CDynLoader::CDynLoader (
    const CDynLoader & ) [delete]
```

10.4.2.4 ~CDynLoader()

```
virtual sound4::impact::dyn::helper::CDynLoader::~~CDynLoader ( ) [inline], [virtual]
```

Definition at line 198 of file [sound4.impact.cl_dyn.hpp](#).

10.4.3 Member Function Documentation

10.4.3.1 Close()

```
void sound4::impact::dyn::helper::CDynLoader::Close ( ) [inline]
```

Definition at line 159 of file [sound4.impact.cl_dyn.hpp](#).

10.4.3.2 GetSymbol()

```
template<typename T >  
DynFuncHolder<T> sound4::impact::dyn::helper::CDynLoader::GetSymbol (   
    const std::string & name ) [inline]
```

Definition at line 172 of file [sound4.impact.cl_dyn.hpp](#).

10.4.3.3 GetSymbol_safe()

```
template<typename T >  
DynFuncHolder<T> sound4::impact::dyn::helper::CDynLoader::GetSymbol_safe (   
    const std::string & name ) [inline]
```

Definition at line 180 of file [sound4.impact.cl_dyn.hpp](#).

10.4.3.4 GetThisLibraryPath()

```
static std::filesystem::path sound4::impact::dyn::helper::CDynLoader::GetThisLibraryPath (   
    void ) [inline], [static]
```

Definition at line 184 of file [sound4.impact.cl_dyn.hpp](#).

10.4.3.5 IsOk()

```
bool sound4::impact::dyn::helper::CDynLoader::IsOk ( ) const [inline]
```

Definition at line 113 of file [sound4.impact.cl_dyn.hpp](#).

10.4.3.6 Load()

```
bool sound4::impact::dyn::helper::CDynLoader::Load (
    const std::filesystem::path & dynlib,
    uint32_t loadflags = LOAD_LIBRARY_SEARCH_DLL_LOAD_DIR|LOAD_LIBRARY_SEARCH_APPLICATION_↵
    _DIR|LOAD_LIBRARY_SEARCH_USER_DIRS|LOAD_LIBRARY_SEARCH_SYSTEM32 ) [inline]
```

Definition at line 153 of file [sound4.impact.cl_dyn.hpp](#).

10.4.3.7 operator bool()

```
sound4::impact::dyn::helper::CDynLoader::operator bool ( ) const [inline]
```

Definition at line 110 of file [sound4.impact.cl_dyn.hpp](#).

10.4.3.8 operator=()

```
CDynLoader& sound4::impact::dyn::helper::CDynLoader::operator= (
    CDynLoader const & ) [delete]
```

The documentation for this class was generated from the following file:

- [sound4.impact.cl_dyn.hpp](#)

10.5 sound4::impact::CInstance Class Reference

```
#include <sound4.impact.cl.hpp>
```

Classes

- class [CClient](#)

Public Member Functions

- [CInstance](#) ()
- [CInstance](#) (const [CInstance](#) &)=delete
- [CInstance](#) & [operator=](#) (const [CInstance](#) &)=delete
- [~CInstance](#) ()
- bool [IsOk](#) () const
- void [SetParam](#) (const std::string &name, const std::string &value)
- std::string [GetParam](#) (const std::string &name)
- void [SetPresetManager](#) ([CPresetLoader](#) *preset_manager)
- bool [Create](#) (const std::string &LoginKey, const std::string &RadioName, const std::string &AWS_Access_ID, const std::string &AWS_Access_Secret, const std::filesystem::path &save_path, int json_port=0, unsigned int frames_per_chunk=64)
- unsigned int [GetChunkFrames](#) ()
- void [PresetManager_InformChange](#) (const std::filesystem::path &relative_path, [PresetChange_Kind](#) change_kind)
- void [SetMetadata](#) (const std::string &key, const char *value)
- std::vector< std::tuple< std::string, std::string > > [GetMetadataInfos](#) ()
- virtual void [OnUpdateThreadStart](#) ()
- virtual void [OnUpdateThreadStop](#) ()
- bool [StartWebServer](#) (int http_port, int https_port=0)
- void [StopWebServer](#) ()
- int [Terminate](#) ()
- void [Stop](#) ()
- unsigned int [GetEstimatedDelay](#) ()
- std::array< float, [InputSampleSize](#) > & [GetBufferIn](#) ()
- std::array< float, [OutputSampleSize](#) > & [GetBufferOut](#) ()
- void [ProcessAudio](#) ()
- void [ProcessAudio_Planar](#) (float const *const *input, float *const *output)
- template<typename T >
std::vector< T > [ProcessAnyAudio](#) (const std::vector< T > input)
- std::shared_ptr< [CClient](#) > [NewClient](#) ()

Protected Member Functions

- template<typename T >
unsigned int [AddAudio](#) (const T *payload, unsigned int nFrame)
- template<typename T >
unsigned int [GetAudio](#) (T *payload, unsigned int max_nFrame)

10.5.1 Detailed Description

Instance handling class

Definition at line 385 of file [sound4.impact.cl.hpp](#).

10.5.2 Constructor & Destructor Documentation

10.5.2.1 CInstance() [1/2]

```
sound4::impact::CInstance::CInstance ( ) [inline]
```

Creates the instance, with default parameters

Definition at line 390 of file [sound4.impact.cl.hpp](#).

10.5.2.2 CInstance() [2/2]

```
sound4::impact::CInstance::CInstance (
    const CInstance & ) [delete]
```

10.5.2.3 ~CInstance()

```
sound4::impact::CInstance::~~CInstance ( ) [inline]
```

Destructor, stopping any running tasks

Definition at line 401 of file [sound4.impact.cl.hpp](#).

10.5.3 Member Function Documentation

10.5.3.1 AddAudio()

```
template<typename T >
unsigned int sound4::impact::CInstance::AddAudio (
    const T * payload,
    unsigned int nFrame ) [inline], [protected]
```

Definition at line 826 of file [sound4.impact.cl.hpp](#).

10.5.3.2 Create()

```
bool sound4::impact::CInstance::Create (
    const std::string & LoginKey,
    const std::string & RadioName,
    const std::string & AWS_Access_ID,
    const std::string & AWS_Access_Secret,
    const std::filesystem::path & save_path,
    int json_port = 0,
    unsigned int frames_per_chunk = 64 ) [inline]
```

Creates and initialize the instance, and starts its update thread

See also

[impact_InitProcess2](#)

Parameters

<i>LoginKey</i>	SOUND4 Login key
<i>RadioName</i>	SOUND4 RadioName
<i>AWS_Access_ID</i>	SOUND4 AWS access ID
<i>AWS_Access_Secret</i>	SOUND4 AWS access Secret
<i>save_path</i>	Path where we can load/save the configuration
<i>json_port</i>	Optional json listening port
<i>frames_per_chunk</i>	The number of audio frames in each chunk of processing. Must be in the list returned by impact_GetPossibleChunkSizeInFrames , or 0 to set default

Returns

false if failed

Definition at line 487 of file [sound4.impact.cl.hpp](#).

10.5.3.3 GetAudio()

```
template<typename T >
unsigned int sound4::impact::CInstance::GetAudio (
    T * payload,
    unsigned int max_nFrame ) [inline], [protected]
```

Definition at line 832 of file [sound4.impact.cl.hpp](#).

10.5.3.4 GetBufferIn()

```
std::array<float, InputSampleSize>& sound4::impact::CInstance::GetBufferIn ( ) [inline]
```

Gets the input buffer used in [ProcessAudio](#)

Input has GetAudioInputCount() * GetChannelCount() channels

Each sample is a native 32-bit floating-point number where 1.0 is full scale. Channels are interlaced, so the buffers are [L0,R0,L1,R1,...,Ln,Rn] (L=Left, R=Right)

In case of multiple audio input/output, buffer is [aL0,aR0,bL0,bR0,...,aLn,aRn,bLn,bRn]

Definition at line 681 of file [sound4.impact.cl.hpp](#).

10.5.3.5 GetBufferOut()

```
std::array<float, OutputSampleSize>& sound4::impact::CInstance::GetBufferOut ( ) [inline]
```

Gets the output buffer used in [ProcessAudio](#)

Output has `GetAudioOutputCount() * GetChannelCount()` channels

Each sample is a native 32-bit floating-point number where 1.0 is full scale. Channels are interlaced, so the buffers are `[L0,R0,L1,R1,...,Ln,Rn]` (L=Left, R=Right)

In case of multiple audio input/output, buffer is `[aL0,aR0,bL0,bR0,...,aLn,aRn,bLn,bRn]`

Definition at line 698 of file [sound4.impact.cl.hpp](#).

10.5.3.6 GetChunkFrames()

```
unsigned int sound4::impact::CInstance::GetChunkFrames ( ) [inline]
```

Get the number of audio frames in each chunk of processing.

The value reflects the `frames_per_chunk` parameter passed to [Create](#)

Returns

the number of audio frames in each chunk of processing

Definition at line 524 of file [sound4.impact.cl.hpp](#).

10.5.3.7 GetEstimatedDelay()

```
unsigned int sound4::impact::CInstance::GetEstimatedDelay ( ) [inline]
```

Gets an estimated delay of current processing

See also

[impact_GetEstimatedDelay](#)

Definition at line 665 of file [sound4.impact.cl.hpp](#).

10.5.3.8 GetMetadataInfos()

```
std::vector< std::tuple<std::string, std::string> > sound4::impact::CInstance::GetMetadataInfos ( ) [inline]
```

Get information on known metadata keys.

Returns

a list of {key,description} of known metadata used in process and extensions.

Definition at line 568 of file [sound4.impact.cl.hpp](#).

10.5.3.9 GetParam()

```
std::string sound4::impact::CInstance::GetParam (
    const std::string & name ) [inline]
```

Gets a parameter value

See also

[impact_GetParameter](#)

Definition at line 427 of file [sound4.impact.cl.hpp](#).

10.5.3.10 IsOk()

```
bool sound4::impact::CInstance::IsOk ( ) const [inline]
```

Returns true if an instance has been created and not stopped.

Definition at line 409 of file [sound4.impact.cl.hpp](#).

10.5.3.11 NewClient()

```
std::shared_ptr<CClient> sound4::impact::CInstance::NewClient ( ) [inline]
```

Creates a low-level JSON client

See also

[JSON syntax](#)

Returns

a new client to communicate with the processing

Definition at line 818 of file [sound4.impact.cl.hpp](#).

10.5.3.12 OnUpdateThreadStart()

```
virtual void sound4::impact::CInstance::OnUpdateThreadStart ( ) [inline], [virtual]
```

Definition at line 588 of file [sound4.impact.cl.hpp](#).

10.5.3.13 OnUpdateThreadStop()

```
virtual void sound4::impact::CInstance::OnUpdateThreadStop ( ) [inline], [virtual]
```

Definition at line 590 of file [sound4.impact.cl.hpp](#).

10.5.3.14 operator=()

```
CInstance& sound4::impact::CInstance::operator= (
    const CInstance & ) [delete]
```

10.5.3.15 PresetManager_InformChange()

```
void sound4::impact::CInstance::PresetManager_InformChange (
    const std::filesystem::path & relative_path,
    PresetChange_Kind change_kind ) [inline]
```

Inform that a change happened in the storage. This must be used only in conjunction with [SetPresetManager](#)

Parameters

<i>relative_path</i>	The path which changed, relative to the root storage
<i>change_kind</i>	What happened to this path

Definition at line 538 of file [sound4.impact.cl.hpp](#).

10.5.3.16 ProcessAnyAudio()

```
template<typename T >
std::vector<T> sound4::impact::CInstance::ProcessAnyAudio (
    const std::vector< T > input ) [inline]
```

Process audio (different formats, less optimized)

Supports for int16_t, int32_t and float (32) in native endianness

Attention

the return count is independent from the input count due to `IMPACT_AUDIOFRAME_COUNT`

Template Parameters

<i>T</i>	the C type for one audio sample
----------	---------------------------------

Parameters

<i>input</i>	audio to process
--------------	------------------

Returns

processed audio

Definition at line 746 of file [sound4.impact.cl.hpp](#).

10.5.3.17 ProcessAudio()

```
void sound4::impact::CInstance::ProcessAudio ( ) [inline]
```

Process one audio chunk, from [GetBufferIn\(\)](#) to [GetBufferOut\(\)](#)

See also

[impact_ProcessAudio](#)

Definition at line 709 of file [sound4.impact.cl.hpp](#).

10.5.3.18 ProcessAudio_Planar()

```
void sound4::impact::CInstance::ProcessAudio_Planar (
    float const *const * input,
    float *const * output ) [inline]
```

Process one audio chunk, but with planar audio

Each sample is a native 32-bit floating-point number where 1.0 is full scale. Channels are NOT interlaced, so the buffers are arrays of planar audio : [[L0,L1,...,Ln] , [R0,R1,...,Rn]] (L=Left, R=Right)

In case of multiple audio input/output, buffer are [[aL...], [aR...], [bL...], [bR...], ...]

See also

[impact_ProcessAudio_Planar](#)

Parameters

<i>input</i>	has GetAudioInputCount() * GetChannelCount() channels
<i>output</i>	has GetAudioOutputCount() * GetChannelCount() channels

Definition at line 728 of file [sound4.impact.cl.hpp](#).

10.5.3.19 SetMetadata()

```
void sound4::impact::CInstance::SetMetadata (
    const std::string & key,
    const char * value ) [inline]
```

Adds the specific metadata to the process.

It can come from any thread, and will be used as soon as possible. Setting a null value erase the metadata, which is different from setting an empty string.

Parameters

<i>key</i>	the metadata key If key contains a dot (like wm.KEY), it will be sent only to the matching plugin (ie wm here) without the prefix (ie KEY here) Use empty prefix for routing to main only.
<i>value</i>	the metadata value or nullptr to erase it.

Definition at line 554 of file [sound4.impact.cl.hpp](#).

10.5.3.20 SetParam()

```
void sound4::impact::CInstance::SetParam (
    const std::string & name,
    const std::string & value ) [inline]
```

Set a parameter value

Must be done before [Create](#)

See also

[impact_SetParameter](#)

Definition at line 417 of file [sound4.impact.cl.hpp](#).

10.5.3.21 SetPresetManager()

```
void sound4::impact::CInstance::SetPresetManager (
    CPresetLoader * preset_manager ) [inline]
```

Sets a custom preset manager Optional, this overrides the `save_path` in [Create](#)

See also

[impact_SetPresetManager](#)

Must be done before [Create](#)

Parameters

<i>preset_manager</i>	The custom preset manager
-----------------------	---------------------------

Definition at line 445 of file [sound4.impact.cl.hpp](#).

10.5.3.22 StartWebServer()

```
bool sound4::impact::CInstance::StartWebServer (
    int http_port,
    int https_port = 0 ) [inline]
```

Starts a Web server on requested ports

See also

[impact_Webserver](#)

Definition at line 598 of file [sound4.impact.cl.hpp](#).

10.5.3.23 Stop()

```
void sound4::impact::CInstance::Stop ( ) [inline]
```

Stops the instance and its web server and its update thread.

See also

[impact_ExitProcess](#),
[impact_StopUpdateThread](#) and
[impact_Webserver_Stop](#)

Definition at line 646 of file [sound4.impact.cl.hpp](#).

10.5.3.24 StopWebServer()

```
void sound4::impact::CInstance::StopWebServer ( ) [inline]
```

Stops the Web server

See also

[impact_Webserver_Stop](#)

Definition at line 620 of file [sound4.impact.cl.hpp](#).

10.5.3.25 Terminate()

```
int sound4::impact::CInstance::Terminate ( ) [inline]
```

Terminate the processing. This is useful only with file processing, to get the final status.

See also

[impact_TerminateProcess](#)

Definition at line 635 of file [sound4.impact.cl.hpp](#).

The documentation for this class was generated from the following file:

- [sound4.impact.cl.hpp](#)

10.6 sound4::impact::dyn::CInstance Class Reference

```
#include <sound4.impact.cl_dyn.hpp>
```

Classes

- class [CClient](#)

Public Member Functions

- [CInstance](#) ([CDynLib](#) &dynlib)
- [CInstance](#) (const [CInstance](#) &)=delete
- [CInstance](#) & [operator=](#) (const [CInstance](#) &)=delete
- [~CInstance](#) ()
- bool [IsOk](#) () const
- void [SetParam](#) (const std::string &name, const std::string &value)
- std::string [GetParam](#) (const std::string &name)
- void [SetPresetManager](#) ([CPresetLoader](#) *preset_manager)
- bool [Create](#) (const std::string &LoginKey, const std::string &RadioName, const std::string &AWS_Access_ID, const std::string &AWS_Access_Secret, const std::filesystem::path &save_path, int json_port=0, unsigned int frames_per_chunk=64)
- unsigned int [GetChunkFrames](#) ()
- void [PresetManager_InformChange](#) (const std::filesystem::path &relative_path, [PresetChange_Kind](#) change_kind)
- void [SetMetadata](#) (const std::string &key, const char *value)
- std::vector< std::tuple< std::string, std::string > > [GetMetadataInfos](#) ()
- virtual void [OnUpdateThreadStart](#) ()
- virtual void [OnUpdateThreadStop](#) ()
- bool [StartWebServer](#) (int http_port, int https_port=0)
- void [StopWebServer](#) ()
- int [Terminate](#) ()
- void [Stop](#) ()
- unsigned int [GetEstimatedDelay](#) ()
- std::array< float, [InputSampleSize](#) > & [GetBufferIn](#) ()
- std::array< float, [OutputSampleSize](#) > & [GetBufferOut](#) ()
- void [ProcessAudio](#) ()
- void [ProcessAudio_Planar](#) (float const *const *input, float *const *output)
- template<typename T >
std::vector< T > [ProcessAnyAudio](#) (const std::vector< T > input)
- std::shared_ptr< [CClient](#) > [NewClient](#) ()

Protected Member Functions

- template<typename T >
unsigned int [AddAudio](#) (const T *payload, unsigned int nFrame)
- template<typename T >
unsigned int [GetAudio](#) (T *payload, unsigned int max_nFrame)

10.6.1 Detailed Description

Instance handling class

Definition at line 770 of file [sound4.impact.cl_dyn.hpp](#).

10.6.2 Constructor & Destructor Documentation

10.6.2.1 CInstance() [1/2]

```
sound4::impact::dyn::CInstance::CInstance (
    CDynLib & dynlib ) [inline]
```

Creates the instance, with default parameters

Definition at line 775 of file [sound4.impact.cl_dyn.hpp](#).

10.6.2.2 CInstance() [2/2]

```
sound4::impact::dyn::CInstance::CInstance (
    const CInstance & ) [delete]
```

10.6.2.3 ~CInstance()

```
sound4::impact::dyn::CInstance::~~CInstance ( ) [inline]
```

Destructor, stopping any running tasks

Definition at line 787 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3 Member Function Documentation

10.6.3.1 AddAudio()

```
template<typename T >
unsigned int sound4::impact::dyn::CInstance::AddAudio (
    const T * payload,
    unsigned int nFrame ) [inline], [protected]
```

Definition at line 1228 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.2 Create()

```
bool sound4::impact::dyn::CInstance::Create (
    const std::string & LoginKey,
    const std::string & RadioName,
    const std::string & AWS_Access_ID,
    const std::string & AWS_Access_Secret,
    const std::filesystem::path & save_path,
    int json_port = 0,
    unsigned int frames_per_chunk = 64 ) [inline]
```

Creates and initialize the instance, and starts its update thread

See also

[impact_InitProcess2](#)

Parameters

<i>LoginKey</i>	SOUND4 Login key
<i>RadioName</i>	SOUND4 RadioName
<i>AWS_Access_ID</i>	SOUND4 AWS access ID
<i>AWS_Access_Secret</i>	SOUND4 AWS access Secret
<i>save_path</i>	Path where we can load/save the configuration
<i>json_port</i>	Optional json listening port
<i>frames_per_chunk</i>	The number of audio frames in each chunk of processing. Must be in the list returned by impact_GetPossibleChunkSizeInFrames , or 0 to set default

Returns

false if failed

Definition at line 875 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.3 GetAudio()

```
template<typename T >
unsigned int sound4::impact::dyn::CInstance::GetAudio (
    T * payload,
    unsigned int max_nFrame ) [inline], [protected]
```

Definition at line 1234 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.4 GetBufferIn()

```
std::array<float, InputSampleSize>& sound4::impact::dyn::CInstance::GetBufferIn ( ) [inline]
```

Gets the input buffer used in [ProcessAudio](#)

Input has GetAudioInputCount() * GetChannelCount() channels

Each sample is a native 32-bit floating-point number where 1.0 is full scale. Channels are interlaced, so the buffers are [L0,R0,L1,R1,...,Ln,Rn] (L=Left, R=Right)

In case of multiple audio input/output, buffer is [aL0,aR0,bL0,bR0,...,aLn,aRn,bLn,bRn]

Definition at line 1081 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.5 GetBufferOut()

```
std::array<float, OutputSampleSize>& sound4::impact::dyn::CInstance::GetBufferOut ( ) [inline]
```

Gets the output buffer used in [ProcessAudio](#)

Output has `GetAudioOutputCount() * GetChannelCount()` channels

Each sample is a native 32-bit floating-point number where 1.0 is full scale. Channels are interlaced, so the buffers are `[L0,R0,L1,R1,...,Ln,Rn]` (L=Left, R=Right)

In case of multiple audio input/output, buffer is `[aL0,aR0,bL0,bR0,...,aLn,aRn,bLn,bRn]`

Definition at line 1098 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.6 GetChunkFrames()

```
unsigned int sound4::impact::dyn::CInstance::GetChunkFrames ( ) [inline]
```

Get the number of audio frames in each chunk of processing.

The value reflects the `frames_per_chunk` parameter passed to [Create](#)

Returns

the number of audio frames in each chunk of processing

Definition at line 918 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.7 GetEstimatedDelay()

```
unsigned int sound4::impact::dyn::CInstance::GetEstimatedDelay ( ) [inline]
```

Gets an estimated delay of current processing

See also

[impact_GetEstimatedDelay](#)

Definition at line 1065 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.8 GetMetadataInfos()

```
std::vector< std::tuple<std::string, std::string> > sound4::impact::dyn::CInstance::GetMetadataInfos ( ) [inline]
```

Get information on known metadata keys.

Returns

a list of {key,description} of known metadata used in process and extensions.

Definition at line 966 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.9 GetParam()

```
std::string sound4::impact::dyn::CInstance::GetParam (
    const std::string & name ) [inline]
```

Gets a parameter value

See also

[impact_GetParameter](#)

Definition at line 813 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.10 IsOk()

```
bool sound4::impact::dyn::CInstance::IsOk ( ) const [inline]
```

Returns true if an instance has been created and not stopped.

Definition at line 795 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.11 NewClient()

```
std::shared_ptr<CClient> sound4::impact::dyn::CInstance::NewClient ( ) [inline]
```

Creates a low-level JSON client

See also

[JSON syntax](#)

Returns

a new client to communicate with the processing

Definition at line 1220 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.12 OnUpdateThreadStart()

```
virtual void sound4::impact::dyn::CInstance::OnUpdateThreadStart ( ) [inline], [virtual]
```

Definition at line 988 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.13 OnUpdateThreadStop()

```
virtual void sound4::impact::dyn::CInstance::OnUpdateThreadStop ( ) [inline], [virtual]
```

Definition at line 990 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.14 operator=()

```
CInstance& sound4::impact::dyn::CInstance::operator= (
    const CInstance & ) [delete]
```

10.6.3.15 PresetManager_InformChange()

```
void sound4::impact::dyn::CInstance::PresetManager_InformChange (
    const std::filesystem::path & relative_path,
    PresetChange_Kind change_kind ) [inline]
```

Inform that a change happened in the storage. This must be used only in conjunction with [SetPresetManager](#)

Parameters

<i>relative_path</i>	The path which changed, relative to the root storage
<i>change_kind</i>	What happened to this path

Definition at line 932 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.16 ProcessAnyAudio()

```
template<typename T >
std::vector<T> sound4::impact::dyn::CInstance::ProcessAnyAudio (
    const std::vector< T > input ) [inline]
```

Process audio (different formats, less optimized)

Supports for int16_t, int32_t and float (32) in native endianness

Attention

the return count is independent from the input count due to `IMPACT_AUDIOFRAME_COUNT`

Template Parameters

<i>T</i>	the C type for one audio sample
----------	---------------------------------

Parameters

<i>input</i>	audio to process
--------------	------------------

Returns

processed audio

Definition at line 1146 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.17 ProcessAudio()

```
void sound4::impact::dyn::CInstance::ProcessAudio ( ) [inline]
```

Process one audio chunk, from [GetBufferIn\(\)](#) to [GetBufferOut\(\)](#)

See also

[impact_ProcessAudio](#)

Definition at line 1109 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.18 ProcessAudio_Planar()

```
void sound4::impact::dyn::CInstance::ProcessAudio_Planar (
    float const *const * input,
    float *const * output ) [inline]
```

Process one audio chunk, but with planar audio

Each sample is a native 32-bit floating-point number where 1.0 is full scale. Channels are NOT interlaced, so the buffers are arrays of planar audio : [[L0,L1,...,Ln] , [R0,R1,...,Rn]] (L=Left, R=Right)

In case of multiple audio input/output, buffer are [[aL...], [aR...], [bL...], [bR...], ...]

See also

[impact_ProcessAudio_Planar](#)

Parameters

<i>input</i>	has GetAudioInputCount() * GetChannelCount() channels
<i>output</i>	has GetAudioOutputCount() * GetChannelCount() channels

Definition at line 1128 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.19 SetMetadata()

```
void sound4::impact::dyn::CInstance::SetMetadata (
    const std::string & key,
    const char * value ) [inline]
```

Adds the specific metadata to the process.

It can come from any thread, and will be used as soon as possible. Setting a null value erase the metadata, which is different from setting an empty string.

Parameters

<i>key</i>	the metadata key If key contains a dot (like wm.KEY), it will be sent only to the matching plugin (ie wm here) without the prefix (ie KEY here) Use empty prefix for routing to main only.
<i>value</i>	the metadata value or nullptr to erase it.

Definition at line 950 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.20 SetParam()

```
void sound4::impact::dyn::CInstance::SetParam (
    const std::string & name,
    const std::string & value ) [inline]
```

Set a parameter value

Must be done before [Create](#)

See also

[impact_SetParameter](#)

Definition at line 803 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.21 SetPresetManager()

```
void sound4::impact::dyn::CInstance::SetPresetManager (
    CPresetLoader * preset_manager ) [inline]
```

Sets a custom preset manager Optional, this overrides the `save_path` in [Create](#)

See also

[impact_SetPresetManager](#)

Must be done before [Create](#)

Parameters

<i>preset_manager</i>	The custom preset manager
-----------------------	---------------------------

Definition at line 842 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.22 StartWebServer()

```
bool sound4::impact::dyn::CInstance::StartWebServer (
    int http_port,
    int https_port = 0 ) [inline]
```

Starts a Web server on requested ports

See also

[impact_Webserver](#)

Definition at line 998 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.23 Stop()

```
void sound4::impact::dyn::CInstance::Stop ( ) [inline]
```

Stops the instance and its web server and its update thread.

See also

[impact_ExitProcess](#),
[impact_StopUpdateThread](#) and
[impact_Webserver_Stop](#)

Definition at line 1046 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.24 StopWebServer()

```
void sound4::impact::dyn::CInstance::StopWebServer ( ) [inline]
```

Stops the Web server

See also

[impact_Webserver_Stop](#)

Definition at line 1020 of file [sound4.impact.cl_dyn.hpp](#).

10.6.3.25 Terminate()

```
int sound4::impact::dyn::CInstance::Terminate ( ) [inline]
```

Terminate the processing. This is useful only with file processing, to get the final status.

See also

[impact_TerminateProcess](#)

Definition at line 1035 of file [sound4.impact.cl_dyn.hpp](#).

The documentation for this class was generated from the following file:

- [sound4.impact.cl_dyn.hpp](#)

10.7 sound4::impact::CPresetLoader Class Reference

```
#include <sound4.impact.cl.hpp>
```

Public Member Functions

- [CPresetLoader](#) ()=default
- virtual [~CPresetLoader](#) ()=default
- virtual bool [IsReadOnly](#) ()=0
- virtual bool [Exists](#) (const std::filesystem::path &name)=0
- virtual bool [Remove](#) (const std::filesystem::path &name)=0
- virtual bool [Rename](#) (const std::filesystem::path &from, const std::filesystem::path &to)=0
- virtual std::vector< std::filesystem::path > [GetAll](#) ()=0
- virtual std::string [Read](#) (const std::filesystem::path &filename)=0
- virtual bool [Write](#) (const std::filesystem::path &filename, const std::string &content)=0

10.7.1 Detailed Description

Custom preset handler helper Derive from this class and call [CInstance::SetPresetManager](#)

Definition at line 367 of file [sound4.impact.cl.hpp](#).

10.7.2 Constructor & Destructor Documentation

10.7.2.1 CPresetLoader()

```
sound4::impact::CPresetLoader::CPresetLoader ( ) [default]
```

10.7.2.2 ~CPresetLoader()

```
virtual sound4::impact::CPresetLoader::~~CPresetLoader ( ) [virtual], [default]
```

10.7.3 Member Function Documentation

10.7.3.1 Exists()

```
virtual bool sound4::impact::CPresetLoader::Exists (
    const std::filesystem::path & name ) [pure virtual]
```

10.7.3.2 GetAll()

```
virtual std::vector<std::filesystem::path> sound4::impact::CPresetLoader::GetAll ( ) [pure
virtual]
```

10.7.3.3 IsReadOnly()

```
virtual bool sound4::impact::CPresetLoader::IsReadOnly ( ) [pure virtual]
```

10.7.3.4 Read()

```
virtual std::string sound4::impact::CPresetLoader::Read (
    const std::filesystem::path & filename ) [pure virtual]
```

10.7.3.5 Remove()

```
virtual bool sound4::impact::CPresetLoader::Remove (
    const std::filesystem::path & name ) [pure virtual]
```

10.7.3.6 Rename()

```
virtual bool sound4::impact::CPresetLoader::Rename (
    const std::filesystem::path & from,
    const std::filesystem::path & to ) [pure virtual]
```

10.7.3.7 Write()

```
virtual bool sound4::impact::CPresetLoader::Write (
    const std::filesystem::path & filename,
    const std::string & content ) [pure virtual]
```

The documentation for this class was generated from the following file:

- [sound4.impact.cl.hpp](#)

10.8 sound4::impact::dyn::CPresetLoader Class Reference

```
#include <sound4.impact.cl_dyn.hpp>
```

Inherited by [MyPresetManager](#).

Public Member Functions

- [CPresetLoader](#) ()=default
- virtual [~CPresetLoader](#) ()=default
- virtual bool [IsReadOnly](#) ()=0
- virtual bool [Exists](#) (const std::filesystem::path &name)=0
- virtual bool [Remove](#) (const std::filesystem::path &name)=0
- virtual bool [Rename](#) (const std::filesystem::path &from, const std::filesystem::path &to)=0
- virtual std::vector< std::filesystem::path > [GetAll](#) ()=0
- virtual std::string [Read](#) (const std::filesystem::path &filename)=0
- virtual bool [Write](#) (const std::filesystem::path &filename, const std::string &content)=0

10.8.1 Detailed Description

Custom preset handler helper Derive from this class and call [CInstance::SetPresetManager](#)

Definition at line 752 of file [sound4.impact.cl_dyn.hpp](#).

10.8.2 Constructor & Destructor Documentation

10.8.2.1 CPresetLoader()

```
sound4::impact::dyn::CPresetLoader::CPresetLoader ( ) [default]
```

10.8.2.2 ~CPresetLoader()

```
virtual sound4::impact::dyn::CPresetLoader::~~CPresetLoader ( ) [virtual], [default]
```

10.8.3 Member Function Documentation

10.8.3.1 Exists()

```
virtual bool sound4::impact::dyn::CPresetLoader::Exists (
    const std::filesystem::path & name ) [pure virtual]
```

Implemented in [MyPresetManager](#).

10.8.3.2 GetAll()

```
virtual std::vector<std::filesystem::path> sound4::impact::dyn::CPresetLoader::GetAll ( )
[pure virtual]
```

Implemented in [MyPresetManager](#).

10.8.3.3 IsReadOnly()

```
virtual bool sound4::impact::dyn::CPresetLoader::IsReadOnly ( ) [pure virtual]
```

Implemented in [MyPresetManager](#).

10.8.3.4 Read()

```
virtual std::string sound4::impact::dyn::CPresetLoader::Read (
    const std::filesystem::path & filename ) [pure virtual]
```

Implemented in [MyPresetManager](#).

10.8.3.5 Remove()

```
virtual bool sound4::impact::dyn::CPresetLoader::Remove (
    const std::filesystem::path & name ) [pure virtual]
```

Implemented in [MyPresetManager](#).

10.8.3.6 Rename()

```
virtual bool sound4::impact::dyn::CPresetLoader::Rename (
    const std::filesystem::path & from,
    const std::filesystem::path & to ) [pure virtual]
```

Implemented in [MyPresetManager](#).

10.8.3.7 Write()

```
virtual bool sound4::impact::dyn::CPresetLoader::Write (
    const std::filesystem::path & filename,
    const std::string & content ) [pure virtual]
```

Implemented in [MyPresetManager](#).

The documentation for this class was generated from the following file:

- [sound4.impact.cl_dyn.hpp](#)

10.9 sound4::impact::dyn::helper::DynFuncHolder< T > Class Template Reference

Helper to wrap a function pointer.

```
#include <sound4.impact.cl_dyn.hpp>
```

Public Member Functions

- [DynFuncHolder](#) ()=default
- [DynFuncHolder](#) ([DynFunc_t](#) a_ptr)
- [operator bool](#) () const
- [bool](#) [isOk](#) () const
- [operator T*](#) () const

10.9.1 Detailed Description

```
template<typename T>
class sound4::impact::dyn::helper::DynFuncHolder< T >
```

Parameters

T	is the function type, you may use <code>decltype(fn)</code>
-------------------	---

Definition at line 86 of file [sound4.impact.cl_dyn.hpp](#).

10.9.2 Constructor & Destructor Documentation

10.9.2.1 DynFuncHolder() [1/2]

```
template<typename T >
sound4::impact::dyn::helper::DynFuncHolder< T >::DynFuncHolder ( ) [default]
```

10.9.2.2 DynFuncHolder() [2/2]

```
template<typename T >
sound4::impact::dyn::helper::DynFuncHolder< T >::DynFuncHolder (
    DynFunc_t a_ptr ) [inline]
```

Definition at line 91 of file [sound4.impact.cl_dyn.hpp](#).

10.9.3 Member Function Documentation

10.9.3.1 IsOk()

```
template<typename T >
bool sound4::impact::dyn::helper::DynFuncHolder< T >::IsOk ( ) const [inline]
```

Definition at line 93 of file [sound4.impact.cl_dyn.hpp](#).

10.9.3.2 operator bool()

```
template<typename T >
sound4::impact::dyn::helper::DynFuncHolder< T >::operator bool ( ) const [inline]
```

Definition at line 92 of file [sound4.impact.cl_dyn.hpp](#).

10.9.3.3 operator T*()

```
template<typename T >
sound4::impact::dyn::helper::DynFuncHolder< T >::operator T* ( ) const [inline]
```

Definition at line 94 of file [sound4.impact.cl_dyn.hpp](#).

The documentation for this class was generated from the following file:

- [sound4.impact.cl_dyn.hpp](#)

10.10 impact_CClientInstance Struct Reference

```
#include <sound4.impact.cl.h>
```

10.10.1 Detailed Description

Abstract pointer for a client instance

The documentation for this struct was generated from the following file:

- [sound4.impact.cl.h](#)

10.11 `impact_CInstance` Struct Reference

```
#include <sound4.impact.cl.h>
```

10.11.1 Detailed Description

Abstract holder for a process instance

The documentation for this struct was generated from the following file:

- [sound4.impact.cl.h](#)

10.12 `impact_CParameters` Struct Reference

```
#include <sound4.impact.cl.h>
```

10.12.1 Detailed Description

Abstract holder for a process instance parameters

Definition at line 307 of file [sound4.impact.cl.h](#).

The documentation for this struct was generated from the following file:

- [sound4.impact.cl.h](#)

10.13 `MyPresetManager` Class Reference

[Custom preset manager]

Inherits [sound4::impact::dyn::CPresetLoader](#).

Public Member Functions

- [MyPresetManager](#) ()=default
- virtual [~MyPresetManager](#) ()=default
- bool [SetupPath](#) (const std::filesystem::path &a_preset_path)
- virtual bool [IsReadOnly](#) () override
- virtual bool [Exists](#) (const std::filesystem::path &name) override
- virtual bool [Remove](#) (const std::filesystem::path &name) override
- virtual bool [Rename](#) (const std::filesystem::path &from, const std::filesystem::path &to) override
- virtual std::vector< std::filesystem::path > [GetAll](#) () override
- virtual std::string [Read](#) (const std::filesystem::path &filename) override
- virtual bool [Write](#) (const std::filesystem::path &filename, const std::string &content) override

10.13.1 Detailed Description

Definition at line 119 of file [sound4.impact.cl-pipe-dyn.cpp](#).

10.13.2 Constructor & Destructor Documentation

10.13.2.1 MyPresetManager()

```
MyPresetManager::MyPresetManager ( ) [default]
```

10.13.2.2 ~MyPresetManager()

```
virtual MyPresetManager::~~MyPresetManager ( ) [virtual], [default]
```

10.13.3 Member Function Documentation

10.13.3.1 Exists()

```
virtual bool MyPresetManager::Exists (
    const std::filesystem::path & name ) [inline], [override], [virtual]
```

Implements [sound4::impact::dyn::CPresetLoader](#).

Definition at line 137 of file [sound4.impact.cl-pipe-dyn.cpp](#).

10.13.3.2 GetAll()

```
virtual std::vector<std::filesystem::path> MyPresetManager::GetAll ( ) [inline], [override],
[virtual]
```

Implements [sound4::impact::dyn::CPresetLoader](#).

Definition at line 153 of file [sound4.impact.cl-pipe-dyn.cpp](#).

10.13.3.3 IsReadOnly()

```
virtual bool MyPresetManager::IsReadOnly ( ) [inline], [override], [virtual]
```

Implements [sound4::impact::dyn::CPresetLoader](#).

Definition at line 136 of file [sound4.impact.cl-pipe-dyn.cpp](#).

10.13.3.4 Read()

```
virtual std::string MyPresetManager::Read (
    const std::filesystem::path & filename ) [inline], [override], [virtual]
```

Implements [sound4::impact::dyn::CPresetLoader](#).

Definition at line 163 of file [sound4.impact.cl-pipe-dyn.cpp](#).

10.13.3.5 Remove()

```
virtual bool MyPresetManager::Remove (
    const std::filesystem::path & name ) [inline], [override], [virtual]
```

Implements [sound4::impact::dyn::CPresetLoader](#).

Definition at line 142 of file [sound4.impact.cl-pipe-dyn.cpp](#).

10.13.3.6 Rename()

```
virtual bool MyPresetManager::Rename (
    const std::filesystem::path & from,
    const std::filesystem::path & to ) [inline], [override], [virtual]
```

Implements [sound4::impact::dyn::CPresetLoader](#).

Definition at line 147 of file [sound4.impact.cl-pipe-dyn.cpp](#).

10.13.3.7 SetupPath()

```
bool MyPresetManager::SetupPath (
    const std::filesystem::path & a_preset_path ) [inline]
```

Definition at line 124 of file [sound4.impact.cl-pipe-dyn.cpp](#).

10.13.3.8 Write()

```
virtual bool MyPresetManager::Write (
    const std::filesystem::path & filename,
    const std::string & content ) [inline], [override], [virtual]
```

Implements [sound4::impact::dyn::CPresetLoader](#).

Definition at line 173 of file [sound4.impact.cl-pipe-dyn.cpp](#).

The documentation for this class was generated from the following file:

- [sound4.impact.cl-pipe-dyn.cpp](#)

10.14 sound4::impact::dyn::helper::SampleFormat< T > Struct Template Reference

Helper for Sample format types.

```
#include <sound4.impact.cl_dyn.hpp>
```

10.14.1 Detailed Description

```
template<typename T>
struct sound4::impact::dyn::helper::SampleFormat< T >
```

Template Parameters

<i>T</i>	the C type for one audio sample
----------	---------------------------------

Definition at line 489 of file [sound4.impact.cl_dyn.hpp](#).

The documentation for this struct was generated from the following file:

- [sound4.impact.cl_dyn.hpp](#)

10.15 sound4::impact::helper::SampleFormat< T > Struct Template Reference

Helper for Sample format types.

```
#include <sound4.impact.cl.hpp>
```

10.15.1 Detailed Description

```
template<typename T>
struct sound4::impact::helper::SampleFormat< T >
```

Template Parameters

<i>T</i>	the C type for one audio sample
----------	---------------------------------

Definition at line 116 of file [sound4.impact.cl.hpp](#).

The documentation for this struct was generated from the following file:

- [sound4.impact.cl.hpp](#)

10.16 sound4::impact::dyn::helper::SampleFormat< float > Struct Reference

```
#include <sound4.impact.cl_dyn.hpp>
```

Public Attributes

- const [impact_SampleFormat](#) format = F32_NATIVE

10.16.1 Detailed Description

Definition at line 500 of file [sound4.impact.cl_dyn.hpp](#).

10.16.2 Member Data Documentation

10.16.2.1 format

```
const impact\_SampleFormat sound4::impact::dyn::helper::SampleFormat< float >::format = F32_NATIVE
```

Definition at line 501 of file [sound4.impact.cl_dyn.hpp](#).

The documentation for this struct was generated from the following file:

- [sound4.impact.cl_dyn.hpp](#)

10.17 sound4::impact::helper::SampleFormat< float > Struct Reference

```
#include <sound4.impact.cl.hpp>
```

Public Attributes

- const [impact_SampleFormat](#) format = F32_NATIVE

10.17.1 Detailed Description

Definition at line 127 of file [sound4.impact.cl.hpp](#).

10.17.2 Member Data Documentation

10.17.2.1 format

```
const impact\_SampleFormat sound4::impact::helper::SampleFormat< float >::format = F32_NATIVE
```

Definition at line 128 of file [sound4.impact.cl.hpp](#).

The documentation for this struct was generated from the following file:

- [sound4.impact.cl.hpp](#)

10.18 sound4::impact::dyn::helper::SampleFormat< int16_t > Struct Reference

```
#include <sound4.impact.cl_dyn.hpp>
```

Public Attributes

- const [impact_SampleFormat](#) format = S16_NATIVE

10.18.1 Detailed Description

Definition at line 492 of file [sound4.impact.cl_dyn.hpp](#).

10.18.2 Member Data Documentation

10.18.2.1 format

```
const impact_SampleFormat sound4::impact::dyn::helper::SampleFormat< int16_t >::format =  
S16_NATIVE
```

Definition at line 493 of file [sound4.impact.cl_dyn.hpp](#).

The documentation for this struct was generated from the following file:

- [sound4.impact.cl_dyn.hpp](#)

10.19 sound4::impact::helper::SampleFormat< int16_t > Struct Reference

```
#include <sound4.impact.cl.hpp>
```

Public Attributes

- const [impact_SampleFormat](#) format = S16_NATIVE

10.19.1 Detailed Description

Definition at line 119 of file [sound4.impact.cl.hpp](#).

10.19.2 Member Data Documentation

10.19.2.1 format

```
const impact_SampleFormat sound4::impact::helper::SampleFormat< int16_t >::format = S16_NATIVE
```

Definition at line 120 of file [sound4.impact.cl.hpp](#).

The documentation for this struct was generated from the following file:

- [sound4.impact.cl.hpp](#)

10.20 sound4::impact::dyn::helper::SampleFormat< int32_t > Struct Reference

```
#include <sound4.impact.cl_dyn.hpp>
```

Public Attributes

- const [impact_SampleFormat](#) format = [S32_NATIVE](#)

10.20.1 Detailed Description

Definition at line [496](#) of file [sound4.impact.cl_dyn.hpp](#).

10.20.2 Member Data Documentation

10.20.2.1 format

```
const impact\_SampleFormat sound4::impact::dyn::helper::SampleFormat< int32\_t >::format =  
S32\_NATIVE
```

Definition at line [497](#) of file [sound4.impact.cl_dyn.hpp](#).

The documentation for this struct was generated from the following file:

- [sound4.impact.cl_dyn.hpp](#)

10.21 [sound4::impact::helper::SampleFormat< int32_t >](#) Struct Reference

```
#include <sound4.impact.cl.hpp>
```

Public Attributes

- const [impact_SampleFormat](#) format = [S32_NATIVE](#)

10.21.1 Detailed Description

Definition at line [123](#) of file [sound4.impact.cl.hpp](#).

10.21.2 Member Data Documentation

10.21.2.1 format

```
const impact\_SampleFormat sound4::impact::helper::SampleFormat< int32\_t >::format = S32\_NATIVE
```

Definition at line [124](#) of file [sound4.impact.cl.hpp](#).

The documentation for this struct was generated from the following file:

- [sound4.impact.cl.hpp](#)

Chapter 11

File Documentation

11.1 sound4.impact.cl-pipe-cxx.cpp File Reference

C++ sample using C++ interface wrapper.

```
#include <unistd.h>
#include <iostream>
#include <strings.h>
#include <sys/types.h>
#include <filesystem>
#include <io.h>
#include <fcntl.h>
#include "sound4.impact.cl.hpp"
```

Functions

- `std::string GetEnv` (`const std::string &name`)
- `void ProcessLoop` (`sound4::impact::CInstance &instance`)
- `void Usage` (`const char *progname`)
- `void MyLogger` (`sound4::impact::LogSeverity severity`, `const std::string &msg`)
- `int main` (`int argc`, `const char **argv`)

11.1.1 Function Documentation

11.1.1.1 GetEnv()

```
std::string GetEnv (
    const std::string & name )
```

Definition at line 39 of file [sound4.impact.cl-pipe-cxx.cpp](#).

11.1.1.2 main()

```
int main (
    int argc,
    const char ** argv )
```

[Setup and sanity checks]

[Setup and sanity checks]

[Create the processing instance]

[Create the processing instance]

[Communicating with the instance]

[Communicating with the instance]

Definition at line 104 of file [sound4.impact.cl-pipe-cxx.cpp](#).

11.1.1.3 MyLogger()

```
void MyLogger (
    sound4::impact::LogSeverity severity,
    const std::string & msg )
```

Definition at line 99 of file [sound4.impact.cl-pipe-cxx.cpp](#).

11.1.1.4 ProcessLoop()

```
void ProcessLoop (
    sound4::impact::CInstance & instance )
```

[Processing Loop]

[Processing Loop]

Definition at line 48 of file [sound4.impact.cl-pipe-cxx.cpp](#).

11.1.1.5 Usage()

```
void Usage (
    const char * progname )
```

Definition at line 79 of file [sound4.impact.cl-pipe-cxx.cpp](#).

11.2 sound4.impact.cl-pipe-cxx.cpp

```

00001
00004 #include <unistd.h>
00005 #include <iostream>
00006 #include <strings.h>
00007 #include <sys/types.h>
00008 #include <filesystem>
00009 #if defined(_WIN32) || defined(WIN32)
00010     #include <io.h>
00011     #include <fcntl.h>
00012 #endif
00013
00014 #include "sound4.impact.cl.hpp"
00015
00016 // -----
00039 std::string GetEnv(const std::string& name)
00040 {
00041     char *data=getenv(name.c_str());
00042     if (!data) return {};
00043     return std::string(data);
00044 }
00045
00046
00047 // Reads from stdin, write to stdout
00048 void ProcessLoop(sound4::impact::CInstance &instance)
00049 {
00050     bool stopthread=false;
00051
00052     #if defined(_WIN32) || defined(WIN32)
00053         // Windows: The stdin, stdout, and stderr streams always open in text mode by default
00054         _setmode(_fileno(stdin), _O_BINARY);
00055         _setmode(_fileno(stdout), _O_BINARY);
00056     #endif
00057
00058     while (!stopthread)
00059     {
00060         // Read a chunk from stdin
00061         if (stdin) {
00062             std::fread(instance.GetBufferIn().data(), sizeof(float), sound4::impact::InputSampleSize,
00063             stdin) != sound4::impact::InputSampleSize) {
00064                 std::cerr << "ProcessLoop: input stopped" << std::endl;
00065                 stopthread=true;
00066                 break;
00067             }
00068             if (stopthread) break;
00069             // Process it
00070             instance.ProcessAudio();
00071             // Write it to stdout
00072             if (fwrite(instance.GetBufferOut().data(), sizeof(float), sound4::impact::OutputSampleSize,
00073             stdout) != sound4::impact::OutputSampleSize) {
00074                 std::cerr << "Failed to write audio output" << std::endl;
00075                 stopthread=true;
00076             }
00077         }
00078     }
00079
00079 void Usage(const char *progname)
00080 {
00081     std::cerr << "Usage: " << progname << std::endl;;
00082     std::cerr << "  Reads audio from stdin and return processed audio in stdout" << std::endl;
00083     std::cerr << "Environment:" << std::endl;;
00084     std::cerr << "  - S4STORE_PATH          : path to store config [default: (no storage)]" <<
00085     std::endl;;
00086     std::cerr << "  - S4LOGINKEY           : SOUND4 Login key (or S4USERID)" << std::endl;;
00087     std::cerr << "  - RADIO_NAME          : SOUND4 Radio Name" << std::endl;;
00088     std::cerr << "  - S4_AWS_ACCESS_KEY_ID : SOUND4 Access Key ID" << std::endl;;
00089     std::cerr << "  - S4_AWS_SECRET_ACCESS_KEY: SOUND4 Access Key Secret" << std::endl;;
00090     std::cerr << std::endl;
00091     std::cerr << "Example:" << std::endl;
00092     std::cerr << "ffmpeg -re -i file.wav -ar " << sound4::impact::GetSampleRate() << " -ac "
00093     << "sound4::impact::GetChannelCount() << " -f f32le - | " << progname << " | ffplay -f f32le -ar "
00094     << "sound4::impact::GetSampleRate() << " -ac " << "sound4::impact::GetChannelCount() << " -i -" << std::endl;;
00095     #if defined(_WIN32) || defined(WIN32)
00096     std::cerr << "ffmpeg -f dshow -i audio=\\\"Microphone\\\" -ar " << sound4::impact::GetSampleRate() << " -ac "
00097     << "sound4::impact::GetChannelCount() << " -f f32le - | " << progname << " | ffplay -f f32le -ar "
00098     << "sound4::impact::GetSampleRate() << " -ac " << "sound4::impact::GetChannelCount() << " -i -" << std::endl;;
00099     #else
00100     std::cerr << "ffmpeg -f pulse -i default -ar " << sound4::impact::GetSampleRate() << " -ac "
00101     << "sound4::impact::GetChannelCount() << " -f f32le - | " << progname << " | ffplay -f f32le -ar "
00102     << "sound4::impact::GetSampleRate() << " -ac " << "sound4::impact::GetChannelCount() << " -i -" << std::endl;;
00103     #endif
00104 }
00105
00106 void MyLogger(sound4::impact::LogSeverity severity, const std::string& msg)
00107 {
00108     std::cerr << msg << std::endl;
00109 }
00110
00111

```

```

00103
00104 int main(int argc, const char **argv)
00105 {
00106     #if (IMPACT_HAS_WEBSERVER)
00107         int listen_port = 8080;
00108     #endif // (IMPACT_HAS_WEBSERVER)
00109     auto store_path_str=GetEnv("S4STORE_PATH");
00110
00111     // Get credentials from environment
00112     auto LoginKey=GetEnv("S4LOGINKEY");
00113     if (LoginKey.empty()) {
00114         LoginKey=GetEnv("S4USERID");
00115     }
00116     auto RadioName=GetEnv("RADIO_NAME");
00117     auto KeyId=GetEnv("S4_AWS_ACCESS_KEY_ID");
00118     auto AccessKey=GetEnv("S4_AWS_SECRET_ACCESS_KEY");
00119
00120     const char *programe=argv[0];
00121
00122     if (argc>1) {
00123         if ((strcasecmp(argv[1],"-h")==0) || (strcasecmp(argv[1],"--help")==0)) {
00124             Usage(programe);
00125             return 0;
00126         }
00127     }
00128     if (LoginKey.empty() || RadioName.empty() || KeyId.empty() || AccessKey.empty()) {
00129         std::cerr << "Missing credentials in environment" << std::endl;
00130         Usage(programe);
00131         return 1;
00132     }
00133     std::filesystem::path store_path;
00134     if (!store_path_str.empty()) {
00135         store_path = std::filesystem::path(store_path_str);
00136         if (!std::filesystem::exists(store_path) || !std::filesystem::is_directory(store_path)) {
00137             std::cerr << "Storage folder '" << store_path.c_str() << "' is not a valid directory" <<
std::endl;
00138             Usage(programe);
00139             return 1;
00140         }
00141     }
00142
00143     sound4::impact::SetLogSeverity(verbose5);
00144     sound4::impact::SetLoggerCallback(MyLogger);
00145
00146     sound4::impact::CInstance instance;
00147     instance.SetParam("ADMIN_USER","admin");
00148     instance.SetParam("ADMIN_SECRET","admin");
00149
00150     std::cerr << "Creating" << std::endl;
00151     if (!instance.Create(LoginKey, RadioName, KeyId, AccessKey, store_path)) {
00152         std::cerr << "Failed to create the processing instance" << std::endl;
00153         return 1;
00154     }
00155
00156     #if (IMPACT_HAS_WEBSERVER)
00157         std::cerr << "Starting web server" << std::endl;
00158         if (!instance.StartWebServer(listen_port,0)) {
00159             std::cerr << "Failed to create the web server on port " << listen_port << std::endl;
00160             return 1;
00161         }
00162     #endif // (IMPACT_HAS_WEBSERVER)
00163
00164     {
00165         auto client = instance.NewClient();
00166         auto answer = client->ProcessJson(R"JSON({{"get":{"processorname":null}}JSON");
00167         std::cerr << "Request for processor name returned " << answer << std::endl;
00168     }
00169
00170     ProcessLoop(instance);
00171
00172     std::cerr << "Stopping now" << std::endl;
00173     instance.Stop();
00174
00175     std::cerr << "End" << std::endl;
00176     return 0;
00177 }

```

11.3 sound4.impact.cl-pipe-dyn.cpp File Reference

C++ sample using C++ interface wrapper with dynamic library loading.

```
#include <unistd.h>
#include <iostream>
#include <strings.h>
#include <sys/types.h>
#include <filesystem>
#include <fstream>
#include <sstream>
#include <io.h>
#include <fcntl.h>
#include "sound4.impact.cl_dyn.hpp"
```

Classes

- class [MyPresetManager](#)
[Custom preset manager]

Functions

- std::string [GetEnv](#) (const std::string &name)
- void [ProcessLoop](#) ([sound4::impact::dyn::CInstance](#) &instance)
- void [Usage](#) (const char *progname, [sound4::impact::dyn::CDynLib](#) &dynlib)
- void [MyLogger](#) ([sound4::impact::dyn::LogSeverity](#) severity, const std::string &msg)
- int [main](#) (int argc, const char **argv)
[Custom preset manager]

11.3.1 Function Documentation

11.3.1.1 GetEnv()

```
std::string GetEnv (
    const std::string & name )
```

Definition at line 51 of file [sound4.impact.cl-pipe-dyn.cpp](#).

11.3.1.2 main()

```
int main (
    int argc,
    const char ** argv )
```

[Dynamic loading]

[Dynamic loading]

[Setup and sanity checks]

[Setup and sanity checks]

[Custom preset manager loading]

[Custom preset manager loading]

[Create the processing instance]

[Create the processing instance]

[Communicating with the instance]

[Communicating with the instance]

Definition at line 194 of file [sound4.impact.cl-pipe-dyn.cpp](#).

11.3.1.3 MyLogger()

```
void MyLogger (
    sound4::impact::dyn::LogSeverity severity,
    const std::string & msg )
```

Definition at line 113 of file [sound4.impact.cl-pipe-dyn.cpp](#).

11.3.1.4 ProcessLoop()

```
void ProcessLoop (
    sound4::impact::dyn::CInstance & instance )
```

[Processing Loop]

[Processing Loop]

Definition at line 60 of file [sound4.impact.cl-pipe-dyn.cpp](#).

11.3.1.5 Usage()

```
void Usage (
    const char * progname,
    sound4::impact::dyn::CDynLib & dynlib )
```

Definition at line 91 of file [sound4.impact.cl-pipe-dyn.cpp](#).

11.4 sound4.impact.cl-pipe-dyn.cpp

```
00001
00004 #include <unistd.h>
00005 #include <iostream>
00006 #include <strings.h>
00007 #include <sys/types.h>
00008 #include <filesystem>
00009 #include <fstream>
00010 #include <sstream>
00011 #if defined(_WIN32) || defined(WIN32)
00012     #include <io.h>
00013     #include <fcntl.h>
00014 #endif
00015
00016 #include "sound4.impact.cl_dyn.hpp"
00017
00018 // -----
00051 std::string GetEnv(const std::string& name)
00052 {
00053     char *data=getenv(name.c_str());
00054     if (!data) return {};
00055     return std::string(data);
00056 }
00057
00058
00059 // Reads from stdin, write to stdout
00060 void ProcessLoop(sound4::impact::dyn::CInstance &instance)
00061 {
00062     bool stopthread=false;
00063
00064     #if defined(_WIN32) || defined(WIN32)
00065         // Windows: The stdin, stdout, and stderr streams always open in text mode by default
00066         _setmode(_fileno(stdin), _O_BINARY);
00067         _setmode(_fileno(stdout), _O_BINARY);
00068     #endif
00069
00071     while (!stopthread)
00072     {
00073         // Read a chunk from stdin
00074         if (std::fread(instance.GetBufferIn().data(), sizeof(float),
00075             sound4::impact::dyn::InputSampleSize, stdin) != sound4::impact::dyn::InputSampleSize) {
00076             std::cerr << "ProcessLoop: input stopped" << std::endl;
00077             stopthread=true;
00078             break;
00079         }
00080         // Process it
00081         instance.ProcessAudio();
00082         // Write it to stdout
00083         if (fwrite(instance.GetBufferOut().data(), sizeof(float),
00084             sound4::impact::dyn::OutputSampleSize, stdout) != sound4::impact::dyn::OutputSampleSize) {
00085             std::cerr << "Failed to write audio output" << std::endl;
00086             stopthread=true;
00087         }
00088     }
00089 }
00090
00091 void Usage(const char *progname, sound4::impact::dyn::CDynLib &dynlib)
00092 {
00093     std::cerr << "Usage: " << progname << std::endl;;
00094     std::cerr << "  Reads audio from stdin and return processed audio in stdout" << std::endl;;
00095     std::cerr << "Environment:" << std::endl;;
00096     std::cerr << "  - S4STORE_PATH           : path to store config [default: (no storage)]" <<
00097         std::endl;;
00098     std::cerr << "  - S4LOGINKEY           : SOUND4 Login key (or S4USERID)" << std::endl;;
00099     std::cerr << "  - RADIO_NAME          : SOUND4 Radio Name" << std::endl;;
00100     std::cerr << "  - S4_AWS_ACCESS_KEY_ID : SOUND4 Access Key ID" << std::endl;;
00101     std::cerr << "  - S4_AWS_SECRET_ACCESS_KEY: SOUND4 Access Key Secret" << std::endl;;
00102     if (dynlib.IsOk()) {
00103         std::cerr << std::endl;
```

```

00103         std::cerr << "Example:" << std::endl;
00104         std::cerr << "ffmpeg -re -i file.wav -ar "<<dynlib.GetSampleRate()<<" -ac
" <<dynlib.GetChannelCount()<<" -f f32le - | "<<progrname<<" | ffplay -f f32le -ar
" <<dynlib.GetSampleRate()<<" -ac "<<dynlib.GetChannelCount()<<" -i -" << std::endl;;
00105         #if defined(_WIN32) || defined(WIN32)
00106         std::cerr << "ffmpeg -f dshow -i audio=\"Microphone\" -ar "<<dynlib.GetSampleRate()<<" -ac
" <<dynlib.GetChannelCount()<<" -f f32le - | "<<progrname<<" | ffplay -f f32le -ar
" <<dynlib.GetSampleRate()<<" -ac "<<dynlib.GetChannelCount()<<" -i -" << std::endl;;
00107         #else
00108         std::cerr << "ffmpeg -f pulse -i default -ar "<<dynlib.GetSampleRate()<<" -ac
" <<dynlib.GetChannelCount()<<" -f f32le - | "<<progrname<<" | ffplay -f f32le -ar
" <<dynlib.GetSampleRate()<<" -ac "<<dynlib.GetChannelCount()<<" -i -" << std::endl;;
00109         #endif
00110     }
00111 }
00112
00113 void MyLogger(sound4::impact::dyn::LogSeverity severity, const std::string& msg)
00114 {
00115     std::cerr << msg << std::endl;
00116 }
00117
00119 class MyPresetManager : public sound4::impact::dyn::CPresetLoader {
00120 public:
00121     MyPresetManager() = default;
00122     virtual ~MyPresetManager() = default;
00123
00124     bool SetupPath(const std::filesystem::path& a_preset_path)
00125     {
00126         m_preset_path=a_preset_path;
00127         if ( !std::filesystem::exists(m_preset_path) ) {
00128             return false;
00129         }
00130         std::error_code ec;
00131         if ( !std::filesystem::is_directory(m_preset_path, ec) ) {
00132             return false;
00133         }
00134         return true;
00135     }
00136     virtual bool IsReadOnly() override { return false; };
00137     virtual bool Exists(const std::filesystem::path &name) override
00138     {
00139         std::error_code ec;
00140         return std::filesystem::exists(GetRealPath(name), ec);
00141     }
00142     virtual bool Remove(const std::filesystem::path &name) override
00143     {
00144         std::error_code ec;
00145         return std::filesystem::remove(GetRealPath(name), ec);
00146     }
00147     virtual bool Rename(const std::filesystem::path &from, const std::filesystem::path &to) override
00148     {
00149         std::error_code ec;
00150         std::filesystem::rename(GetRealPath(from), GetRealPath(to), ec);
00151         return (!ec);
00152     }
00153     virtual std::vector<std::filesystem::path> GetAll() override
00154     {
00155         std::vector<std::filesystem::path> list;
00156         for (const auto & entry : std::filesystem::directory_iterator(m_preset_path.c_str(),
std::filesystem::directory_options::skip_permission_denied)) {
00157             if (entry.is_regular_file()) {
00158                 list.push_back(std::filesystem::relative(entry.path(), m_preset_path).native());
00159             }
00160         }
00161         return list;
00162     }
00163     virtual std::string Read(const std::filesystem::path &filename) override
00164     {
00165         std::ifstream f(GetRealPath(filename));
00166         if ( f.fail() ) {
00167             return std::string();
00168         }
00169         std::ostringstream ss;
00170         ss << f.rdbuf();
00171         return ss.str();
00172     }
00173     virtual bool Write(const std::filesystem::path &filename, const std::string &content) override
00174     {
00175         std::ofstream f(GetRealPath(filename));
00176         if ( f.fail() ) {
00177             return false;
00178         }
00179         f << content;
00180         if ( f.fail() ) {
00181             return false;
00182         }
00183         return true;

```

```

00184     }
00185 private:
00186     std::filesystem::path m_preset_path;
00187     std::filesystem::path GetRealPath(const std::filesystem::path &name)
00188     {
00189         return m_preset_path / name;
00190     }
00191 };
00192
00193
00194 int main(int argc, const char **argv)
00195 {
00196     #if (IMPACT_HAS_WEBSERVER)
00197         int listen_port = 8080;
00198     #endif // (IMPACT_HAS_WEBSERVER)
00199     auto store_path_str=GetEnv("S4STORE_PATH");
00200
00201     // Get credentials from environment
00202     auto LoginKey=GetEnv("S4LOGINKEY");
00203     if (LoginKey.empty()) {
00204         LoginKey=GetEnv("S4USERID");
00205     }
00206     auto RadioName=GetEnv("RADIO_NAME");
00207     auto KeyId=GetEnv("S4_AWS_ACCESS_KEY_ID");
00208     auto AccessKey=GetEnv("S4_AWS_SECRET_ACCESS_KEY");
00209
00210     const char *programe=argv[0];
00211
00212
00213     sound4::impact::dyn::CDynLib dynlib;
00214     if (!dynlib.Load()) {
00215         std::cerr << "Failed to load processing library" << std::endl;
00216         return 1;
00217     }
00218
00219     if (argc>1) {
00220         if ((strcmp(argv[1],"-h")==0) || (strcmp(argv[1],"--help")==0)) {
00221             Usage(programe, dynlib);
00222             return 0;
00223         }
00224     }
00225
00226     if (LoginKey.empty() || RadioName.empty() || KeyId.empty() || AccessKey.empty()) {
00227         std::cerr << "Missing credentials in environment" << std::endl;
00228         Usage(programe, dynlib);
00229         return 1;
00230     }
00231
00232     std::filesystem::path store_path;
00233     if (!store_path_str.empty()) {
00234         store_path = std::filesystem::path(store_path_str);
00235         if (!std::filesystem::exists(store_path) || !std::filesystem::is_directory(store_path)) {
00236             std::cerr << "Storage folder '" << store_path.c_str() << "' is not a valid directory" <<
00237             std::endl;
00238             Usage(programe, dynlib);
00239             return 1;
00240         }
00241     }
00242
00243     sound4::impact::dyn::SetLogSeverity(dynlib, verbose5);
00244     sound4::impact::dyn::SetLoggerCallback(dynlib, MyLogger);
00245
00246     sound4::impact::dyn::CInstance instance(dynlib);
00247     instance.SetParam("ADMIN_USER", "admin");
00248     instance.SetParam("ADMIN_SECRET", "admin");
00249
00250     MyPresetManager preset_manager;
00251     if (!store_path.empty()) {
00252         if (!preset_manager.SetupPath(store_path)) {
00253             std::cerr << "Failed to setup the custom preset manager on path " << store_path.c_str() <<
00254             std::endl;
00255             return 1;
00256         }
00257     }
00258     instance.SetPresetManager(&preset_manager);
00259
00260
00261     std::cerr << "Creating" << std::endl;
00262     if (!instance.Create(LoginKey, RadioName, KeyId, AccessKey, {})) {
00263         std::cerr << "Failed to create the processing instance" << std::endl;
00264         return 1;
00265     }
00266
00267
00268     #if (IMPACT_HAS_WEBSERVER)
00269     std::cerr << "Starting web server" << std::endl;
00270     if (!instance.StartWebServer(listen_port, 0)) {
00271         std::cerr << "Failed to create the web server on port " << listen_port << std::endl;
00272         return 1;
00273     }
00274     #endif // (IMPACT_HAS_WEBSERVER)
00275
00276
00277

```

```

00280     {
00282         auto client = instance.NewClient();
00283         auto answer = client->ProcessJson(R"JSON({\"get\":{\"processorname\":null}})JSON");
00284         std::cerr << "Request for processor name returned " << answer << std::endl;
00286     }
00287
00288     ProcessLoop(instance);
00289
00290     std::cerr << "Stopping now" << std::endl;
00291     instance.Stop();
00292
00293     std::cerr << "End" << std::endl;
00294     return 0;
00295 }

```

11.5 sound4.impact.cl-pipe.cpp File Reference

C++ sample using only C interface.

```

#include <unistd.h>
#include <iostream>
#include <strings.h>
#include <sys/types.h>
#include <thread>
#include <experimental/filesystem>
#include <io.h>
#include <fcntl.h>
#include <stringapiset.h>
#include <sound4.impact.cl.h>

```

Namespaces

- [std](#)

Macros

- #define [SAMPLE_RATE](#) 48000
- #define [CHUNK_SIZE](#) 64
- #define [CHANNEL_COUNT](#) 2

Functions

- void [ProcessLoop](#) (struct [impact_CInstance](#) *pInstance)
- void [Usage](#) (const char *programe)
- void [MyLogger](#) ([impact_LogSeverity](#) severe[[maybe_unused]], const char *str)
- int [main](#) (int argc, char *const argv[])

11.5.1 Macro Definition Documentation

11.5.1.1 CHANNEL_COUNT

```
#define CHANNEL_COUNT 2
```

Definition at line 28 of file [sound4.impact.cl-pipe.cpp](#).

11.5.1.2 CHUNK_SIZE

```
#define CHUNK_SIZE 64
```

Definition at line 27 of file [sound4.impact.cl-pipe.cpp](#).

11.5.1.3 SAMPLE_RATE

```
#define SAMPLE_RATE 48000
```

Definition at line 26 of file [sound4.impact.cl-pipe.cpp](#).

11.5.2 Function Documentation

11.5.2.1 main()

```
int main (  
    int argc,  
    char *const argv[] )
```

[Setup and sanity checks]

[Setup and sanity checks]

[Create the processing instance]

[Create the processing instance]

[Stopping the processing instance]

[Stopping the processing instance]

Definition at line 90 of file [sound4.impact.cl-pipe.cpp](#).

11.5.2.2 MyLogger()

```
void MyLogger (
    impact_LogSeverity severe] [[maybe_unused],
    const char * str )
```

Definition at line 84 of file [sound4.impact.cl-pipe.cpp](#).

11.5.2.3 ProcessLoop()

```
void ProcessLoop (
    struct impact_CInstance * pInstance )
```

[Processing Loop]

[Processing Loop]

Definition at line 31 of file [sound4.impact.cl-pipe.cpp](#).

11.5.2.4 Usage()

```
void Usage (
    const char * progname )
```

Definition at line 64 of file [sound4.impact.cl-pipe.cpp](#).

11.6 sound4.impact.cl-pipe.cpp

```
00001
00004 #include <unistd.h>
00005 #include <iostream>
00006 #include <strings.h>
00007 #include <sys/types.h>
00008 #include <thread>           // NOTE: needs pthread link
00009 // Choose good filesystem version depending on compiler.
00010 #if __has_include(<filesystem>)
00011     #include <filesystem>
00012 #else //if __cpp_lib_experimental_filesystem
00013     // We need the alias from std::experimental::filesystem to std::filesystem
00014     #include <experimental/filesystem>
00015     namespace std {
00016         namespace filesystem = experimental::filesystem;
00017     }
00018 #endif
00019 #if defined(_WIN32) || defined(WIN32)
00020     #include <io.h>
00021     #include <fcntl.h>
00022     #include <stringapiset.h> // UTF-8 conversion
00023 #endif
00024 #include <sound4.impact.cl.h>
00025
00026 #define SAMPLE_RATE      48000
00027 #define CHUNK_SIZE       64
00028 #define CHANNEL_COUNT    2
00029
00030 // Reads from stdin, write to stdout
00031 void ProcessLoop(struct impact_CInstance *pInstance)
00032 {
00034     bool stopthread=false;
```

```

00035 alignas(64) float audio_in[CHUNK_SIZE*CHANNEL_COUNT];
00036 alignas(64) float audio_out[CHUNK_SIZE*CHANNEL_COUNT];
00037
00038 #if defined(_WIN32) || defined(WIN32)
00039     // Windows: The stdin, stdout, and stderr streams always open in text mode by default
00040     _setmode(_fileno(stdin), _O_BINARY);
00041     _setmode(_fileno(stdout), _O_BINARY);
00042 #endif
00043
00044 while (!stopthread)
00045 {
00046     // Read a chunk from stdin
00047     if (std::fread(&audio_in[0], sizeof(float), CHUNK_SIZE*CHANNEL_COUNT, stdin) !=
CHUNK_SIZE*CHANNEL_COUNT) {
00048         std::cerr << "ProcessLoop: input stopped" << std::endl;
00049         stopthread=true;
00050         break;
00051     }
00052     if (stopthread) break;
00053     // Process it
00054     impact_ProcessAudio(pInstance, audio_in, audio_out);
00055     // Write it to stdout
00056     if (fwrite(&audio_out[0], sizeof(float), CHUNK_SIZE*CHANNEL_COUNT, stdout) !=
CHUNK_SIZE*CHANNEL_COUNT) {
00057         std::cerr << "Failed to write audio output" << std::endl;
00058         stopthread=true;
00059     }
00060 }
00062 }
00063
00064 void Usage(const char *programe)
00065 {
00066     std::cerr << "Usage: " << programe << std::endl;;
00067     std::cerr << "  Reads audio from stdin and return processed audio in stdout" << std::endl;
00068     std::cerr << "Environment:" << std::endl;;
00069     std::cerr << "  - S4STORE_PATH           : path to store config [default: ./state]" << std::endl;;
00070     std::cerr << "  - S4LOGINKEY           : SOUND4 Login key (or S4USERID)" << std::endl;;
00071     std::cerr << "  - RADIO_NAME          : SOUND4 Radio Name" << std::endl;;
00072     std::cerr << "  - S4_AWS_ACCESS_KEY_ID : SOUND4 Access Key ID" << std::endl;;
00073     std::cerr << "  - S4_AWS_SECRET_ACCESS_KEY: SOUND4 Access Key Secret" << std::endl;;
00074     std::cerr << std::endl;
00075     std::cerr << "Example:" << std::endl;
00076     std::cerr << "ffmpeg -re -i file.wav -ar "<<SAMPLE_RATE<<" -ac "<<CHANNEL_COUNT<<" -f f32le - |
" <<programe<<" | ffplay -f f32le -ar "<<SAMPLE_RATE<<" -ac "<<CHANNEL_COUNT<<" -i -" << std::endl;;
00077     #if defined(_WIN32) || defined(WIN32)
00078     std::cerr << "ffmpeg -f dshow -i audio=\\\"Microphone\\\" -ar "<<SAMPLE_RATE<<" -ac "<<CHANNEL_COUNT<<"
-f f32le - | "<<programe<<" | ffplay -f f32le -ar "<<SAMPLE_RATE<<" -ac "<<CHANNEL_COUNT<<" -i -" <<
std::endl;;
00079     #else
00080     std::cerr << "ffmpeg -f pulse -i default -ar "<<SAMPLE_RATE<<" -ac "<<CHANNEL_COUNT<<" -f f32le - |
" <<programe<<" | ffplay -f f32le -ar "<<SAMPLE_RATE<<" -ac "<<CHANNEL_COUNT<<" -i -" << std::endl;;
00081     #endif
00082 }
00083
00084 void MyLogger(impact_LogSeverity severe [[maybe_unused]], const char *str)
00085 {
00086     std::cerr << str << std::endl;
00087 }
00088
00089
00090 int main(int argc, char *const argv[])
00091 {
00092     struct impact_CInstance *pInstance = NULL;
00093     const char *store_path_str=getenv("S4STORE_PATH");
00094     // Get credentials from environment
00095     char *pLoginKey=getenv("S4LOGINKEY");
00096     if (!pLoginKey) {
00097         pLoginKey=getenv("S4USERID");
00098     }
00099     char *pRadioName=getenv("RADIO_NAME");
00100     char *pKeyId=getenv("S4_AWS_ACCESS_KEY_ID");
00101     char *pAccessKey=getenv("S4_AWS_SECRET_ACCESS_KEY");
00102
00103     const char *programe=argv[0];
00104
00105     if (argc>1) {
00106         if ((strcmp(argv[1], "-h")==0) || (strcmp(argv[1], "--help")==0)) {
00107             Usage(programe);
00108             return 0;
00109         }
00110     }
00111     if (!pLoginKey || !pRadioName || !pKeyId || !pAccessKey) {
00112         std::cerr << "Missing credentials in environment" << std::endl;
00113         Usage(programe);
00114         return 1;
00115     }
00116     std::filesystem::path fs_store_path;

```

```

00117     if (!store_path_str || store_path_str[0]==0) {
00118         fs_store_path=std::filesystem::current_path() / "state";
00119     } else {
00120         fs_store_path = std::filesystem::path(store_path_str);
00121     }
00122     if (!std::filesystem::exists(fs_store_path) || !std::filesystem::is_directory(fs_store_path)) {
00123         std::cerr << "Storage folder '"<fs_store_path.c_str()<"' is not a valid directory" << std::endl;
00124         Usage(progname);
00125         return 1;
00126     }
00127     std::string store_path;
00128     #ifdef _WIN32
00129     {
00130         // Convert path to UTF-8
00131         std::wstring wstr(fs_store_path.wstring());
00132         if (wstr.empty()) return {};
00133         int size = WideCharToMultiByte(CP_UTF8, 0, &wstr[0], (int)wstr.size(), NULL, 0, NULL, NULL);
00134         std::string str(size, 0);
00135         WideCharToMultiByte(CP_UTF8, 0, &wstr[0], (int)wstr.size(), &str[0], size, NULL, NULL);
00136         store_path=str;
00137     }
00138     #else // !_WIN32
00139         store_path=fs_store_path;
00140     #endif // !_WIN32
00141
00142     // Optional: Use our own logging, instead of default color output to stderr.
00143     //impact_SetLoggerCallback(&MyLogger);
00144
00145     //impact_SetLogSeverity(impact_LogSeverity::info);
00146     impact_SetLogSeverity(impact_LogSeverity::verbose5);
00147
00148     std::cerr << "Process version: " << impact_GetVersion() << std::endl;
00149     // Do some sanity checks
00150     if (impact_GetSampleRate()!=SAMPLE_RATE) {
00151         std::cerr << "Bad library sampling rate, expecting '"<SAMPLE_RATE<"' but has "<
00152     impact_GetSampleRate() << std::endl;
00153         return 1;
00154     }
00155     if (impact_GetChunkSizeInFrames()!=CHUNK_SIZE) {
00156         std::cerr << "Bad library frame size, expecting '"<CHUNK_SIZE<"' but has "<
00157     impact_GetChunkSizeInFrames() << std::endl;
00158         return 1;
00159     }
00160     if (impact_GetChannelCount()!=CHANNEL_COUNT) {
00161         std::cerr << "Bad library channel count, expecting '"<CHANNEL_COUNT<"' but has "<
00162     impact_GetChannelCount() << std::endl;
00163         return 1;
00164     }
00165
00166     // Setup parameters
00167     struct impact_CParameters *params = impact_NewParameters();
00168     // Optional: activate web authentication, set admin password
00169     // This creates the authentication only for a new storage path
00170     impact_SetParameter(params,"ADMIN_USER", "admin");
00171     impact_SetParameter(params,"ADMIN_SECRET", "admin");
00172
00173     // Create the processing instance
00174     pInstance=impact_InitProcess2(pLoginKey,pRadioName,pKeyId,pAccessKey,store_path.c_str(), params);
00175     impact_FreeParameters(params);
00176     if (!pInstance) {
00177         std::cerr << "Failed to create the process instance"< std::endl;
00178         return 1;
00179     }
00180
00181     // Start the update thread, without JSON server (low priority)
00182     std::thread updater([pInstance](){
00183         // will returned when stopped or destroyed
00184         std::cerr << "impact_StartUpdateThread (no json port)" << std::endl;
00185         impact_StartUpdateThread(pInstance, 0);
00186         std::cerr << "impact_StartUpdateThread END" << std::endl;
00187     });
00188
00189     // This is not mandatory, but better be sure we are ready right now
00190     std::cerr << "Waiting update thread" << std::endl;
00191     if (impact_WaitUpdateThreadReady(pInstance, 5000)<0) {
00192         std::cerr << "Timeout to create the process instance"< std::endl;
00193     }
00194     std::cerr << "Waiting update thread DONE" << std::endl;
00195
00196     #if IMPACT_HAS_WEBSERVER
00197     // Starts a web server, listening on port http://localhost:8080, https://localhost:8443
00198     std::cerr << "Starting web server" << std::endl;
00199     int listenport= 8080;
00200     int listenport_secure= 8443;
00201     uint64_t webserver= SOUND4_INVALID_WEBSERVER_ID;
00202     if (listenport || listenport_secure) {
00203         webserver = impact_Webserver(listenport,listenport_secure,pInstance);
00204     }

```

```

00205         if (webserver==SOUND4_INVALID_WEBSERVER_ID) {
00206             std::cerr << "Starting web server FAILED" << std::endl;
00207         } else {
00208             int web_status=impact_Webserver_Status(webserver);
00209             if (listenport) {
00210                 if (web_status & SOUND4_WEBSERVER_HTTP_OK) {
00211                     std::cerr << "Web server listening on port " << listenport;
00212                 } else {
00213                     std::cerr << "Web server failed to listen on port " << listenport;
00214                 }
00215             }
00216             if (listenport_secure) {
00217                 if (web_status & SOUND4_WEBSERVER_HTTPS_OK) {
00218                     std::cerr << "Web server listening on secure port " << listenport_secure;
00219                 } else {
00220                     std::cerr << "Web server failed to listen on secure port " << listenport_secure;
00221                 }
00222             }
00223             std::cerr << "Starting web server DONE" << std::endl;
00224         }
00225     }
00227 #endif // (IMPACT_HAS_WEBSERVER)
00228
00229     // Force load a factory preset now
00230     // Could be used instead of setting a store_path
00231     /*{
00232         impact_CClientInstance *pClient=impact_NewClient(pInstance);
00233         const char *answer=impact_ProcessJson(pClient, "{ \"factoryload\": \"All Programs\" }",
00234         NULL);
00235         std::cerr << "Loaded factory preset answer: " << answer << std::endl;
00236         impact_FreeJsonAnswer(answer);
00237         impact_DeleteClient(pClient);
00238     }*/
00239
00240     std::cerr << "Estimated delay " << ( impact_GetEstimatedDelay(pInstance)*1000.0/SAMPLE_RATE ) << "
ms" << std::endl;
00241
00242     ProcessLoop(pInstance);
00243
00245 #if (IMPACT_HAS_WEBSERVER)
00246     // Stopping the webserver
00247     std::cerr << "Stopping web server" << std::endl;
00248     impact_Webserver_Stop(webserver, 1000);
00249     std::cerr << "Stopping web server DONE" << std::endl;
00250 #endif // (IMPACT_HAS_WEBSERVER)
00251
00252     // Stopping the processing instance
00253     std::cerr << "Stopping Update thread" << std::endl;
00254     impact_StopUpdateThread(pInstance); // this will exit the update thread
00255     std::cerr << "Stopping Update thread DONE" << std::endl;
00256
00257     updater.join();
00258
00259     impact_ExitProcess(pInstance);
00260
00261     return 0;
00262 }
00263 }

```

11.7 sound4.impact.cl.h File Reference

C interface for library.

```
#include <stdint.h>
```

Macros

- #define [IMPACT_DECL __declspec\(dllimport\)](#)
- #define [IMPACT_HAS_WEBSERVER](#) 1
- #define [IMPACT_HAS_CLOUDBUS](#) 0
- #define [IMPACT_AUDIOFRAME_COUNT](#) 64
- #define [IMPACT_CHANNEL_COUNT](#) 2
- #define [IMPACT_AUDIO_INPUT_COUNT](#) 1

- `#define IMPACT_AUDIO_OUTPUT_COUNT 1`
- `#define IMPACT_SAMPLE_RATE 48000`
- `#define SOUND4_INVALID_WEBSERVER_ID ((uint64_t)-1)`
- `#define SOUND4_WEBSERVER_HTTP_OK (1<<0)`
- `#define SOUND4_WEBSERVER_HTTPS_OK (1<<1)`

Typedefs

- `typedef void(* impact_loggerfn) (enum impact_LogSeverity, const char *)`
- `typedef wchar_t fs_char`
- `typedef char *(* impact_storage_reader) (const fs_char *filename, void *userdata)`
- `typedef void(* impact_storage_reader_free) (char *content, void *userdata)`
- `typedef int(* impact_storage_writer) (const fs_char *filename, const char *content, void *userdata)`
- `typedef int(* impact_storage_exists) (const fs_char *filename, void *userdata)`
- `typedef fs_char *(* impact_storage_getall) (void *userdata)`
- `typedef void(* impact_storage_getall_free) (fs_char **all, void *userdata)`
- `typedef int(* impact_storage_remove) (const fs_char *filename, void *userdata)`
- `typedef int(* impact_storage_rename) (const fs_char *from, const fs_char *to, void *userdata)`

Enumerations

- `enum impact_LogSeverity {
none = 0 , fatal = 1 , error = 2 , warning = 3 ,
info = 4 , verbose = 5 , verbose2 = 6 , verbose3 = 7 ,
verbose4 = 8 , verbose5 = 9 }`
- `enum impact_PresetChange_Kind { change_kind_created = 1 , change_kind_modified , change_kind_deleted
}`
- `enum impact_SampleFormat {
INVALID_FORMAT =0 , S16_LE , S16_BE , S24_LE ,
S24_BE , S32_LE , S32_BE , F32_LE ,
F32_BE , S16_NATIVE =S16_LE , S24_NATIVE =S24_LE , S32_NATIVE =S32_LE ,
F32_NATIVE =F32_LE }`

Functions

- `const char * impact_GetVersion ()`
- `unsigned int impact_GetChunkSizeInFrames ()`
- `unsigned int * impact_GetPossibleChunkSizeInFrames ()`
- `unsigned int impact_GetChannelCount ()`
- `unsigned int impact_GetAudioInputCount ()`
- `unsigned int impact_GetAudioOutputCount ()`
- `unsigned int impact_GetSampleRate ()`
- `void impact_SetLoggerCallback (impact_loggerfn logger)`
- `void impact_SetLogSeverity (enum impact_LogSeverity severity)`
- `struct impact_CParameters * impact_NewParameters ()`
- `void impact_FreeParameters (struct impact_CParameters *params)`
- `void impact_SetParameter (struct impact_CParameters *params, const char *name, const char *value)`
- `const char * impact_GetParameter (struct impact_CParameters *params, const char *name)`
- `void impact_FreeParameterValue (const char *value)`
- `struct impact_CInstance * impact_InitProcess (const char *LoginKey, const char *RadioName, const char *AWS_Access_ID, const char *AWS_Access_Secret, const char *save_path)`

- struct [impact_CInstance](#) * [impact_InitProcess2](#) (const char *LoginKey, const char *RadioName, const char *AWS_Access_ID, const char *AWS_Access_Secret, const char *save_path, const struct [impact_CParameters](#) *parameters)
- struct [impact_CInstance](#) * [impact_InitProcess3](#) (const char *LoginKey, const char *RadioName, const char *AWS_Access_ID, const char *AWS_Access_Secret, const char *save_path, const struct [impact_CParameters](#) *parameters, unsigned int frames_per_chunk)
- unsigned int [impact_GetProcessChunkFrames](#) (struct [impact_CInstance](#) *instance)
- int [impact_TerminateProcess](#) (struct [impact_CInstance](#) *instance)
- void [impact_ExitProcess](#) (struct [impact_CInstance](#) *instance)
- void [impact_SetPresetManager](#) (struct [impact_CParameters](#) *params, [impact_storage_reader](#) reader, [impact_storage_reader_free](#), [impact_storage_writer](#) writer, [impact_storage_exists](#) exists, [impact_storage_getall](#) getall, [impact_storage_getall_free](#) getall_free, [impact_storage_remove](#) remove, [impact_storage_rename](#) rename, int IsReadOnly, void *userdata)
- void [impact_PresetManager_InformChange](#) (struct [impact_CInstance](#) *instance, const fs_char *relative_↵ path, enum [impact_PresetChange_Kind](#) change_kind)
- void [impact_SetMetadata](#) (struct [impact_CInstance](#) *instance, const char *key, const char *value)
- const char ** [impact_GetMetadataInfos](#) (struct [impact_CInstance](#) *instance)
- void [impact_FreeMetadataInfos](#) (struct [impact_CInstance](#) *instance, const char **infos)
- void [impact_StartUpdateThread](#) (struct [impact_CInstance](#) *instance, unsigned int port)
- void [impact_StopUpdateThread](#) (struct [impact_CInstance](#) *instance)
- int [impact_WaitUpdateThreadReady](#) (struct [impact_CInstance](#) *instance, int milliseconds)
- void [impact_ProcessAudio](#) (struct [impact_CInstance](#) *instance, const float *input, float *output)
- void [impact_ProcessAudio_Planar](#) (struct [impact_CInstance](#) *instance, float const *const *input, float *const *output)
- float * [impact_GetBufferIn](#) (struct [impact_CInstance](#) *instance)
- float * [impact_GetBufferOut](#) (struct [impact_CInstance](#) *instance)
- unsigned int [impact_GetEstimatedDelay](#) (struct [impact_CInstance](#) *instance)
- const char * [impact_GetFormatName](#) (const enum [impact_SampleFormat](#) fmt)
- enum [impact_SampleFormat](#) [impact_GetFormatFromName](#) (const char *name)
- unsigned int [impact_GetBytesFromFormat](#) (const enum [impact_SampleFormat](#) fmt)
- unsigned int [impact_GetMaxPacketFrame](#) (struct [impact_CInstance](#) *instance)
- unsigned int [impact_AddAudio](#) (struct [impact_CInstance](#) *instance, const uint8_t *payload, unsigned int n_↵ Frame, enum [impact_SampleFormat](#) fmt)
- unsigned int [impact_AddPadAudio](#) (struct [impact_CInstance](#) *instance)
- unsigned int [impact_GetOutputCount](#) (struct [impact_CInstance](#) *instance)
- unsigned int [impact_GetAudio](#) (struct [impact_CInstance](#) *instance, uint8_t *payload, unsigned int max_n_↵ Frame, enum [impact_SampleFormat](#) fmt)
- void [impact_AudioConvertFrom](#) (const uint8_t *payload, float *output, size_t nSpl, enum [impact_SampleFormat](#) fmt)
- void [impact_AudioConvertTo](#) (const float *input, uint8_t *payload, size_t nSpl, enum [impact_SampleFormat](#) fmt)
- void [impact_StereoToMono](#) (const float *input, float *output, size_t nFrame)
- void [impact_MonoToStereo](#) (const float *input, float *output, size_t nFrame)
- void [impact_StereoToMono_Planar](#) (const float *inputL, const float *inputR, float *output, size_t nFrame)
- void [impact_MonoToStereo_Planar](#) (const float *input, float *outputL, float *outputR, size_t nFrame)
- void [impact_AudioMonoFromLiveStereo](#) (const uint8_t *payload, float *output)
- void [impact_AudioMonoToLiveStereo](#) (const float *input, uint8_t *payload)
- struct [impact_CClientInstance](#) * [impact_NewClient](#) (struct [impact_CInstance](#) *instance)
- void [impact_DeleteClient](#) (struct [impact_CClientInstance](#) *client)
- const char * [impact_ProcessJson](#) (struct [impact_CClientInstance](#) *client, const char *json_str, int *need_↵ save)
- void [impact_FreeJsonAnswer](#) (const char *json_str)
- int [impact_SaveState](#) (struct [impact_CInstance](#) *instance)
- uint64_t [impact_Webserver_tcp](#) (unsigned int listenport, unsigned int listenport_secure, const char *socket_↵ _ip, unsigned int socket_port)

- uint64_t [impact_Webserver_tcp2](#) (unsigned int listenport, unsigned int listenport_secure, const char *socket_ip, unsigned int socket_port, const struct [impact_CParameters](#) *parameters)
- uint64_t [impact_Webserver](#) (unsigned int listenport, unsigned int listenport_secure, struct [impact_CInstance](#) *instance)
- int [impact_Webserver_Stop](#) (uint64_t id, int timeout_ms)
- int [impact_Webserver_Status](#) (uint64_t id)

11.7.1 Macro Definition Documentation

11.7.1.1 IMPACT_DECL

```
#define IMPACT_DECL __declspec(dllimport)
```

Definition at line 14 of file [sound4.impact.cl.h](#).

11.7.1.2 IMPACT_HAS_CLOUDBUS

```
#define IMPACT_HAS_CLOUDBUS 0
```

Definition at line 19 of file [sound4.impact.cl.h](#).

11.7.1.3 IMPACT_HAS_WEBSERVER

```
#define IMPACT_HAS_WEBSERVER 1
```

Definition at line 18 of file [sound4.impact.cl.h](#).

11.8 sound4.impact.cl.h

```
00001
00004 #pragma once
00005
00006 #include <stdint.h>
00007 #ifdef __unix__
00008     #include <sys/types.h>
00009     #define IMPACT_DECL __attribute__((visibility ("default")))
00010 #elif defined(_WIN32) || defined(WIN32)
00011     #ifdef BUILDING_IMPACT_DLL
00012         #define IMPACT_DECL __declspec(dllexport)
00013     #else
00014         #define IMPACT_DECL __declspec(dllimport)
00015     #endif
00016 #endif
00017
00018 #define IMPACT_HAS_WEBSERVER 1
00019 #define IMPACT_HAS_CLOUDBUS 0
00020
00021 #ifdef __cplusplus
00022 extern "C" {
00023 #endif // __cplusplus
00024
```

```

00068 // -----
00087 // -----
00140 // -----
00141
00142 // -----
00154 #define IMPACT_AUDIOFRAME_COUNT      64
00160 #define IMPACT_CHANNEL_COUNT          2
00166 #define IMPACT_AUDIO_INPUT_COUNT      1
00172 #define IMPACT_AUDIO_OUTPUT_COUNT     1
00178 #define IMPACT_SAMPLE_RATE            48000
00179
00185 IMPACT_DECL const char *impact_GetVersion();
00186
00199 IMPACT_DECL unsigned int impact_GetChunkSizeInFrames();
00200
00209 IMPACT_DECL unsigned int* impact_GetPossibleChunkSizeInFrames();
00210
00218 IMPACT_DECL unsigned int impact_GetChannelCount();
00219
00228 IMPACT_DECL unsigned int impact_GetAudioInputCount();
00229
00238 IMPACT_DECL unsigned int impact_GetAudioOutputCount();
00239
00247 IMPACT_DECL unsigned int impact_GetSampleRate();
00248
00252 enum impact_LogSeverity {
00253     none = 0,
00254     fatal = 1,
00255     error = 2,
00256     warning = 3,
00257     info = 4,
00258     verbose = 5,
00259     verbose2 = 6,
00260     verbose3 = 7,
00261     verbose4 = 8,
00262     verbose5 = 9,
00263 };
00264
00271 typedef void (*impact_loggerfn) (enum impact_LogSeverity, const char *);
00272
00282 IMPACT_DECL void impact_SetLoggerCallback( impact_loggerfn logger );
00283
00291 IMPACT_DECL void impact_SetLogSeverity( enum impact_LogSeverity severity );
00292
00295 // -----
00301 // -----
00305 struct impact_CInstance;
00306
00310 struct impact_CParameters;
00311
00319 IMPACT_DECL struct impact_CParameters *impact_NewParameters();
00320
00324 IMPACT_DECL void impact_FreeParameters(struct impact_CParameters *params);
00325
00337 IMPACT_DECL void impact_SetParameter(struct impact_CParameters *params, const char *name, const char
    *value);
00338
00344 IMPACT_DECL const char *impact_GetParameter(struct impact_CParameters *params, const char *name);
00345
00351 IMPACT_DECL void impact_FreeParameterValue(const char *value);
00352
00360 IMPACT_DECL struct impact_CInstance *impact_InitProcess(
00361     const char *LoginKey,
00362     const char *RadioName,
00363     const char *AWS_Access_ID,
00364     const char *AWS_Access_Secret,
00365     const char *save_path
00366 );
00367
00375 IMPACT_DECL struct impact_CInstance *impact_InitProcess2(
00376     const char *LoginKey,
00377     const char *RadioName,
00378     const char *AWS_Access_ID,
00379     const char *AWS_Access_Secret,
00380     const char *save_path,
00381     const struct impact_CParameters *parameters
00382 );
00383
00428 IMPACT_DECL struct impact_CInstance *impact_InitProcess3(
00429     const char *LoginKey,
00430     const char *RadioName,
00431     const char *AWS_Access_ID,
00432     const char *AWS_Access_Secret,
00433     const char *save_path,
00434     const struct impact_CParameters *parameters,
00435     unsigned int frames_per_chunk
00436 );

```

```

00437
00449 IMPACT_DECL unsigned int impact_GetProcessChunkFrames(struct impact_CInstance *instance);
00450
00460 IMPACT_DECL int impact_TerminateProcess(struct impact_CInstance *instance);
00461
00467 IMPACT_DECL void impact_ExitProcess(struct impact_CInstance *instance);
00468
00471 #if IMPACT_HAS_CLOUDBUS
00472 // -----
00481 struct impact_CBus;
00482
00488 IMPACT_DECL struct impact_CBus* impact_NewBus();
00489
00495 IMPACT_DECL void impact_FreeBus(struct impact_CBus *bus);
00496
00506 IMPACT_DECL void impact_SetInstanceBus(struct impact_CParameters *params, struct impact_CBus *bus);
00507
00508
00510 #endif // IMPACT_HAS_CLOUDBUS
00511
00512 // -----
00535 // -----
00536
00537 // OS dependent filesystem path char type
00538 #ifdef _WIN32
00539     typedef wchar_t fs_char;
00540 #else // !_WIN32
00541     typedef char fs_char;
00542 #endif // !_WIN32
00543
00551 typedef char * (*impact_storage_reader) (const fs_char *filename, void* userdata);
00552
00559 typedef void (*impact_storage_reader_free) (char *content, void* userdata);
00560
00569 typedef int (*impact_storage_writer) (const fs_char *filename, const char *content, void* userdata);
00570
00578 typedef int (*impact_storage_exists) (const fs_char *filename, void* userdata);
00579
00587 typedef fs_char** (*impact_storage_getall) (void* userdata);
00588
00595 typedef void (*impact_storage_getall_free) (fs_char**all, void* userdata);
00596
00604 typedef int (*impact_storage_remove) (const fs_char *filename, void* userdata);
00605
00614 typedef int (*impact_storage_rename) (const fs_char *from, const fs_char *to, void* userdata);
00615
00633 IMPACT_DECL void impact_SetPresetManager(struct impact_CParameters *params
00634     , impact_storage_reader reader, impact_storage_reader_free
00635     , impact_storage_writer writer
00636     , impact_storage_exists exists
00637     , impact_storage_getall getall, impact_storage_getall_free getall_free
00638     , impact_storage_remove remove
00639     , impact_storage_rename rename
00640     , int IsReadOnly
00641     , void* userdata
00642     );
00643
00647 enum impact_PresetChange_Kind {
00648     change_kind_created = 1,
00649     change_kind_modified ,
00650     change_kind_deleted ,
00651 };
00652
00661 IMPACT_DECL void impact_PresetManager_InformChange(struct impact_CInstance *instance, const fs_char
    *relative_path, enum impact_PresetChange_Kind change_kind);
00662
00665 // -----
00673 // -----
00674
00688 IMPACT_DECL void impact_SetMetadata(struct impact_CInstance *instance, const char* key, const char*
    value);
00689
00697 IMPACT_DECL const char** impact_GetMetadataInfos(struct impact_CInstance *instance);
00698
00705 IMPACT_DECL void impact_FreeMetadataInfos(struct impact_CInstance *instance, const char** infos);
00706
00709 // -----
00714 // -----
00715
00728 IMPACT_DECL void impact_StartUpdateThread(struct impact_CInstance *instance, unsigned int port);
00729
00735 IMPACT_DECL void impact_StopUpdateThread(struct impact_CInstance *instance);
00736
00744 IMPACT_DECL int impact_WaitUpdateThreadReady(struct impact_CInstance *instance, int milliseconds);
00745
00748 // -----
00753 // -----

```

```

00775 IMPACT_DECL void impact_ProcessAudio(struct impact_CInstance *instance, const float *input, float
    *output );
00776
00795 IMPACT_DECL void impact_ProcessAudio_Planar(struct impact_CInstance *instance
00796     , float const * const *input
00797     , float * const *output);
00798
00811 IMPACT_DECL float *impact_GetBufferIn(struct impact_CInstance *instance);
00812
00825 IMPACT_DECL float *impact_GetBufferOut(struct impact_CInstance *instance);
00826
00834 IMPACT_DECL unsigned int impact_GetEstimatedDelay(struct impact_CInstance *instance);
00835
00838 // -----
00845 // -----
00846 #ifdef _MSC_VER
00847     #define __BYTE_ORDER__ REG_DWORD
00848     #define __ORDER_LITTLE_ENDIAN__ REG_DWORD_LITTLE_ENDIAN
00849     #define __ORDER_BIG_ENDIAN__ REG_DWORD_BIG_ENDIAN
00850 #endif
00851
00855 enum impact_SampleFormat {
00856     INVALID_FORMAT=0,
00857     S16_LE,
00858     S16_BE,
00859     S24_LE,
00860     S24_BE,
00861     S32_LE,
00862     S32_BE,
00863     F32_LE,
00864     F32_BE,
00865
00866     // Native definitions, only links to the physical ones
00867     #if __BYTE_ORDER__ == __ORDER_LITTLE_ENDIAN__
00868         S16_NATIVE=S16_LE,
00869         S24_NATIVE=S24_LE,
00870         S32_NATIVE=S32_LE,
00871         F32_NATIVE=F32_LE,
00872     #else
00873         S16_NATIVE=S16_BE,
00874         S24_NATIVE=S24_BE,
00875         S32_NATIVE=S32_BE,
00876         F32_NATIVE=F32_BE,
00877     #endif
00878 };
00879
00886 IMPACT_DECL const char *impact_GetFormatName(const enum impact_SampleFormat fmt);
00887
00894 IMPACT_DECL enum impact_SampleFormat impact_GetFormatFromName(const char *name);
00895
00902 IMPACT_DECL unsigned int impact_GetBytesFromFormat(const enum impact_SampleFormat fmt);
00903
00904
00911 IMPACT_DECL unsigned int impact_GetMaxPacketFrame(struct impact_CInstance *instance);
00912
00923 IMPACT_DECL unsigned int impact_AddAudio(struct impact_CInstance *instance, const uint8_t *payload,
    unsigned int nFrame, enum impact_SampleFormat fmt );
00924
00931 IMPACT_DECL unsigned int impact_AddPadAudio(struct impact_CInstance *instance);
00932
00939 IMPACT_DECL unsigned int impact_GetOutputCount(struct impact_CInstance *instance);
00940
00950 IMPACT_DECL unsigned int impact_GetAudio(struct impact_CInstance *instance, uint8_t *payload, unsigned
    int max_nFrame, enum impact_SampleFormat fmt );
00951
00955 // -----
00959 // -----
00970 IMPACT_DECL void impact_AudioConvertFrom(const uint8_t *payload, float *output, size_t nSpl, enum
    impact_SampleFormat fmt);
00971
00982 IMPACT_DECL void impact_AudioConvertTo(const float *input, uint8_t *payload, size_t nSpl, enum
    impact_SampleFormat fmt);
00983
00993 IMPACT_DECL void impact_StereoToMono(const float *input, float *output, size_t nFrame);
00994
01004 IMPACT_DECL void impact_MonoToStereo(const float *input, float *output, size_t nFrame);
01005
01016 IMPACT_DECL void impact_StereoToMono_Planar(const float *inputL, const float *inputR, float *output,
    size_t nFrame);
01017
01028 IMPACT_DECL void impact_MonoToStereo_Planar(const float *input, float *outputL, float *outputR, size_t
    nFrame);
01029
01036 IMPACT_DECL void impact_AudioMonoFromLiveStereo(const uint8_t *payload, float *output);
01037
01044 IMPACT_DECL void impact_AudioMonoToLiveStereo(const float *input, uint8_t *payload);
01045

```

```

01048 // -----
01053 // -----
01057 struct impact_CClientInstance;
01058
01067 IMPACT_DECL struct impact_CClientInstance *impact_NewClient(struct impact_CInstance *instance);
01068
01074 IMPACT_DECL void impact_DeleteClient(struct impact_CClientInstance *client);
01075
01089 IMPACT_DECL const char *impact_ProcessJson(struct impact_CClientInstance *client, const char
    *json_str, int *need_save);
01090
01096 IMPACT_DECL void impact_FreeJsonAnswer(const char *json_str);
01097
01109 IMPACT_DECL int impact_SaveState(struct impact_CInstance *instance);
01110
01406 #if IMPACT_HAS_WEBSERVER
01407 // -----
01415 // -----
01434 IMPACT_DECL uint64_t impact_Webserver_tcp(unsigned int listenport, unsigned int listenport_secure,
    const char *socket_ip, unsigned int socket_port);
01435
01436 // -----
01456 IMPACT_DECL uint64_t impact_Webserver_tcp2(unsigned int listenport, unsigned int listenport_secure,
    const char *socket_ip, unsigned int socket_port, const struct impact_CParameters *parameters);
01457
01475 IMPACT_DECL uint64_t impact_Webserver(unsigned int listenport, unsigned int listenport_secure, struct
    impact_CInstance *instance);
01476
01486 IMPACT_DECL int impact_Webserver_Stop(uint64_t id, int timeout_ms);
01487
01496 IMPACT_DECL int impact_Webserver_Status(uint64_t id);
01497
01502 #define SOUND4_INVALID_WEBSERVER_ID ((uint64_t)-1)
01503
01507 #define SOUND4_WEBSERVER_HTTP_OK (1<<0)
01511 #define SOUND4_WEBSERVER_HTTPS_OK (1<<1)
01512
01514 #endif // IMPACT_HAS_WEBSERVER
01515
01516 #ifdef __cplusplus
01517 } // extern "C"
01518 #endif // __cplusplus

```

11.9 sound4.impact.cl.hpp File Reference

C++ wrapper for library.

```

#include <string>
#include <exception>
#include <thread>
#include <functional>
#include <memory>
#include <array>
#include <assert.h>
#include <stdexcept>
#include <filesystem>
#include <string.h>
#include "sound4.impact.cl.h"
#include <stringapiset.h>
#include <wchar.h>

```

Classes

- struct [sound4::impact::helper::SampleFormat< T >](#)
Helper for Sample format types.
- struct [sound4::impact::helper::SampleFormat< int16_t >](#)
- struct [sound4::impact::helper::SampleFormat< int32_t >](#)

- struct [sound4::impact::helper::SampleFormat< float >](#)
- class [sound4::impact::CPresetLoader](#)
- class [sound4::impact::CInstance](#)
- class [sound4::impact::CInstance::CClient](#)

Namespaces

- [sound4](#)
- [sound4::impact](#)
- [sound4::impact::helper](#)

Macros

- `#define fs\_strdup wcsdup`
helper for OS dependant file name copy

Typedefs

- using [sound4::impact::SampleFormat](#) = [impact_SampleFormat](#)
- using [sound4::impact::LogSeverity](#) = [impact_LogSeverity](#)
- using [sound4::impact::log_cb_t](#) = `std::function< void(LogSeverity, const std::string &)>`
- using [sound4::impact::PresetChange_Kind](#) = [impact_PresetChange_Kind](#)

Variables

- `const size_t sound4::impact::ChunkFrames = IMPACT\_AUDIOFRAME\_COUNT`
- `const size_t sound4::impact::InputChannels = IMPACT\_CHANNEL\_COUNT*IMPACT\_AUDIO\_INPUT\_COUNT`
- `const size_t sound4::impact::OutputChannels = IMPACT\_CHANNEL\_COUNT*IMPACT\_AUDIO\_OUTPUT\_COUNT`
- `const size_t sound4::impact::InputSampleSize = ChunkFrames*InputChannels`
- `const size_t sound4::impact::OutputSampleSize = ChunkFrames*OutputChannels`
- `const size_t sound4::impact::SampleRate = IMPACT\_SAMPLE\_RATE`

11.9.1 Macro Definition Documentation

11.9.1.1 `fs_strdup`

```
#define fs\_strdup wcsdup
```

Definition at line 25 of file [sound4.impact.cl.hpp](#).

11.10 sound4.impact.cl.hpp

```

00001
00004 #pragma once
00005
00006 #include <string>
00007 #include <exception>
00008 #include <thread>
00009 #include <functional>
00010 #include <memory>
00011 #include <array>
00012 #include <assert.h>
00013 #include <stdexcept>
00014 #include <filesystem>
00015 #include <string.h>
00016
00017 #include "sound4.impact.cl.h"
00018
00019
00020 // Filesystem path char type
00021 #ifdef _WIN32
00022     #include <stringapiset.h>
00023     #include <wchar.h>
00025     #define fs_strdup wcsdup
00026 #else // !_WIN32
00028     #define fs_strdup strdup
00029 #endif // !_WIN32
00030
00031 // bridge C callbacks to CPresetLoader
00032 extern "C" {
00033     static char *impact_custom_reader(const fs_char *filename, void* userdata);
00034     static void impact_custom_reader_free(char *content, void* userdata);
00035     static int impact_custom_writer(const fs_char *filename, const char *content, void* userdata);
00036     static int impact_custom_exists(const fs_char *filename, void* userdata);
00037     static fs_char** impact_custom_getall(void* userdata);
00038     static void impact_custom_getall_free(fs_char** all, void* userdata);
00039     static int impact_custom_remove(const fs_char *filename, void* userdata);
00040     static int impact_custom_rename(const fs_char *from, const fs_char *to, void* userdata);
00041 };
00042
00046 namespace sound4 {
00050 namespace impact {
00051     static constexpr const char *process_name = "SOUND4 IMPACT.CL";
00052     static constexpr const char *process_shortcode = "impact";
00053     using SampleFormat = impact_SampleFormat;
00057     const size_t ChunkFrames=IMPACT_AUDIOFRAME_COUNT;
00061     const size_t InputChannels=IMPACT_CHANNEL_COUNT*IMPACT_AUDIO_INPUT_COUNT;
00065     const size_t OutputChannels=IMPACT_CHANNEL_COUNT*IMPACT_AUDIO_OUTPUT_COUNT;
00069     const size_t InputSampleSize=ChunkFrames*InputChannels;
00073     const size_t OutputSampleSize=ChunkFrames*OutputChannels;
00077     const size_t SampleRate=IMPACT_SAMPLE_RATE;
00078
00082     namespace helper {
00083         #ifdef _WIN32
00089         static inline std::string WStringToUTF8(const std::wstring& wstr) {
00090             if (wstr.empty()) return {};
00091             int size = WideCharToMultiByte(CP_UTF8, 0, &wstr[0], (int)wstr.size(), NULL, 0, NULL,
NULL);
00092             std::string str(size, 0);
00093             WideCharToMultiByte(CP_UTF8, 0, &wstr[0], (int)wstr.size(), &str[0], size, NULL, NULL);
00094             return str;
00095         }
00101         static inline std::wstring UTF8ToWString(const std::string& str) {
00102             if (str.empty()) return std::wstring();
00103             int size = MultiByteToWideChar(CP_UTF8, 0, &str[0], (int)str.size(), NULL, 0);
00104             std::wstring wstr(size, 0);
00105             MultiByteToWideChar(CP_UTF8, 0, &str[0], (int)str.size(), &wstr[0], size);
00106             return wstr;
00107         }
00108         #endif // _WIN32
00109
00115         template<typename T>
00116         struct SampleFormat {
00117         };
00118         template<>
00119         struct SampleFormat<int16_t> {
00120             const impact_SampleFormat format = S16_NATIVE;
00121         };
00122         template<>
00123         struct SampleFormat<int32_t> {
00124             const impact_SampleFormat format = S32_NATIVE;
00125         };
00126         template<>
00127         struct SampleFormat<float> {
00128             const impact_SampleFormat format = F32_NATIVE;
00129         };
00130

```

```

00131
00136     static inline void AudioConvertFrom(const uint8_t *payload, float *output, size_t nSpl,
impact_SampleFormat fmt) {
00137         impact_AudioConvertFrom(payload, output, nSpl, fmt);
00138     }
00139     static inline void AudioConvertTo(const float *input, uint8_t *payload, size_t nSpl,
impact_SampleFormat fmt) {
00140         impact_AudioConvertTo(input, payload, nSpl, fmt);
00141     }
00142     static inline void StereoToMono(const float *input, float *output, size_t nSpl) {
00143         impact_StereoToMono(input, output, nSpl);
00144     }
00145     static inline void MonoToStereo(const float *input, float *output, size_t nSpl) {
00146         impact_MonoToStereo(input, output, nSpl);
00147     }
00148     static inline void StereoToMono_Planar(const float *inputL, const float *inputR, float
*output, size_t nSpl) {
00149         impact_StereoToMono_Planar(inputL, inputR, output, nSpl);
00150     }
00151     static inline void MonoToStereo_Planar(const float *input, float *outputL, float *outputR,
size_t nSpl) {
00152         impact_MonoToStereo_Planar(input, outputL, outputR, nSpl);
00153     }
00154     static inline void AudioMonoFromLiveStereo(const uint8_t *payload, float *output) {
00155         impact_AudioMonoFromLiveStereo(payload, output);
00156     }
00157     static inline void AudioMonoToLiveStereo(const float *input, uint8_t *payload) {
00158         impact_AudioMonoToLiveStereo(input, payload);
00159     }
00160
00161 }; // namespace helper
00162
00168     static inline std::string GetVersion()
00169     {
00170         return std::string(impact_GetVersion());
00171     }
00172
00183     static inline unsigned int GetChunkSizeInFrames()
00184     {
00185         return impact_GetChunkSizeInFrames();
00186     }
00187
00196     static inline std::vector<unsigned int> GetPossibleChunkSizeInFrames()
00197     {
00198         std::vector<unsigned int> list;
00199         for (unsigned int* src=impact_GetPossibleChunkSizeInFrames();*src;src++) {
00200             list.push_back(*src);
00201         }
00202         return list;
00203     }
00204
00212     static inline unsigned int GetChannelCount()
00213     {
00214         return impact_GetChannelCount();
00215     }
00216
00225     static inline unsigned int GetAudioInputCount()
00226     {
00227         return impact_GetAudioInputCount();
00228     }
00229
00238     static inline unsigned int GetAudioOutputCount()
00239     {
00240         return impact_GetAudioOutputCount();
00241     }
00242
00250     static inline unsigned int GetSampleRate()
00251     {
00252         return impact_GetSampleRate();
00253     }
00254
00260     static inline void SanityCheck(bool a_bCheckFrames = true)
00261     {
00262         // Do some sanity checks
00263         if (impact_GetSampleRate() != IMPACT_SAMPLE_RATE) {
00264             throw std::runtime_error("Bad library sampling rate");
00265         }
00266         if (a_bCheckFrames && impact_GetChunkSizeInFrames() != ChunkFrames) {
00267             throw std::runtime_error("Bad library frame size");
00268         }
00269         if (impact_GetChannelCount() != IMPACT_CHANNEL_COUNT) {
00270             throw std::runtime_error("Bad library channel count");
00271         }
00272         if (impact_GetAudioInputCount() != IMPACT_AUDIO_INPUT_COUNT) {
00273             throw std::runtime_error("Bad library input count");
00274         }
00275         if (impact_GetAudioOutputCount() != IMPACT_AUDIO_OUTPUT_COUNT) {

```

```

00276         throw std::runtime_error("Bad library output count");
00277     }
00278 }
00279
00286 static inline std::string GetFormatName(const SampleFormat fmt)
00287 {
00288     return std::string(impact_GetFormatName(fmt));
00289 }
00290
00297 static inline SampleFormat GetFormatFromName(const std::string& name)
00298 {
00299     return impact_GetFormatFromName(name.c_str());
00300 }
00301
00308 static inline unsigned int GetBytesFromFormat(const SampleFormat fmt)
00309 {
00310     return impact_GetBytesFromFormat(fmt);
00311 }
00312
00316 using LogSeverity = impact_LogSeverity;
00320 using log_cb_t = std::function<void(LogSeverity, const std::string&)>;
00321
00325 static log_cb_t _log_cb;
00326 extern "C" {
00327     static inline void _log_cb_c(impact_LogSeverity severity, const char *c_msg) {
00328         _log_cb(severity, std::string(c_msg));
00329     }
00330 }
00334 static inline void SetLogSeverity(LogSeverity severity)
00335 {
00336     impact_SetLogSeverity(severity);
00337 }
00341 static inline void SetLoggerCallback(log_cb_t cb)
00342 {
00343     _log_cb=cb;
00344     impact_SetLoggerCallback(&_log_cb_c);
00345 }
00346
00347 #if IMPACT_HAS_CLOUDBUS
00348 class CBus {
00349 public:
00350     CBus()
00351         : m_bus(impact_NewBus()) {}
00352     ~CBus()
00353     {
00354         impact_FreeBus(m_bus);
00355         m_bus = nullptr;
00356     }
00357     impact_CBus *Get() const { return m_bus; }
00358 private:
00359     impact_CBus *m_bus;
00360 };
00361 #endif // IMPACT_HAS_CLOUDBUS
00362
00367 class CPresetLoader {
00368 public:
00369     CPresetLoader() = default;
00370     virtual ~CPresetLoader() = default;
00371
00372     virtual bool IsReadOnly() = 0;
00373     virtual bool Exists(const std::filesystem::path &name) = 0;
00374     virtual bool Remove(const std::filesystem::path &name) = 0;
00375     virtual bool Rename(const std::filesystem::path &from, const std::filesystem::path &to) = 0;
00376     virtual std::vector<std::filesystem::path> GetAll() = 0;
00377     virtual std::string Read(const std::filesystem::path &filename) = 0;
00378     virtual bool Write(const std::filesystem::path &filename, const std::string &content) = 0;
00379 };
00380 using PresetChange_Kind = impact_PresetChange_Kind;
00381
00385 class CInstance {
00386 public:
00390     CInstance()
00391     {
00392         params = impact_NewParameters();
00393         if (!params) throw std::bad_alloc();
00394     }
00395     // non-copyable
00396     CInstance(const CInstance&) = delete;
00397     CInstance& operator=(const CInstance&) = delete;
00401     ~CInstance()
00402     {
00403         Stop();
00404         if (params) impact_FreeParameters(params);
00405     }
00409     bool IsOk() const { return instance!=nullptr; }
00417     void SetParam(const std::string& name, const std::string& value)
00418     {

```

```

00419         assert(params);
00420         impact_SetParameter(params, name.c_str(), value.c_str());
00421     }
00427     std::string GetParam(const std::string& name)
00428     {
00429         assert(params);
00430         auto c_value=impact_GetParameter(params, name.c_str());
00431         std::string ret(c_value);
00432         impact_FreeParameterValue(c_value);
00433         return ret;
00434     }
00435
00445     void SetPresetManager(CPresetLoader *preset_manager)
00446     {
00447         if (!preset_manager) return;
00448         assert(params);
00449         impact_SetPresetManager(params,
00450             impact_custom_reader,
00451             impact_custom_reader_free,
00452             impact_custom_writer,
00453             impact_custom_exists,
00454             impact_custom_getall,
00455             impact_custom_getall_free,
00456             impact_custom_remove,
00457             impact_custom_rename,
00458             preset_manager->IsReadOnly(),
00459             preset_manager
00460         );
00461     }
00462
00463     #if IMPACT_HAS_CLOUDBUS
00467     void SetBus(const CBus& bus) {
00468         assert(params);
00469         impact_SetInstanceBus(params, bus.Get());
00470     }
00471     #endif // IMPACT_HAS_CLOUDBUS
00472
00487     bool Create(const std::string& LoginKey, const std::string& RadioName, const std::string&
AWS_Access_ID, const std::string& AWS_Access_Secret, const std::filesystem::path& save_path, int
json_port = 0, unsigned int frames_per_chunk=64)
00488     {
00489         assert(!instance);
00490         std::string l_save_path;
00491         if (!save_path.empty()) {
00492             l_save_path = save_path.u8string();
00493         }
00494         instance = impact_InitProcess3(LoginKey.c_str(), RadioName.c_str(),
AWS_Access_ID.c_str(), AWS_Access_Secret.c_str(), l_save_path.c_str(), params, frames_per_chunk);
00495         if (!instance) return false;
00496         if (!init_metadata.empty()) {
00497             for (auto& [key,value]: init_metadata) {
00498                 impact_SetMetadata(instance, key.c_str(), value.c_str());
00499             }
00500             init_metadata.clear();
00501         }
00502         update_thread = std::thread([this, json_port]() {
00503             OnUpdateThreadStart();
00504             impact_StartUpdateThread(instance, json_port);
00505             OnUpdateThreadStop();
00506         });
00507         int timeout=5000;
00508         #ifdef DEBUG
00509             timeout=60*1000; // For debugger pauses
00510         #endif
00511         if (impact_WaitUpdateThreadReady(instance, timeout)<0) {
00512             return false;
00513         }
00514         return true;
00515     }
00516
00524     unsigned int GetChunkFrames() {
00525         if (instance) {
00526             return impact_GetProcessChunkFrames(instance);
00527         }
00528         return 0;
00529     }
00530
00538     void PresetManager_InformChange(const std::filesystem::path& relative_path, PresetChange_Kind
change_kind)
00539     {
00540         impact_PresetManager_InformChange(instance, relative_path.c_str(),
(implement_PresetChange_Kind) change_kind);
00541     }
00542
00554     void SetMetadata(const std::string& key, const char* value)
00555     {
00556         if (instance) {

```

```

00557         impact_SetMetadata(instance, key.c_str(), value);
00558     } else {
00559         init_metadata.push_back( {key, value} );
00560     }
00561 }
00562
00563 std::vector< std::tuple<std::string, std::string> > GetMetadataInfos()
00564 {
00565     std::vector< std::tuple<std::string, std::string> > values;
00566     const char** c_values = impact_GetMetadataInfos(instance);
00567     if (c_values) {
00568         for (const char** c_value=c_values; *c_value; ) {
00569             std::string key(*c_value);
00570             c_value++;
00571             if (*c_value) {
00572                 std::string descr(*c_value);
00573                 c_value++;
00574                 values.push_back( {key, descr} );
00575             }
00576         }
00577         impact_FreeMetadataInfos(instance, c_values);
00578     }
00579     return values;
00580 }
00581
00582 // Can be overloaded, called at start of UpdateThread in the thread
00583 virtual void OnUpdateThreadStart() {}
00584 // Can be overloaded to call at end of UpdateThread in the thread
00585 virtual void OnUpdateThreadStop() {}
00586
00587 #if IMPACT_HAS_WEBSERVER
00588 bool StartWebServer(int http_port, int https_port=0)
00589 {
00590     assert(instance);
00591     assert(webserver==SOUND4_INVALID_WEBSERVER_ID);
00592     webserver = impact_Webserver(http_port, https_port, instance);
00593     if (webserver==SOUND4_INVALID_WEBSERVER_ID) {
00594         return false;
00595     }
00596     int web_status=impact_Webserver_Status(webserver);
00597     if (http_port && (web_status & SOUND4_WEBSERVER_HTTP_OK) == 0) {
00598         return false;
00599     }
00600     if (https_port && (web_status & SOUND4_WEBSERVER_HTTPS_OK) == 0) {
00601         return false;
00602     }
00603     return true;
00604 }
00605 void StopWebServer()
00606 {
00607     if (webserver != SOUND4_INVALID_WEBSERVER_ID) {
00608         impact_Webserver_Stop(webserver, 1000);
00609         webserver = SOUND4_INVALID_WEBSERVER_ID;
00610     }
00611 }
00612 #endif // IMPACT_HAS_WEBSERVER
00613
00614 int Terminate()
00615 {
00616     if (!instance) return 0;
00617     return impact_TerminateProcess(instance);
00618 }
00619
00620 void Stop()
00621 {
00622     if (!instance) return;
00623 #if IMPACT_HAS_WEBSERVER
00624     StopWebServer();
00625 #endif // IMPACT_HAS_WEBSERVER
00626     if (update_thread.joinable()) {
00627         impact_StopUpdateThread(instance); // this will exit the update thread
00628         update_thread.join();
00629     }
00630     impact_ExitProcess(instance);
00631     instance=nullptr;
00632 }
00633
00634 unsigned int GetEstimatedDelay()
00635 {
00636     assert(instance);
00637     return impact_GetEstimatedDelay(instance);
00638 }
00639
00640 std::array<float, InputSampleSize>& GetBufferIn()
00641 {
00642     assert(instance);
00643     float *buf=impact_GetBufferIn(instance);

```

```

00685         return reinterpret_cast< std::array<float, InputSampleSize>& > (*buf);
00686     }
00687 }
00698 std::array<float, OutputSampleSize>& GetBufferOut ()
00699 {
00700     assert(instance);
00701     float *buf= impact_GetBufferOut(instance);
00702     return reinterpret_cast< std::array<float, OutputSampleSize>& > (*buf);
00703 }
00709 void ProcessAudio()
00710 {
00711     assert(instance);
00712     impact_ProcessAudio(instance, impact_GetBufferIn(instance),
00713 impact_GetBufferOut(instance));
00713 }
00727 // void ProcessAudio_Planar(const std::array< const std::array<const float, ChunkFrames>,
00728 InputChannels>& input, std::array< std::array<float, ChunkFrames>, OutputChannels>& output)
00729 void ProcessAudio_Planar(float const * const *input, float * const *output)
00729 {
00730     assert(instance);
00731     impact_ProcessAudio_Planar(instance, input, output);
00732 }
00733
00745 template<typename T>
00746 std::vector<T> ProcessAnyAudio(const std::vector<T> input)
00747 {
00748     assert(instance);
00749     std::vector<T> output;
00750     unsigned int out_offset=0;
00751     unsigned int in_offset=0;
00752     unsigned int todo = input.size();
00753     while (todo>0) {
00754         unsigned int left = AddAudio(&input[in_offset], todo);
00755         unsigned int out_avail = impact_GetOutputCount(instance);
00756         output.resize(out_offset + out_avail);
00757         GetAudio(&output[out_offset], out_avail);
00758         out_offset+=out_avail;
00759         in_offset += todo-left;
00760         todo=left;
00761     }
00762     return output;
00763 }
00764
00770 class CClient {
00771 public:
00772     CClient(impact_CInstance* instance)
00773     {
00774         assert(instance);
00775         client=impact_NewClient(instance);
00776         if (!client) throw std::bad_alloc();
00777     }
00778     // non-copyable
00779     CClient( const CInstance& ) = delete;
00780     CClient& operator=( const CInstance& ) = delete;
00781     ~CClient()
00782     {
00783         if (client) {
00784             impact_DeleteClient(client);
00785             client=nullptr;
00786         }
00787     }
00795     std::string ProcessJson(const std::string &request, bool *NeedSave = nullptr)
00796     {
00797         assert(client);
00798         int need_save=0;
00799         const char *canswer = impact_ProcessJson(client, request.c_str(), &need_save);
00800         if (!canswer) return {};
00801         std::string answer(canswer);
00802         impact_FreeJsonAnswer (canswer);
00803         if (NeedSave) {
00804             *NeedSave=(need_save!=0);
00805         }
00806         return answer;
00807     }
00808 private:
00809     impact_CClientInstance *client = nullptr;
00810 };
00818 std::shared_ptr<CClient> NewClient ()
00819 {
00820     assert(instance);
00821     return std::make_shared<CClient>(instance);
00822 }
00823
00824 protected:
00825     template<typename T>
00826     unsigned int AddAudio(const T* payload, unsigned int nFrame)
00827 {

```

```

00828         assert(instance);
00829         return impact_AddAudio(instance, reinterpret_cast<const T*>(payload), nFrame,
helper::SampleFormat<T>::format);
00830     }
00831     template<typename T>
00832     unsigned int GetAudio(T* payload, unsigned int max_nFrame)
00833     {
00834         assert(instance);
00835         return impact_GetAudio(instance, reinterpret_cast<T*>(payload), max_nFrame,
helper::SampleFormat<T>::format);
00836     }
00837
00838     private:
00839         impact_CParameters* params = nullptr;
00840         impact_CInstance* instance = nullptr;
00841         std::thread update_thread;
00842         std::vector< std::pair<std::string, std::string> > init_metadata;
00843 #if IMPACT_HAS_WEBSERVER
00844         uint64_t webserver = SOUND4_INVALID_WEBSERVER_ID;
00845 #endif // IMPACT_HAS_WEBSERVER
00846     };
00847
00848 }; // namespace impact
00849 }; // namespace sound4
00850
00851 // bridge C callbacks to CPresetLoader
00852 extern "C" {
00853     static char *impact_custom_reader(const fs_char *filename, void* userdata) {
00854         sound4::impact::CPresetLoader
*preset_loader=reinterpret_cast<sound4::impact::CPresetLoader*>(userdata);
00855         std::string content=preset_loader->Read(filename);
00856         return strdup(content.c_str());
00857     }
00858     static void impact_custom_reader_free(char *content, void* userdata) {
00859         if (!content) return;
00860         free(content);
00861     }
00862     static int impact_custom_writer(const fs_char *filename, const char *content, void* userdata) {
00863         sound4::impact::CPresetLoader
*preset_loader=reinterpret_cast<sound4::impact::CPresetLoader*>(userdata);
00864         auto res=preset_loader->Write(filename,content);
00865         return res?0:-1;
00866     }
00867     static int impact_custom_exists(const fs_char *filename, void* userdata) {
00868         sound4::impact::CPresetLoader
*preset_loader=reinterpret_cast<sound4::impact::CPresetLoader*>(userdata);
00869         auto res=preset_loader->Exists(filename);
00870         return res?0:-1;
00871     }
00872     static fs_char** impact_custom_getall(void* userdata) {
00873         sound4::impact::CPresetLoader
*preset_loader=reinterpret_cast<sound4::impact::CPresetLoader*>(userdata);
00874         auto res=preset_loader->GetAll();
00875         fs_char**all=(fs_char**)malloc((res.size()+1)*sizeof(const fs_char*));
00876         for (size_t n=0;n<res.size();n++) {
00877             all[n]=fs_strdup(res[n].c_str());
00878         }
00879         all[res.size()]=nullptr;
00880         return all;
00881     }
00882     static void impact_custom_getall_free(fs_char** all, void* userdata) {
00883         if (!all) return;
00884         for (fs_char** one=all;*one;one++) {
00885             free(*one);
00886         }
00887         free(all);
00888     }
00889     static int impact_custom_remove(const fs_char *filename, void* userdata) {
00890         sound4::impact::CPresetLoader
*preset_loader=reinterpret_cast<sound4::impact::CPresetLoader*>(userdata);
00891         auto res=preset_loader->Remove(filename);
00892         return res?0:-1;
00893     }
00894     static int impact_custom_rename(const fs_char *from, const fs_char *to, void* userdata) {
00895         sound4::impact::CPresetLoader
*preset_loader=reinterpret_cast<sound4::impact::CPresetLoader*>(userdata);
00896         auto res=preset_loader->Rename(from,to);
00897         return res?0:-1;
00898     }
00899 }
00900 };

```

11.11 sound4.impact.cl_dyn.hpp File Reference

C++ wrapper for dynamic loading library.

```
#include <string>
#include <exception>
#include <thread>
#include <functional>
#include <memory>
#include <array>
#include <assert.h>
#include <stdexcept>
#include <filesystem>
#include <string.h>
#include <loaderapi.h>
#include "sound4.impact.cl.h"
#include <stringapiset.h>
#include <wchar.h>
```

Classes

- class [sound4::impact::dyn::helper::DynFuncHolder< T >](#)
Helper to wrap a function pointer.
- class [sound4::impact::dyn::helper::CDynLoader](#)
Helper to load dynamic library.
- class [sound4::impact::dyn::CDynLib](#)
Dynamic library interface.
- struct [sound4::impact::dyn::helper::SampleFormat< T >](#)
Helper for Sample format types.
- struct [sound4::impact::dyn::helper::SampleFormat< int16_t >](#)
- struct [sound4::impact::dyn::helper::SampleFormat< int32_t >](#)
- struct [sound4::impact::dyn::helper::SampleFormat< float >](#)
- class [sound4::impact::dyn::CPresetLoader](#)
- class [sound4::impact::dyn::CInstance](#)
- class [sound4::impact::dyn::CInstance::CClient](#)

Namespaces

- [sound4](#)
- [sound4::impact](#)
- [dyn](#)
- [sound4::impact::dyn](#)
- [sound4::impact::dyn::helper](#)

Macros

- [#define fs_strdup](#) wcsdup
helper for OS dependant file name copy

Typedefs

- using [sound4::impact::dyn::helper::DynLib_t](#) = HMODULE
- using [sound4::impact::dyn::helper::DynFunc_t](#) = FARPROC
- using [sound4::impact::dyn::SampleFormat](#) = [impact_SampleFormat](#)
- using [sound4::impact::dyn::LogSeverity](#) = [impact_LogSeverity](#)
- using [sound4::impact::dyn::log_cb_t](#) = std::function< void(LogSeverity, const std::string &)>
- using [sound4::impact::dyn::PresetChange_Kind](#) = [impact_PresetChange_Kind](#)

Variables

- const size_t [sound4::impact::dyn::ChunkFrames](#) = [IMPACT_AUDIOFRAME_COUNT](#)
- const size_t [sound4::impact::dyn::InputChannels](#) = [IMPACT_CHANNEL_COUNT](#)*[IMPACT_AUDIO_INPUT_COUNT](#)
- const size_t [sound4::impact::dyn::OutputChannels](#) = [IMPACT_CHANNEL_COUNT](#)*[IMPACT_AUDIO_OUTPUT_COUNT](#)
- const size_t [sound4::impact::dyn::InputSampleSize](#) = [ChunkFrames](#)*[InputChannels](#)
- const size_t [sound4::impact::dyn::OutputSampleSize](#) = [ChunkFrames](#)*[OutputChannels](#)
- const size_t [sound4::impact::dyn::SampleRate](#) = [IMPACT_SAMPLE_RATE](#)

11.11.1 Detailed Description

You need to load the dynamic library, and if it succeed you can use it.

Definition in file [sound4.impact.cl_dyn.hpp](#).

11.11.2 Macro Definition Documentation

11.11.2.1 fs_strdup

```
#define fs_strdup wcsdup
```

Definition at line 36 of file [sound4.impact.cl_dyn.hpp](#).

11.12 sound4.impact.cl_dyn.hpp

```
00001
00007 #pragma once
00008
00009 #include <string>
00010 #include <exception>
00011 #include <thread>
00012 #include <functional>
00013 #include <memory>
00014 #include <array>
00015 #include <assert.h>
00016 #include <stdexcept>
00017 #include <filesystem>
00018 #include <string.h>
00019
00020 #ifdef __unix__
00021     #include <dlfcn.h>
00022 #elif defined(_WIN32)
00023     #include <loaderapi.h>
00024 #else
00025     #error "Unsupported OS"
```

```

00026 #endif
00027
00028 // Needed to have function declarations
00029 #include "sound4.impact.cl.h"
00030
00031
00032 #ifdef _WIN32
00033     #include <stringapiset.h>
00034     #include <wchar.h>
00036     #define fs_strdup wcsdup
00037 #else // !_WIN32
00039     #define fs_strdup strdup
00040 #endif // !_WIN32
00041
00042 // bridge C callbacks to CPresetLoader
00043 extern "C" {
00044     static char *impact_custom_reader(const fs_char *filename, void* userdata);
00045     static void impact_custom_reader_free(char *content, void* userdata);
00046     static int impact_custom_writer(const fs_char *filename, const char *content, void* userdata);
00047     static int impact_custom_exists(const fs_char *filename, void* userdata);
00048     static fs_char** impact_custom_getall(void* userdata);
00049     static void impact_custom_getall_free(fs_char** all, void* userdata);
00050     static int impact_custom_remove(const fs_char *filename, void* userdata);
00051     static int impact_custom_rename(const fs_char *from, const fs_char *to, void* userdata);
00052 };
00053
00054 namespace sound4 {
00055     namespace impact {
00056         namespace dyn {
00057             namespace helper {
00058                 // Storage definition, depending on OS
00059                 #ifdef __unix__
00060                     using DynLib_t = void *;
00061                     using DynFunc_t = void *;
00062                 #else
00063                     using DynLib_t = HMODULE;
00064                     using DynFunc_t = FARPROC;
00065                 #endif
00066
00067                 template <typename T>
00068                 class DynFuncHolder {
00069 private:
00070                     DynFunc_t m_ptr = NULL;
00071 public:
00072                     DynFuncHolder() = default;
00073                     DynFuncHolder(DynFunc_t a_ptr) : m_ptr(a_ptr) {}
00074                     operator bool() const { return (m_ptr!=NULL); }
00075                     bool IsOk() const { return m_ptr!=NULL; }
00076                     operator T* () const { return reinterpret_cast<T*>(m_ptr); }
00077                 };
00078
00079                 class CDynLoader {
00080 private:
00081                     DynLib_t m_lib {};
00082 public:
00083                     CDynLoader() = default;
00084                     CDynLoader(CDynLoader&&) = default;
00085                     // No copy allowed
00086                     CDynLoader(const CDynLoader&) = delete;
00087                     CDynLoader& operator=(CDynLoader const&) = delete;
00088                     operator bool() const {
00089                         return (m_lib!=NULL);
00090                     }
00091                     bool IsOk() const {
00092                         return (m_lib!=NULL);
00093                     }
00094                     #ifdef __unix__
00095                     void Close() {
00096                         if (IsOk()) {
00097                             #ifndef __SANITIZE_ADDRESS__ // avoid unloading to keep call stack
00098                                 dlclose(m_lib);
00099                             #endif // __SANITIZE_ADDRESS__
00100                             m_lib=NULL;
00101                         }
00102                     }
00103                     bool Load(const std::filesystem::path& dynlib)
00104                     {
00105                         Close();
00106                         m_lib=dlopen(dynlib.c_str(), RTLD_NOW|RTLD_LOCAL);
00107                         return IsOk();
00108                     }
00109
00110                     template <typename T>
00111                     DynFuncHolder<T> GetSymbol(const std::string& name) {
00112                         auto ptr=dlsym(m_lib, name.c_str());
00113                         if (!ptr) {
00114                             throw std::runtime_error("Missing function in library");
00115                         }
00116                     }
00117                 };
00118             }
00119         }
00120     }
00121 }

```

```

00136         }
00137         return DynFuncHolder<T>(ptr);
00138     }
00139     template <typename T>
00140     DynFuncHolder<T> GetSymbol_safe(const std::string& name) {
00141         auto ptr=dlsym(m_lib, name.c_str());
00142         return DynFuncHolder<T>(ptr);
00143     }
00144     static std::filesystem::path GetThisLibraryPath(void) {
00145         static Dl_info info;
00146         if (! dladdr((void *) GetThisLibraryPath, & info)) return {};
00147         auto rp=realpath(info.dli_fname, NULL);
00148         std::filesystem::path p(rp);
00149         free(rp);
00150         return p;
00151     }
00152     #else
00153     bool Load(const std::filesystem::path& dynlib, uint32_t loadflags =
LOAD_LIBRARY_SEARCH_DLL_LOAD_DIR|LOAD_LIBRARY_SEARCH_APPLICATION_DIR|LOAD_LIBRARY_SEARCH_USER_DIRS|LOAD_LIBRARY_SEARCH_
00154     {
00155         Close();
00156         m_lib=LoadLibraryExW(dynlib.c_str(), NULL, loadflags);
00157         return IsOk();
00158     }
00159     void Close() {
00160         if (IsOk()) {
00161             // NOTE: On Windows, FreeLibrary may create a lot of troubles, should use
FreeLibraryAndExitThread but...
00162             // So define SOUND4_CALL_FREELIBRARY before including this file if you
really want to unload the library dynamically
00163             #if defined(SOUND4_CALL_FREELIBRARYANEXITTHREAD)
FreeLibraryAndExitThread(m_lib, 0);
00164             #elif defined(SOUND4_CALL_FREELIBRARY)
FreeLibrary(m_lib);
00165             #endif // SOUND4_CALL_FREELIBRARY
m_lib=NULL;
00166         }
00167     }
00168     template <typename T>
00169     DynFuncHolder<T> GetSymbol(const std::string& name) {
00170         auto ptr=GetProcAddress(m_lib, name.c_str());
00171         if (!ptr) {
00172             throw std::runtime_error("Missing function in library");
00173         }
00174         return DynFuncHolder<T>(ptr);
00175     }
00176     template <typename T>
00177     DynFuncHolder<T> GetSymbol_safe(const std::string& name) {
00178         auto ptr=GetProcAddress(m_lib, name.c_str());
00179         return DynFuncHolder<T>(ptr);
00180     }
00181     static std::filesystem::path GetThisLibraryPath(void) {
00182         static wchar_t path[MAX_PATH]={};
00183         HMODULE hm = NULL;
00184         if (GetModuleHandleExW(GET_MODULE_HANDLE_EX_FLAG_FROM_ADDRESS |
GET_MODULE_HANDLE_EX_FLAG_UNCHANGED_REFCOUNT,
00185         (LPCWSTR) &GetThisLibraryPath, &hm))
00186         {
00187             if (GetModuleFileNameW(hm, path, MAX_PATH) > 0) {
00188                 return std::filesystem::path(path);
00189             }
00190         }
00191         return {};
00192     }
00193     #endif
00194     virtual ~CDynLoader() {
00195         Close();
00196     }
00197 }; // class CDynLoader
00198 }; // namespace helper
00199
00200 class CDynLib {
00201 private:
00202     helper::CDynLoader m_lib;
00203     bool m_bOK = false;
00204 public:
00205     CDynLib() = default;
00206
00207     // All those wrapped functions have the same signature as there C impact_XXX
00208     helper::DynFuncHolder< decltype(impact_GetVersion) ) > GetVersion ;
00209     helper::DynFuncHolder< decltype(impact_GetChunkSizeInFrames) ) > GetChunkSizeInFrames ;
00210     helper::DynFuncHolder< decltype(impact_GetChannelCount) ) > GetChannelCount ;
00211     helper::DynFuncHolder< decltype(impact_GetAudioInputCount) ) > GetAudioInputCount ;
00212     helper::DynFuncHolder< decltype(impact_GetAudioOutputCount) ) > GetAudioOutputCount ;
00213     helper::DynFuncHolder< decltype(impact_GetSampleRate) ) > GetSampleRate ;
00214     helper::DynFuncHolder< decltype(impact_SetLoggerCallback) ) > SetLoggerCallback ;
00215     helper::DynFuncHolder< decltype(impact_SetLogSeverity) ) > SetLogSeverity ;

```

```

00226     helper::DynFuncHolder< decltype(impact_NewParameters) ) > NewParameters ;
00227     helper::DynFuncHolder< decltype(impact_FreeParameters) ) > FreeParameters ;
00228     helper::DynFuncHolder< decltype(impact_SetParameter) ) > SetParameter ;
00229     helper::DynFuncHolder< decltype(impact_GetParameter) ) > GetParameter ;
00230     helper::DynFuncHolder< decltype(impact_FreeParameterValue) ) > FreeParameterValue ;
00231     helper::DynFuncHolder< decltype(impact_InitProcess) ) > InitProcess ;
00232     helper::DynFuncHolder< decltype(impact_InitProcess2) ) > InitProcess2 ;
00233     helper::DynFuncHolder< decltype(impact_TerminateProcess) ) > TerminateProcess ;
00234     helper::DynFuncHolder< decltype(impact_ExitProcess) ) > ExitProcess ;
00235     helper::DynFuncHolder< decltype(impact_StartUpdateThread) ) > StartUpdateThread ;
00236     helper::DynFuncHolder< decltype(impact_StopUpdateThread) ) > StopUpdateThread ;
00237     helper::DynFuncHolder< decltype(impact_WaitUpdateThreadReady) ) > WaitUpdateThreadReady ;
00238     helper::DynFuncHolder< decltype(impact_ProcessAudio) ) > ProcessAudio ;
00239     helper::DynFuncHolder< decltype(impact_ProcessAudio_Planar) ) > ProcessAudio_Planar ;
00240     helper::DynFuncHolder< decltype(impact_GetBufferIn) ) > GetBufferIn ;
00241     helper::DynFuncHolder< decltype(impact_GetBufferOut) ) > GetBufferOut ;
00242     helper::DynFuncHolder< decltype(impact_GetEstimatedDelay) ) > GetEstimatedDelay ;
00243     helper::DynFuncHolder< decltype(impact_GetFormatName) ) > GetFormatName ;
00244     helper::DynFuncHolder< decltype(impact_GetFormatFromName) ) > GetFormatFromName ;
00245     helper::DynFuncHolder< decltype(impact_GetBytesFromFormat) ) > GetBytesFromFormat ;
00246     helper::DynFuncHolder< decltype(impact_GetMaxPacketFrame) ) > GetMaxPacketFrame ;
00247     helper::DynFuncHolder< decltype(impact_AddAudio) ) > AddAudio ;
00248     helper::DynFuncHolder< decltype(impact_AddPadAudio) ) > AddPadAudio ;
00249     helper::DynFuncHolder< decltype(impact_GetOutputCount) ) > GetOutputCount ;
00250     helper::DynFuncHolder< decltype(impact_GetAudio) ) > GetAudio ;
00251     helper::DynFuncHolder< decltype(impact_AudioConvertFrom) ) > AudioConvertFrom ;
00252     helper::DynFuncHolder< decltype(impact_AudioConvertTo) ) > AudioConvertTo ;
00253     helper::DynFuncHolder< decltype(impact_StereoToMono) ) > StereoToMono ;
00254     helper::DynFuncHolder< decltype(impact_MonoToStereo) ) > MonoToStereo ;
00255     helper::DynFuncHolder< decltype(impact_AudioMonoFromLiveStereo) ) > AudioMonoFromLiveStereo ;
00256     helper::DynFuncHolder< decltype(impact_AudioMonoToLiveStereo) ) > AudioMonoToLiveStereo ;
00257     helper::DynFuncHolder< decltype(impact_NewClient) ) > NewClient ;
00258     helper::DynFuncHolder< decltype(impact_DeleteClient) ) > DeleteClient ;
00259     helper::DynFuncHolder< decltype(impact_ProcessJson) ) > ProcessJson ;
00260     helper::DynFuncHolder< decltype(impact_FreeJsonAnswer) ) > FreeJsonAnswer ;
00261     helper::DynFuncHolder< decltype(impact_SaveState) ) > SaveState ;
00262 #if IMPACT_HAS_WEBSERVER
00263     helper::DynFuncHolder< decltype(impact_Webserver_tcp) ) > Webserver_tcp ;
00264     helper::DynFuncHolder< decltype(impact_Webserver_tcp2) ) > Webserver_tcp2 ;
00265     helper::DynFuncHolder< decltype(impact_Webserver) ) > Webserver ;
00266     helper::DynFuncHolder< decltype(impact_Webserver_Stop) ) > Webserver_Stop ;
00267     helper::DynFuncHolder< decltype(impact_Webserver_Status) ) > Webserver_Status ;
00268 #endif // IMPACT_HAS_WEBSERVER
00269
00270     // added 2023-03-22
00271     helper::DynFuncHolder< decltype(impact_StereoToMono_Planar) ) > StereoToMono_Planar ;
00272     helper::DynFuncHolder< decltype(impact_MonoToStereo_Planar) ) > MonoToStereo_Planar ;
00273
00274     // added 2023-05-22
00275     helper::DynFuncHolder< decltype(impact_SetMetadata) ) > SetMetadata ;
00276     helper::DynFuncHolder< decltype(impact_GetMetadataInfos) ) > GetMetadataInfos ;
00277     helper::DynFuncHolder< decltype(impact_FreeMetadataInfos) ) > FreeMetadataInfos ;
00278
00279     // added 2023-06-20
00280     helper::DynFuncHolder< decltype(impact_SetPresetManager) ) > SetPresetManager ;
00281 ;
00282     helper::DynFuncHolder< decltype(impact_PresetManager_InformChange) ) >
00283     PresetManager_InformChange ;
00284
00285     // added 2023-09-21
00286     helper::DynFuncHolder< decltype(impact_GetPossibleChunkSizeInFrames) ) >
00287     GetPossibleChunkSizeInFrames ;
00288     helper::DynFuncHolder< decltype(impact_GetProcessChunkFrames) ) >
00289     GetProcessChunkFrames ;
00290     helper::DynFuncHolder< decltype(impact_InitProcess3) ) > InitProcess3 ;
00291 ;
00292
00293 #if IMPACT_HAS_CLOUDBUS
00294     // added 2023-06-26
00295     helper::DynFuncHolder< decltype(impact_NewBus) ) > NewBus ;
00296     helper::DynFuncHolder< decltype(impact_FreeBus) ) > FreeBus ;
00297     helper::DynFuncHolder< decltype(impact_SetInstanceBus) ) > SetInstanceBus ;
00298 #endif // IMPACT_HAS_CLOUDBUS
00299
00300 bool Load(const std::filesystem::path& path = std::filesystem::current_path()) {
00301     std::string filename;
00302     #ifdef __unix__
00303         filename="libsound4.impact.cl.so";
00304     #else
00305         filename="sound4.impact.cl.dll";
00306     #endif
00307     auto p = path;
00308     p.append(filename);
00309     m_lib.Load(p.native());
00310     if (!m_lib.IsOk()) {
00311         // Search in the same directory this code is in
00312         p =helper::CDynLoader::GetThisLibraryPath();
00313     }
00314 }

```

```

00315         p.append(filename);
00316         m_lib.Load(p.native());
00317         if (!m_lib.IsOk()) {
00318             return false;
00319         }
00320     }
00321     // Load all C functions
00322     try {
00323         GetVersion = m_lib.GetSymbol< decltype(impact_GetVersion) >
00324 >("impact_GetVersion" );
00325         GetChunkSizeInFrames = m_lib.GetSymbol< decltype(impact_GetChunkSizeInFrames) >
00326 >("impact_GetChunkSizeInFrames" );
00327         GetChannelCount = m_lib.GetSymbol< decltype(impact_GetChannelCount) >
00328 >("impact_GetChannelCount" );
00329         GetAudioInputCount = m_lib.GetSymbol< decltype(impact_GetAudioInputCount) >
00330 >("impact_GetAudioInputCount" );
00331         GetAudioOutputCount = m_lib.GetSymbol< decltype(impact_GetAudioOutputCount) >
00332 >("impact_GetAudioOutputCount" );
00333         GetSampleRate = m_lib.GetSymbol< decltype(impact_GetSampleRate) >
00334 >("impact_GetSampleRate" );
00335         SetLoggerCallback = m_lib.GetSymbol< decltype(impact_SetLoggerCallback) >
00336 >("impact_SetLoggerCallback" );
00337         SetLogSeverity = m_lib.GetSymbol< decltype(impact_SetLogSeverity) >
00338 >("impact_SetLogSeverity" );
00339         NewParameters = m_lib.GetSymbol< decltype(impact_NewParameters) >
00340 >("impact_NewParameters" );
00341         FreeParameters = m_lib.GetSymbol< decltype(impact_FreeParameters) >
00342 >("impact_FreeParameters" );
00343         SetParameter = m_lib.GetSymbol< decltype(impact_SetParameter) >
00344 >("impact_SetParameter" );
00345         GetParameter = m_lib.GetSymbol< decltype(impact_GetParameter) >
00346 >("impact_GetParameter" );
00347         FreeParameterValue = m_lib.GetSymbol< decltype(impact_FreeParameterValue) >
00348 >("impact_FreeParameterValue" );
00349         InitProcess = m_lib.GetSymbol< decltype(impact_InitProcess) >
00350 >("impact_InitProcess" );
00351         InitProcess2 = m_lib.GetSymbol< decltype(impact_InitProcess2) >
00352 >("impact_InitProcess2" );
00353         TerminateProcess = m_lib.GetSymbol< decltype(impact_TerminateProcess) >
00354 >("impact_TerminateProcess" );
00355         ExitProcess = m_lib.GetSymbol< decltype(impact_ExitProcess) >
00356 >("impact_ExitProcess" );
00357         StartUpdateThread = m_lib.GetSymbol< decltype(impact_StartUpdateThread) >
00358 >("impact_StartUpdateThread" );
00359         StopUpdateThread = m_lib.GetSymbol< decltype(impact_StopUpdateThread) >
00360 >("impact_StopUpdateThread" );
00361         WaitUpdateThreadReady = m_lib.GetSymbol< decltype(impact_WaitUpdateThreadReady) >
00362 >("impact_WaitUpdateThreadReady" );
00363         ProcessAudio = m_lib.GetSymbol< decltype(impact_ProcessAudio) >
00364 >("impact_ProcessAudio" );
00365         ProcessAudio_Planar = m_lib.GetSymbol< decltype(impact_ProcessAudio_Planar) >
00366 >("impact_ProcessAudio_Planar" );
00367         GetBufferIn = m_lib.GetSymbol< decltype(impact_GetBufferIn) >
00368 >("impact_GetBufferIn" );
00369         GetBufferOut = m_lib.GetSymbol< decltype(impact_GetBufferOut) >
00370 >("impact_GetBufferOut" );
00371         GetEstimatedDelay = m_lib.GetSymbol< decltype(impact_GetEstimatedDelay) >
00372 >("impact_GetEstimatedDelay" );
00373         GetFormatName = m_lib.GetSymbol< decltype(impact_GetFormatName) >
00374 >("impact_GetFormatName" );
00375         GetFormatFromName = m_lib.GetSymbol< decltype(impact_GetFormatFromName) >
00376 >("impact_GetFormatFromName" );
00377         GetBytesFromFormat = m_lib.GetSymbol< decltype(impact_GetBytesFromFormat) >
00378 >("impact_GetBytesFromFormat" );
00379         GetMaxPacketFrame = m_lib.GetSymbol< decltype(impact_GetMaxPacketFrame) >
00380 >("impact_GetMaxPacketFrame" );
00381         AddAudio = m_lib.GetSymbol< decltype(impact_AddAudio) >
00382 >("impact_AddAudio" );
00383         AddPadAudio = m_lib.GetSymbol< decltype(impact_AddPadAudio) >
00384 >("impact_AddPadAudio" );
00385         GetOutputCount = m_lib.GetSymbol< decltype(impact_GetOutputCount) >
00386 >("impact_GetOutputCount" );
00387         GetAudio = m_lib.GetSymbol< decltype(impact_GetAudio) >
00388 >("impact_GetAudio" );
00389         AudioConvertFrom = m_lib.GetSymbol< decltype(impact_AudioConvertFrom) >
00390 >("impact_AudioConvertFrom" );
00391         AudioConvertTo = m_lib.GetSymbol< decltype(impact_AudioConvertTo) >
00392 >("impact_AudioConvertTo" );
00393         StereoToMono = m_lib.GetSymbol< decltype(impact_StereoToMono) >
00394 >("impact_StereoToMono" );
00395         MonoToStereo = m_lib.GetSymbol< decltype(impact_MonoToStereo) >
00396 >("impact_MonoToStereo" );
00397         AudioMonoFromLiveStereo = m_lib.GetSymbol< decltype(impact_AudioMonoFromLiveStereo) >
00398 >("impact_AudioMonoFromLiveStereo" );
00399         AudioMonoToLiveStereo = m_lib.GetSymbol< decltype(impact_AudioMonoToLiveStereo) >
00400 >("impact_AudioMonoToLiveStereo" );
00401         NewClient = m_lib.GetSymbol< decltype(impact_NewClient) >
00402 >("impact_NewClient" );

```

```

>("impact_NewClient"                );
00363     DeleteClient                = m_lib.GetSymbol< decltype(impact_DeleteClient      )
>("impact_DeleteClient"            );
00364     ProcessJson                 = m_lib.GetSymbol< decltype(impact_ProcessJson   )
>("impact_ProcessJson"             );
00365     FreeJsonAnswer              = m_lib.GetSymbol< decltype(impact_FreeJsonAnswer )
>("impact_FreeJsonAnswer"          );
00366     SaveState                   = m_lib.GetSymbol< decltype(impact_SaveState     )
>("impact_SaveState"               );
00367 #if IMPACT_HAS_WEBSERVER
00368     Webserver_tcp               = m_lib.GetSymbol< decltype(impact_Webserver_tcp   )
>("impact_Webserver_tcp"           );
00369     Webserver_tcp2              = m_lib.GetSymbol< decltype(impact_Webserver_tcp2  )
>("impact_Webserver_tcp2"          );
00370     Webserver                   = m_lib.GetSymbol< decltype(impact_Webserver      )
>("impact_Webserver"               );
00371     Webserver_Stop              = m_lib.GetSymbol< decltype(impact_Webserver_Stop  )
>("impact_Webserver_Stop"          );
00372     Webserver_Status            = m_lib.GetSymbol< decltype(impact_Webserver_Status )
>("impact_Webserver_Status"        );
00373 #endif // IMPACT_HAS_WEBSERVER
00374
00375     // added 2023-03-22
00376     StereoToMono_Planar         = m_lib.GetSymbol< decltype(impact_StereoToMono_Planar )
>("impact_StereoToMono_Planar"     );
00377     MonoToStereo_Planar         = m_lib.GetSymbol< decltype(impact_MonoToStereo_Planar )
>("impact_MonoToStereo_Planar"     );
00378
00379     } catch (std::runtime_error& ) {
00380         return false;
00381     }
00382     // C functions allowed to be missing
00383     try {
00384         // added 2023-05-22
00385         SetMetadata              = m_lib.GetSymbol< decltype(impact_SetMetadata      )
>("impact_SetMetadata"            );
00386         GetMetadataInfos         = m_lib.GetSymbol< decltype(impact_GetMetadataInfos  )
>("impact_GetMetadataInfos"       );
00387         FreeMetadataInfos        = m_lib.GetSymbol< decltype(impact_FreeMetadataInfos )
>("impact_FreeMetadataInfos"      );
00388         // added 2023-06-20
00389         SetPresetManager         = m_lib.GetSymbol< decltype(impact_SetPresetManager )
>("impact_SetPresetManager"       );
00390         PresetManager_InformChange = m_lib.GetSymbol<
decltype(impact_PresetManager_InformChange ) >("impact_PresetManager_InformChange" );
00391
00392         // added 2023-09-21
00393         GetPossibleChunkSizeInFrames = m_lib.GetSymbol<
decltype(impact_GetPossibleChunkSizeInFrames ) >("impact_GetPossibleChunkSizeInFrames" );
00394         GetProcessChunkFrames     = m_lib.GetSymbol< decltype(impact_GetProcessChunkFrames )
>("impact_GetProcessChunkFrames" );
00395         InitProcess3              = m_lib.GetSymbol< decltype(impact_InitProcess3    )
>("impact_InitProcess3"           );
00396
00397 #if IMPACT_HAS_CLOUDBUS
00398         // added 2023-06-26
00399         NewBus                    = m_lib.GetSymbol< decltype(impact_NewBus          )
>("impact_NewBus"                 );
00400         FreeBus                   = m_lib.GetSymbol< decltype(impact_FreeBus         )
>("impact_FreeBus"                );
00401         SetInstanceBus            = m_lib.GetSymbol< decltype(impact_SetInstanceBus  )
>("impact_SetInstanceBus"         );
00402 #endif // IMPACT_HAS_CLOUDBUS
00403     } catch (std::runtime_error& ) {
00404         // Ignored, handler will take care
00405     }
00406
00407     m_bOK=true;
00408     return true;
00409 }
00410 bool IsOk() const {
00411     return m_bOK;
00412 }
00413
00414 };
00415
00416 static constexpr const char *process_name = "SOUND4 IMPACT.CL";
00417 static constexpr const char *process_shortcode = "impact";
00418 using SampleFormat = impact_SampleFormat;
00419 const size_t ChunkFrames=IMPACT_AUDIOFRAME_COUNT;
00420 const size_t InputChannels=IMPACT_CHANNEL_COUNT*IMPACT_AUDIO_INPUT_COUNT;
00421 const size_t OutputChannels=IMPACT_CHANNEL_COUNT*IMPACT_AUDIO_OUTPUT_COUNT;
00422 const size_t InputSampleSize=ChunkFrames*InputChannels;
00423 const size_t OutputSampleSize=ChunkFrames*OutputChannels;
00424 const size_t SampleRate=IMPACT_SAMPLE_RATE;

```

```

00451
00452 namespace helper {
00453     #ifdef _WIN32
00454         static inline std::string WStringToUTF8(const std::wstring& wstr) {
00455             if (wstr.empty()) return {};
00456             int size = WideCharToMultiByte(CP_UTF8, 0, &wstr[0], (int)wstr.size(), NULL, 0, NULL,
00457             NULL);
00458             std::string str(size, 0);
00459             WideCharToMultiByte(CP_UTF8, 0, &wstr[0], (int)wstr.size(), &str[0], size, NULL, NULL);
00460             return str;
00461         }
00462         static inline std::wstring UTF8ToWString(const std::string& str) {
00463             if (str.empty()) return std::wstring();
00464             int size = MultiByteToWideChar(CP_UTF8, 0, &str[0], (int)str.size(), NULL, 0);
00465             std::wstring wstr(size, 0);
00466             MultiByteToWideChar(CP_UTF8, 0, &str[0], (int)str.size(), &wstr[0], size);
00467             return wstr;
00468         }
00469     #endif // _WIN32
00470
00471     template<typename T>
00472     struct SampleFormat {
00473     };
00474     template<>
00475     struct SampleFormat<int16_t> {
00476         const impact_SampleFormat format = S16_NATIVE;
00477     };
00478     template<>
00479     struct SampleFormat<int32_t> {
00480         const impact_SampleFormat format = S32_NATIVE;
00481     };
00482     template<>
00483     struct SampleFormat<float> {
00484         const impact_SampleFormat format = F32_NATIVE;
00485     };
00486
00487     static inline void AudioConvertFrom(CDynLib& dynlib, const uint8_t *payload, float *output,
00488     size_t nSpl, impact_SampleFormat fmt) {
00489         dynlib.AudioConvertFrom(payload, output, nSpl, fmt);
00490     }
00491     static inline void AudioConvertTo(CDynLib& dynlib, const float *input, uint8_t *payload,
00492     size_t nSpl, impact_SampleFormat fmt) {
00493         dynlib.AudioConvertTo(input, payload, nSpl, fmt);
00494     }
00495     static inline void StereoToMono(CDynLib& dynlib, const float *input, float *output, size_t
00496     nSpl) {
00497         dynlib.StereoToMono(input, output, nSpl);
00498     }
00499     static inline void MonoToStereo(CDynLib& dynlib, const float *input, float *output, size_t
00500     nSpl) {
00501         dynlib.MonoToStereo(input, output, nSpl);
00502     }
00503     static inline void StereoToMono_Planar(CDynLib& dynlib, const float *inputL, const float
00504     *inputR, float *output, size_t nSpl) {
00505         dynlib.StereoToMono_Planar(inputL, inputR, output, nSpl);
00506     }
00507     static inline void MonoToStereo_Planar(CDynLib& dynlib, const float *input, float *outputL,
00508     float *outputR, size_t nSpl) {
00509         dynlib.MonoToStereo_Planar(input, outputL, outputR, nSpl);
00510     }
00511     static inline void AudioMonoFromLiveStereo(CDynLib& dynlib, const uint8_t *payload, float
00512     *output) {
00513         dynlib.AudioMonoFromLiveStereo(payload, output);
00514     }
00515     static inline void AudioMonoToLiveStereo(CDynLib& dynlib, const float *input, uint8_t
00516     *payload) {
00517         dynlib.AudioMonoToLiveStereo(input, payload);
00518     }
00519 }; // namespace helper
00520
00521 static inline std::string GetVersion(CDynLib& dynlib)
00522 {
00523     return std::string(dynlib.GetVersion());
00524 }
00525
00526 static inline unsigned int GetChunkSizeInFrames(CDynLib& dynlib)
00527 {
00528     return dynlib.GetChunkSizeInFrames();
00529 }
00530
00531 static inline std::vector<unsigned int> GetPossibleChunkSizeInFrames(CDynLib& dynlib)
00532 {
00533     std::vector<unsigned int> list;
00534     if (dynlib.GetPossibleChunkSizeInFrames) {
00535         for (unsigned int* src=dynlib.GetPossibleChunkSizeInFrames();*src;src++) {

```

```

00574         list.push_back(*src);
00575     }
00576     } else {
00577         list.push_back(64);
00578     }
00579     return list;
00580 }
00581
00582 static inline unsigned int GetChannelCount(CDynLib& dynlib)
00583 {
00584     return dynlib.GetChannelCount();
00585 }
00586
00587 static inline unsigned int GetAudioInputCount(CDynLib& dynlib)
00588 {
00589     return dynlib.GetAudioInputCount();
00590 }
00591
00592 static inline unsigned int GetAudioOutputCount(CDynLib& dynlib)
00593 {
00594     return dynlib.GetAudioOutputCount();
00595 }
00596
00597 static inline unsigned int GetSampleRate(CDynLib& dynlib)
00598 {
00599     return dynlib.GetSampleRate();
00600 }
00601
00602 static inline void SanityCheck(CDynLib& dynlib, bool a_bCheckFrames = true)
00603 {
00604     // Do some sanity checks
00605     if (dynlib.GetSampleRate() != IMPACT_SAMPLE_RATE) {
00606         throw std::runtime_error("Bad library sampling rate");
00607     }
00608     if (a_bCheckFrames && dynlib.GetChunkSizeInFrames() != ChunkFrames) {
00609         throw std::runtime_error("Bad library frame size");
00610     }
00611     if (dynlib.GetChannelCount() != IMPACT_CHANNEL_COUNT) {
00612         throw std::runtime_error("Bad library channel count");
00613     }
00614     if (dynlib.GetAudioInputCount() != IMPACT_AUDIO_INPUT_COUNT) {
00615         throw std::runtime_error("Bad library input count");
00616     }
00617     if (dynlib.GetAudioOutputCount() != IMPACT_AUDIO_OUTPUT_COUNT) {
00618         throw std::runtime_error("Bad library output count");
00619     }
00620 }
00621
00622 static inline std::string GetFormatName(CDynLib& dynlib, const SampleFormat fmt)
00623 {
00624     return std::string(dynlib.GetFormatName(fmt));
00625 }
00626
00627 static inline SampleFormat GetFormatFromName(CDynLib& dynlib, const std::string& name)
00628 {
00629     return dynlib.GetFormatFromName(name.c_str());
00630 }
00631
00632 static inline unsigned int GetBytesFromFormat(CDynLib& dynlib, const SampleFormat fmt)
00633 {
00634     return dynlib.GetBytesFromFormat(fmt);
00635 }
00636
00637 using LogSeverity = impact_LogSeverity;
00638 using log_cb_t = std::function<void(LogSeverity, const std::string&)>;
00639
00640 static log_cb_t _log_cb;
00641 extern "C" {
00642     static inline void _log_cb_c(impact_LogSeverity severity, const char *c_msg) {
00643         _log_cb(severity, std::string(c_msg));
00644     }
00645 }
00646
00647 static inline void SetLogSeverity(CDynLib& dynlib, LogSeverity severity)
00648 {
00649     dynlib.SetLogSeverity(severity);
00650 }
00651
00652 static inline void SetLoggerCallback(CDynLib& dynlib, log_cb_t cb)
00653 {
00654     _log_cb=cb;
00655     dynlib.SetLoggerCallback(&_log_cb_c);
00656 }
00657
00658 #if IMPACT_HAS_CLOUDBUS
00659 class CBus {
00660 public:
00661     CBus(CDynLib& dynlib)
00662         : m_dynlib(dynlib)
00663 
```

```

00729         {
00730             if (m_dynlib.NewBus) {
00731                 m_bus=m_dynlib.NewBus();
00732             }
00733         }
00734     ~CBus()
00735     {
00736         if (m_bus && m_dynlib.FreeBus) {
00737             m_dynlib.FreeBus(m_bus);
00738         }
00739         m_bus = nullptr;
00740     }
00741     impact_CBus *Get() const { return m_bus; }
00742 private:
00743     CDynLib& m_dynlib;
00744     impact_CBus *m_bus;
00745 };
00746 #endif // IMPACT_HAS_CLOUDBUS
00747
00752     class CPresetLoader {
00753     public:
00754         CPresetLoader() = default;
00755         virtual ~CPreSetLoader() = default;
00756
00757         virtual bool IsReadOnly() = 0;
00758         virtual bool Exists(const std::filesystem::path &name) = 0;
00759         virtual bool Remove(const std::filesystem::path &name) = 0;
00760         virtual bool Rename(const std::filesystem::path &from, const std::filesystem::path &to) = 0;
00761         virtual std::vector<std::filesystem::path> GetAll() = 0;
00762         virtual std::string Read(const std::filesystem::path &filename) = 0;
00763         virtual bool Write(const std::filesystem::path &filename, const std::string &content) = 0;
00764     };
00765     using PresetChange_Kind = impact_PresetChange_Kind;
00766
00770     class CInstance {
00771     public:
00772         CInstance(CDynLib& dynlib)
00773         : m_dynlib(dynlib)
00774         {
00775             params = m_dynlib.NewParameters();
00776             if (!params) throw std::bad_alloc();
00777         }
00778         // non-copyable
00779         CInstance( const CInstance& ) = delete;
00780         CInstance& operator=( const CInstance& ) = delete;
00781         ~CInstance()
00782         {
00783             Stop();
00784             if (params) m_dynlib.FreeParameters(params);
00785         }
00786     bool IsOk() const { return instance!=nullptr; }
00787     void SetParam(const std::string& name, const std::string& value)
00788     {
00789         assert(params);
00790         m_dynlib.SetParameter(params, name.c_str(), value.c_str());
00791     }
00792     std::string GetParam(const std::string& name)
00793     {
00794         assert(params);
00795         auto c_value=m_dynlib.GetParameter(params, name.c_str());
00796         std::string ret(c_value);
00797         m_dynlib.FreeParameterValue(c_value);
00798         return ret;
00799     }
00800 #if IMPACT_HAS_CLOUDBUS
00801     void SetBus(const CBus& bus) {
00802         assert(params);
00803         if (m_dynlib.SetInstanceBus) {
00804             m_dynlib.SetInstanceBus(params,bus.Get());
00805         }
00806     }
00807 #endif // IMPACT_HAS_CLOUDBUS
00808
00809     void SetPresetManager(CPresetLoader *preset_manager)
00810     {
00811         if (!preset_manager) return;
00812         if (!m_dynlib.SetPresetManager) return;
00813         assert(params);
00814         m_dynlib.SetPresetManager(params,
00815             impact_custom_reader,
00816             impact_custom_reader_free,
00817             impact_custom_writer,
00818             impact_custom_exists,
00819             impact_custom_getall,
00820             impact_custom_getall_free,
00821             impact_custom_remove,
00822             impact_custom_rename,

```

```

00856         preset_manager->IsReadOnly(),
00857         preset_manager
00858     );
00859 }
00860
00875 bool Create(const std::string& LoginKey, const std::string& RadioName, const std::string&
AWS_Access_ID, const std::string& AWS_Access_Secret, const std::filesystem::path& save_path, int
json_port = 0, unsigned int frames_per_chunk=64)
00876 {
00877     assert(!instance);
00878     std::string l_save_path;
00879     if (!save_path.empty()) {
00880         l_save_path = save_path.u8string();
00881     }
00882     if (m_dynlib.InitProcess3) {
00883         instance = m_dynlib.InitProcess3(LoginKey.c_str(), RadioName.c_str(),
AWS_Access_ID.c_str(), AWS_Access_Secret.c_str(), l_save_path.c_str(), params, frames_per_chunk);
00884     } else if (frames_per_chunk!=64) {
00885         return false;
00886     } else {
00887         instance = m_dynlib.InitProcess2(LoginKey.c_str(), RadioName.c_str(),
AWS_Access_ID.c_str(), AWS_Access_Secret.c_str(), l_save_path.c_str(), params);
00888     }
00889     if (!instance) return false;
00890     if (!init_metadata.empty()) {
00891         for (auto&& [key,value]: init_metadata) {
00892             m_dynlib.SetMetadata(instance, key.c_str(), value.c_str());
00893         }
00894         init_metadata.clear();
00895     }
00896     update_thread = std::thread([this, json_port]() {
00897         OnUpdateThreadStart();
00898         m_dynlib.StartUpdateThread(instance, json_port);
00899         OnUpdateThreadStop();
00900     });
00901     int timeout=5000;
00902     #ifdef DEBUG
00903         timeout=60*1000; // For debugger pauses
00904     #endif
00905     if (m_dynlib.WaitUpdateThreadReady(instance, timeout)<0) {
00906         return false;
00907     }
00908     return true;
00909 }
00910
00918 unsigned int GetChunkFrames() {
00919     if (instance && m_dynlib.GetProcessChunkFrames) {
00920         return m_dynlib.GetProcessChunkFrames(instance);
00921     }
00922     return 64;
00923 }
00924
00932 void PresetManager_InformChange(const std::filesystem::path& relative_path, PresetChange_Kind
change_kind)
00933 {
00934     if (m_dynlib.PresetManager_InformChange) {
00935         m_dynlib.PresetManager_InformChange(instance, relative_path.c_str(),
(im_preset_change_kind) change_kind);
00936     }
00937 }
00938
00950 void SetMetadata(const std::string& key, const char* value)
00951 {
00952     if (m_dynlib.SetMetadata) {
00953         if (instance) {
00954             m_dynlib.SetMetadata(instance, key.c_str(), value);
00955         } else {
00956             init_metadata.push_back( {key, value} );
00957         }
00958     }
00959 }
00960
00966 std::vector< std::tuple<std::string, std::string> > GetMetadataInfos()
00967 {
00968     std::vector< std::tuple<std::string, std::string> > values;
00969     if (m_dynlib.GetMetadataInfos) {
00970         const char** c_values = m_dynlib.GetMetadataInfos(instance);
00971         if (c_values) {
00972             for (const char** c_value=c_values; *c_value; ) {
00973                 std::string key(*c_value);
00974                 c_value++;
00975                 if (*c_value) {
00976                     std::string descr(*c_value);
00977                     c_value++;
00978                     values.push_back( {key, descr} );
00979                 }
00980             }
00981         }
00982     }
00983 }

```

```

00981         m_dynlib.FreeMetadataInfos(instance, c_values);
00982     }
00983 }
00984     return values;
00985 }
00986
00987 // Can be overloaded, called at start of UpdateThread in the thread
00988 virtual void OnUpdateThreadStart() {}
00989 // Can be overloaded to call at end of UpdateThread in the thread
00990 virtual void OnUpdateThreadStop() {}
00991
00992 #if IMPACT_HAS_WEBSERVER
00993 bool StartWebServer(int http_port, int https_port=0)
00994 {
01000     assert(instance);
01001     assert(webserver==SOUND4_INVALID_WEBSERVER_ID);
01002     webserver = m_dynlib.Webserver(http_port,https_port,instance);
01003     if (webserver==SOUND4_INVALID_WEBSERVER_ID) {
01004         return false;
01005     }
01006     int web_status=m_dynlib.Webserver_Status(webserver);
01007     if (http_port && (web_status & SOUND4_WEBSERVER_HTTP_OK) == 0) {
01008         return false;
01009     }
01010     if (https_port && (web_status & SOUND4_WEBSERVER_HTTPS_OK) == 0) {
01011         return false;
01012     }
01013     return true;
01014 }
01020 void StopWebServer()
01021 {
01022     if (webserver != SOUND4_INVALID_WEBSERVER_ID) {
01023         m_dynlib.Webserver_Stop(webserver, 1000);
01024         webserver = SOUND4_INVALID_WEBSERVER_ID;
01025     }
01026 }
01027 #endif // IMPACT_HAS_WEBSERVER
01028
01035 int Terminate()
01036 {
01037     if (!instance) return 0;
01038     return m_dynlib.TerminateProcess(instance);
01039 }
01040
01046 void Stop()
01047 {
01048     if (!instance) return;
01049 #if IMPACT_HAS_WEBSERVER
01050     StopWebServer();
01051 #endif // IMPACT_HAS_WEBSERVER
01052     if (update_thread.joinable()) {
01053         m_dynlib.StopUpdateThread(instance); // this will exit the update thread
01054         update_thread.join();
01055     }
01056     m_dynlib.ExitProcess(instance);
01057     instance=nullptr;
01058 }
01059
01065 unsigned int GetEstimatedDelay()
01066 {
01067     assert(instance);
01068     return m_dynlib.GetEstimatedDelay(instance);
01069 }
01070
01081 std::array<float,InputSampleSize>& GetBufferIn()
01082 {
01083     assert(instance);
01084     float *buf=m_dynlib.GetBufferIn(instance);
01085     return reinterpret_cast< std::array<float,InputSampleSize>& >(*buf);
01086 }
01087
01098 std::array<float,OutputSampleSize>& GetBufferOut()
01099 {
01100     assert(instance);
01101     float *buf= m_dynlib.GetBufferOut(instance);
01102     return reinterpret_cast< std::array<float,OutputSampleSize>& >(*buf);
01103 }
01109 void ProcessAudio()
01110 {
01111     assert(instance);
01112     m_dynlib.ProcessAudio(instance, m_dynlib.GetBufferIn(instance),
01113         m_dynlib.GetBufferOut(instance));
01114 }
01127 // void ProcessAudio_Planar(const std::array< const std::array<const float,ChunkFrames>,
01128 // InputChannels>& input, std::array< std::array<float,ChunkFrames>, OutputChannels>& output)
01129 void ProcessAudio_Planar(float const * const *input, float * const *output)
01129 {

```

```

01130         assert(instance);
01131         m_dynlib.ProcessAudio_Planar(instance, input, output);
01132     }
01133
01134     template<typename T>
01146     std::vector<T> ProcessAnyAudio(const std::vector<T> input)
01147     {
01148         assert(instance);
01149         std::vector<T> output;
01150         unsigned int out_offset=0;
01151         unsigned int in_offset=0;
01152         unsigned int todo = input.size();
01153         while (todo>0) {
01154             unsigned int left = AddAudio(&input[in_offset], todo);
01155             unsigned int out_avail = m_dynlib.GetOutputCount(instance);
01156             output.resize(out_offset + out_avail);
01157             GetAudio(&output[out_offset], out_avail);
01158             out_offset+=out_avail;
01159             in_offset += todo-left;
01160             todo=left;
01161         }
01162         return output;
01163     }
01164
01170     class CClient {
01171     public:
01172         CClient(impact_CInstance* instance, CDynLib& dynlib)
01173             : m_dynlib(dynlib)
01174         {
01175             assert(instance);
01176             client=m_dynlib.NewClient(instance);
01177             if (!client) throw std::bad_alloc();
01178         }
01179         // non-copyable
01180         CClient( const CInstance& ) = delete;
01181         CClient& operator=( const CInstance& ) = delete;
01182         ~CClient()
01183         {
01184             if (client) {
01185                 m_dynlib.DeleteClient(client);
01186                 client=nullptr;
01187             }
01188         }
01196         std::string ProcessJson(const std::string &request, bool *NeedSave = nullptr)
01197         {
01198             assert(client);
01199             int need_save=0;
01200             const char *canswer = m_dynlib.ProcessJson(client, request.c_str(),
&need_save);
01201
01202             if (!canswer) return {};
01203             std::string answer(canswer);
01204             m_dynlib.FreeJsonAnswer(canswer);
01205             if (NeedSave) {
01206                 *NeedSave=(need_save!=0);
01207             }
01208             return answer;
01209         }
01210     private:
01211         CDynLib& m_dynlib;
01212         impact_CClientInstance *client = nullptr;
01213     };
01220     std::shared_ptr<CClient> NewClient()
01221     {
01222         assert(instance);
01223         return std::make_shared<CClient>(instance, m_dynlib);
01224     }
01225
01226     protected:
01227         template<typename T>
01228         unsigned int AddAudio(const T* payload, unsigned int nFrame)
01229         {
01230             assert(instance);
01231             return m_dynlib.AddAudio(instance, reinterpret_cast<const T*>(payload), nFrame,
helper::SampleFormat<T>::format);
01232         }
01233         template<typename T>
01234         unsigned int GetAudio(T* payload, unsigned int max_nFrame)
01235         {
01236             assert(instance);
01237             return m_dynlib.GetAudio(instance, reinterpret_cast<T*>(payload), max_nFrame,
helper::SampleFormat<T>::format);
01238         }
01239     private:
01240         CDynLib& m_dynlib;
01241         impact_CParameters* params = nullptr;
01242         impact_CInstance* instance = nullptr;
01243     };

```

```

01244         std::thread update_thread;
01245         std::vector< std::pair<std::string, std::string> > init_metadata;
01246 #if IMPACT_HAS_WEBSERVER
01247         uint64_t webserver = SOUND4_INVALID_WEBSERVER_ID;
01248 #endif // IMPACT_HAS_WEBSERVER
01249     };
01250
01251 }; // namespace dyn
01252 }; // namespace impact
01253 }; // namespace sound4
01254
01255
01256 // bridge C callbacks to CPresetLoader
01257 extern "C" {
01258     static char *impact_custom_reader(const fs_char *filename, void* userdata) {
01259         sound4::impact::dyn::CPresetLoader
01260 *preset_loader=reinterpret_cast<sound4::impact::dyn::CPresetLoader*>(userdata);
01261         std::string content=preset_loader->Read(filename);
01262         return strdup(content.c_str());
01263     }
01264     static void impact_custom_reader_free(char *content, void* userdata) {
01265         if (!content) return;
01266         free(content);
01267     }
01268     static int impact_custom_writer(const fs_char *filename, const char *content, void* userdata) {
01269         sound4::impact::dyn::CPresetLoader
01270 *preset_loader=reinterpret_cast<sound4::impact::dyn::CPresetLoader*>(userdata);
01271         auto res=preset_loader->Write(filename, content);
01272         return res?0:-1;
01273     }
01274     static int impact_custom_exists(const fs_char *filename, void* userdata) {
01275         sound4::impact::dyn::CPresetLoader
01276 *preset_loader=reinterpret_cast<sound4::impact::dyn::CPresetLoader*>(userdata);
01277         auto res=preset_loader->Exists(filename);
01278         return res?0:-1;
01279     }
01280     static fs_char** impact_custom_getall(void* userdata) {
01281         sound4::impact::dyn::CPresetLoader
01282 *preset_loader=reinterpret_cast<sound4::impact::dyn::CPresetLoader*>(userdata);
01283         auto res=preset_loader->GetAll();
01284         fs_char**all=(fs_char**)malloc((res.size()+1)*sizeof(const fs_char*));
01285         for (size_t n=0;n<res.size();n++) {
01286             all[n]=fs_strdup(res[n].c_str());
01287         }
01288         all[res.size()]=nullptr;
01289         return all;
01290     }
01291     static void impact_custom_getall_free(fs_char** all, void* userdata) {
01292         if (!all) return;
01293         for (fs_char** one=all;*one;one++) {
01294             free(*one);
01295         }
01296         free(all);
01297     }
01298     static int impact_custom_remove(const fs_char *filename, void* userdata) {
01299         sound4::impact::dyn::CPresetLoader
01300 *preset_loader=reinterpret_cast<sound4::impact::dyn::CPresetLoader*>(userdata);
01301         auto res=preset_loader->Remove(filename);
01302         return res?0:-1;
01303     }
01304     static int impact_custom_rename(const fs_char *from, const fs_char *to, void* userdata) {
01305         sound4::impact::dyn::CPresetLoader
01306 *preset_loader=reinterpret_cast<sound4::impact::dyn::CPresetLoader*>(userdata);
01307         auto res=preset_loader->Rename(from, to);
01308         return res?0:-1;
01309     }
01310 }
01311 };

```

Index

- ~CClient
 - sound4::impact::CInstance::CClient, [76](#)
 - sound4::impact::dyn::CInstance::CClient, [78](#)
- ~CDynLoader
 - sound4::impact::dyn::helper::CDynLoader, [92](#)
- ~CInstance
 - sound4::impact::CInstance, [96](#)
 - sound4::impact::dyn::CInstance, [106](#)
- ~CPresetLoader
 - sound4::impact::CPresetLoader, [115](#)
 - sound4::impact::dyn::CPresetLoader, [117](#)
- ~MyPresetManager
 - MyPresetManager, [122](#)
- AddAudio
 - sound4::impact::CInstance, [96](#)
 - sound4::impact::dyn::CDynLib, [81](#)
 - sound4::impact::dyn::CInstance, [106](#)
- AddPadAudio
 - sound4::impact::dyn::CDynLib, [81](#)
- Audio convert helpers, [46](#)
 - impact_AudioConvertFrom, [46](#)
 - impact_AudioConvertTo, [47](#)
 - impact_AudioMonoFromLiveStereo, [47](#)
 - impact_AudioMonoToLiveStereo, [48](#)
 - impact_MonoToStereo, [48](#)
 - impact_MonoToStereo_Planar, [48](#)
 - impact_StereoToMono, [49](#)
 - impact_StereoToMono_Planar, [49](#)
- Audio managing (any audio), [41](#)
 - F32_BE, [42](#)
 - F32_LE, [42](#)
 - F32_NATIVE, [42](#)
 - impact_AddAudio, [42](#)
 - impact_AddPadAudio, [42](#)
 - impact_GetAudio, [43](#)
 - impact_GetBytesFromFormat, [43](#)
 - impact_GetFormatFromName, [44](#)
 - impact_GetFormatName, [44](#)
 - impact_GetMaxPacketFrame, [44](#)
 - impact_GetOutputCount, [46](#)
 - impact_SampleFormat, [41](#)
 - INVALID_FORMAT, [42](#)
 - S16_BE, [42](#)
 - S16_LE, [42](#)
 - S16_NATIVE, [42](#)
 - S24_BE, [42](#)
 - S24_LE, [42](#)
 - S24_NATIVE, [42](#)
 - S32_BE, [42](#)
 - S32_LE, [42](#)
 - S32_NATIVE, [42](#)
- AudioConvertFrom
 - sound4::impact::dyn::CDynLib, [81](#)
- AudioConvertTo
 - sound4::impact::dyn::CDynLib, [82](#)
- AudioMonoFromLiveStereo
 - sound4::impact::dyn::CDynLib, [82](#)
- AudioMonoToLiveStereo
 - sound4::impact::dyn::CDynLib, [82](#)
- CClient
 - sound4::impact::CInstance::CClient, [75](#)
 - sound4::impact::dyn::CInstance::CClient, [77](#)
- CDynLib
 - sound4::impact::dyn::CDynLib, [80](#)
- CDynLoader
 - sound4::impact::dyn::helper::CDynLoader, [92](#)
- change_kind_created
 - Custom preset managagement, [34](#)
- change_kind_deleted
 - Custom preset managagement, [34](#)
- change_kind_modified
 - Custom preset managagement, [34](#)
- CHANNEL_COUNT
 - sound4.impact.cl-pipe.cpp, [138](#)
- CHUNK_SIZE
 - sound4.impact.cl-pipe.cpp, [139](#)
- ChunkFrames
 - sound4::impact, [69](#)
 - sound4::impact::dyn, [72](#)
- CInstance
 - sound4::impact::CInstance, [95](#), [96](#)
 - sound4::impact::dyn::CInstance, [105](#), [106](#)
- Client's JSON config interfacing, [50](#)
 - impact_DeleteClient, [50](#)
 - impact_FreeJsonAnswer, [51](#)
 - impact_NewClient, [51](#)
 - impact_ProcessJson, [51](#)
 - impact_SaveState, [52](#)
- Close
 - sound4::impact::dyn::helper::CDynLoader, [92](#)
- CPresetLoader
 - sound4::impact::CPresetLoader, [115](#)
 - sound4::impact::dyn::CPresetLoader, [117](#)
- Create
 - sound4::impact::CInstance, [96](#)
 - sound4::impact::dyn::CInstance, [106](#)
- Custom preset managagement, [29](#)
 - change_kind_created, [34](#)

- change_kind_deleted, [34](#)
- change_kind_modified, [34](#)
- fs_char, [30](#)
- impact_PresetChange_Kind, [33](#)
- impact_PresetManager_InformChange, [34](#)
- impact_SetPresetManager, [34](#)
- impact_storage_exists, [30](#)
- impact_storage_getall, [31](#)
- impact_storage_getall_free, [31](#)
- impact_storage_reader, [31](#)
- impact_storage_reader_free, [32](#)
- impact_storage_remove, [32](#)
- impact_storage_rename, [32](#)
- impact_storage_writer, [33](#)
- DeleteClient
 - sound4::impact::dyn::CDynLib, [82](#)
- Direct processing, [38](#)
 - impact_GetBufferIn, [38](#)
 - impact_GetBufferOut, [39](#)
 - impact_GetEstimatedDelay, [39](#)
 - impact_ProcessAudio, [39](#)
 - impact_ProcessAudio_Planar, [40](#)
- dyn, [67](#)
- DynFunc_t
 - sound4::impact::dyn::helper, [73](#)
- DynFuncHolder
 - sound4::impact::dyn::helper::DynFuncHolder< T >, [119](#)
- DynLib_t
 - sound4::impact::dyn::helper, [73](#)
- Environment variables and parameters, [17](#)
- error
 - Global setup, [21](#)
- Exists
 - MyPresetManager, [122](#)
 - sound4::impact::CPresetLoader, [115](#)
 - sound4::impact::dyn::CPresetLoader, [117](#)
- ExitProcess
 - sound4::impact::dyn::CDynLib, [82](#)
- F32_BE
 - Audio managing (any audio), [42](#)
- F32_LE
 - Audio managing (any audio), [42](#)
- F32_NATIVE
 - Audio managing (any audio), [42](#)
- fatal
 - Global setup, [21](#)
- format
 - sound4::impact::dyn::helper::SampleFormat< float >, [125](#)
 - sound4::impact::dyn::helper::SampleFormat< int16_t >, [126](#)
 - sound4::impact::dyn::helper::SampleFormat< int32_t >, [128](#)
 - sound4::impact::helper::SampleFormat< float >, [126](#)
 - sound4::impact::helper::SampleFormat< int16_t >, [127](#)
 - sound4::impact::helper::SampleFormat< int32_t >, [128](#)
- FreeJsonAnswer
 - sound4::impact::dyn::CDynLib, [82](#)
- FreeMetadataInfos
 - sound4::impact::dyn::CDynLib, [83](#)
- FreeParameters
 - sound4::impact::dyn::CDynLib, [83](#)
- FreeParameterValue
 - sound4::impact::dyn::CDynLib, [83](#)
- fs_char
 - Custom preset managagement, [30](#)
- fs_strdup
 - sound4.impact.cl.hpp, [151](#)
 - sound4.impact.cl_dyn.hpp, [160](#)
- GetAll
 - MyPresetManager, [122](#)
 - sound4::impact::CPresetLoader, [115](#)
 - sound4::impact::dyn::CPresetLoader, [117](#)
- GetAudio
 - sound4::impact::CInstance, [97](#)
 - sound4::impact::dyn::CDynLib, [83](#)
 - sound4::impact::dyn::CInstance, [107](#)
- GetAudioInputCount
 - sound4::impact::dyn::CDynLib, [83](#)
- GetAudioOutputCount
 - sound4::impact::dyn::CDynLib, [83](#)
- GetBufferIn
 - sound4::impact::CInstance, [97](#)
 - sound4::impact::dyn::CDynLib, [84](#)
 - sound4::impact::dyn::CInstance, [107](#)
- GetBufferOut
 - sound4::impact::CInstance, [97](#)
 - sound4::impact::dyn::CDynLib, [84](#)
 - sound4::impact::dyn::CInstance, [107](#)
- GetBytesFromFormat
 - sound4::impact::dyn::CDynLib, [84](#)
- GetChannelCount
 - sound4::impact::dyn::CDynLib, [84](#)
- GetChunkFrames
 - sound4::impact::CInstance, [98](#)
 - sound4::impact::dyn::CInstance, [108](#)
- GetChunkSizeInFrames
 - sound4::impact::dyn::CDynLib, [84](#)
- GetEnv
 - sound4.impact.cl-pipe-cxx.cpp, [129](#)
 - sound4.impact.cl-pipe-dyn.cpp, [133](#)
- GetEstimatedDelay
 - sound4::impact::CInstance, [98](#)
 - sound4::impact::dyn::CDynLib, [84](#)
 - sound4::impact::dyn::CInstance, [108](#)
- GetFormatFromName
 - sound4::impact::dyn::CDynLib, [85](#)
- GetFormatName
 - sound4::impact::dyn::CDynLib, [85](#)
- GetMaxPacketFrame

- sound4::impact::dyn::CDynLib, 85
- GetMetadataInfos
 - sound4::impact::CInstance, 98
 - sound4::impact::dyn::CDynLib, 85
 - sound4::impact::dyn::CInstance, 108
- GetOutputCount
 - sound4::impact::dyn::CDynLib, 85
- GetParam
 - sound4::impact::CInstance, 99
 - sound4::impact::dyn::CInstance, 109
- GetParameter
 - sound4::impact::dyn::CDynLib, 85
- GetPossibleChunkSizeInFrames
 - sound4::impact::dyn::CDynLib, 86
- GetProcessChunkFrames
 - sound4::impact::dyn::CDynLib, 86
- GetSampleRate
 - sound4::impact::dyn::CDynLib, 86
- GetSymbol
 - sound4::impact::dyn::helper::CDynLoader, 93
- GetSymbol_safe
 - sound4::impact::dyn::helper::CDynLoader, 93
- GetThisLibraryPath
 - sound4::impact::dyn::helper::CDynLoader, 93
- GetVersion
 - sound4::impact::dyn::CDynLib, 86
- Global setup, 18
 - error, 21
 - fatal, 21
 - IMPACT_AUDIO_INPUT_COUNT, 19
 - IMPACT_AUDIO_OUTPUT_COUNT, 19
 - IMPACT_AUDIOFRAME_COUNT, 19
 - IMPACT_CHANNEL_COUNT, 19
 - impact_GetAudioInputCount, 21
 - impact_GetAudioOutputCount, 21
 - impact_GetChannelCount, 21
 - impact_GetChunkSizeInFrames, 22
 - impact_GetPossibleChunkSizeInFrames, 22
 - impact_GetSampleRate, 22
 - impact_GetVersion, 23
 - impact_loggerfn, 20
 - impact_LogSeverity, 20
 - IMPACT_SAMPLE_RATE, 20
 - impact_SetLoggerCallback, 23
 - impact_SetLogSeverity, 23
 - info, 21
 - none, 21
 - verbose, 21
 - verbose2, 21
 - verbose3, 21
 - verbose4, 21
 - verbose5, 21
 - warning, 21
- impact_AddAudio
 - Audio managing (any audio), 42
- impact_AddPadAudio
 - Audio managing (any audio), 42
- IMPACT_AUDIO_INPUT_COUNT
 - Global setup, 19
- IMPACT_AUDIO_OUTPUT_COUNT
 - Global setup, 19
- impact_AudioConvertFrom
 - Audio convert helpers, 46
- impact_AudioConvertTo
 - Audio convert helpers, 47
- IMPACT_AUDIOFRAME_COUNT
 - Global setup, 19
- impact_AudioMonoFromLiveStereo
 - Audio convert helpers, 47
- impact_AudioMonoToLiveStereo
 - Audio convert helpers, 48
- impact_CClientInstance, 120
- IMPACT_CHANNEL_COUNT
 - Global setup, 19
- impact_CInstance, 121
- impact_CParameters, 121
- IMPACT_DECL
 - sound4.impact.cl.h, 146
- impact_DeleteClient
 - Client's JSON config interfacing, 50
- impact_ExitProcess
 - Process creation/destruction, 24
- impact_FreeJsonAnswer
 - Client's JSON config interfacing, 51
- impact_FreeMetadataInfos
 - Metadata Management, 35
- impact_FreeParameters
 - Process creation/destruction, 25
- impact_FreeParameterValue
 - Process creation/destruction, 25
- impact_GetAudio
 - Audio managing (any audio), 43
- impact_GetAudioInputCount
 - Global setup, 21
- impact_GetAudioOutputCount
 - Global setup, 21
- impact_GetBufferIn
 - Direct processing, 38
- impact_GetBufferOut
 - Direct processing, 39
- impact_GetBytesFromFormat
 - Audio managing (any audio), 43
- impact_GetChannelCount
 - Global setup, 21
- impact_GetChunkSizeInFrames
 - Global setup, 22
- impact_GetEstimatedDelay
 - Direct processing, 39
- impact_GetFormatFromName
 - Audio managing (any audio), 44
- impact_GetFormatName
 - Audio managing (any audio), 44
- impact_GetMaxPacketFrame
 - Audio managing (any audio), 44
- impact_GetMetadataInfos
 - Metadata Management, 35

- impact_GetOutputCount
 - Audio managing (any audio), [46](#)
- impact_GetParameter
 - Process creation/destruction, [25](#)
- impact_GetPossibleChunkSizeInFrames
 - Global setup, [22](#)
- impact_GetProcessChunkFrames
 - Process creation/destruction, [25](#)
- impact_GetSampleRate
 - Global setup, [22](#)
- impact_GetVersion
 - Global setup, [23](#)
- IMPACT_HAS_CLOUDBUS
 - sound4.impact.cl.h, [146](#)
- IMPACT_HAS_WEBSERVER
 - sound4.impact.cl.h, [146](#)
- impact_InitProcess
 - Process creation/destruction, [26](#)
- impact_InitProcess2
 - Process creation/destruction, [26](#)
- impact_InitProcess3
 - Process creation/destruction, [26](#)
- impact_loggerfn
 - Global setup, [20](#)
- impact_LogSeverity
 - Global setup, [20](#)
- impact_MonoToStereo
 - Audio convert helpers, [48](#)
- impact_MonoToStereo_Planar
 - Audio convert helpers, [48](#)
- impact_NewClient
 - Client's JSON config interfacing, [51](#)
- impact_NewParameters
 - Process creation/destruction, [28](#)
- impact_PresetChange_Kind
 - Custom preset management, [33](#)
- impact_PresetManager_InformChange
 - Custom preset management, [34](#)
- impact_ProcessAudio
 - Direct processing, [39](#)
- impact_ProcessAudio_Planar
 - Direct processing, [40](#)
- impact_ProcessJson
 - Client's JSON config interfacing, [51](#)
- IMPACT_SAMPLE_RATE
 - Global setup, [20](#)
- impact_SampleFormat
 - Audio managing (any audio), [41](#)
- impact_SaveState
 - Client's JSON config interfacing, [52](#)
- impact_SetLoggerCallback
 - Global setup, [23](#)
- impact_SetLogSeverity
 - Global setup, [23](#)
- impact_SetMetadata
 - Metadata Management, [36](#)
- impact_SetParameter
 - Process creation/destruction, [28](#)
- impact_SetPresetManager
 - Custom preset management, [34](#)
- impact_StartUpdateThread
 - Update Management, [37](#)
- impact_StereoToMono
 - Audio convert helpers, [49](#)
- impact_StereoToMono_Planar
 - Audio convert helpers, [49](#)
- impact_StopUpdateThread
 - Update Management, [37](#)
- impact_storage_exists
 - Custom preset management, [30](#)
- impact_storage_getall
 - Custom preset management, [31](#)
- impact_storage_getall_free
 - Custom preset management, [31](#)
- impact_storage_reader
 - Custom preset management, [31](#)
- impact_storage_reader_free
 - Custom preset management, [32](#)
- impact_storage_remove
 - Custom preset management, [32](#)
- impact_storage_rename
 - Custom preset management, [32](#)
- impact_storage_writer
 - Custom preset management, [33](#)
- impact_TerminateProcess
 - Process creation/destruction, [28](#)
- impact_WaitUpdateThreadReady
 - Update Management, [37](#)
- impact_Webserver
 - Web server, [60](#)
- impact_Webserver_Status
 - Web server, [61](#)
- impact_Webserver_Stop
 - Web server, [61](#)
- impact_Webserver_tcp
 - Web server, [62](#)
- impact_Webserver_tcp2
 - Web server, [62](#)
- info
 - Global setup, [21](#)
- InitProcess
 - sound4::impact::dyn::CDynLib, [86](#)
- InitProcess2
 - sound4::impact::dyn::CDynLib, [86](#)
- InitProcess3
 - sound4::impact::dyn::CDynLib, [87](#)
- InputChannels
 - sound4::impact, [69](#)
 - sound4::impact::dyn, [72](#)
- InputSampleSize
 - sound4::impact, [69](#)
 - sound4::impact::dyn, [72](#)
- INVALID_FORMAT
 - Audio managing (any audio), [42](#)
- IsOk
 - sound4::impact::CInstance, [99](#)

- sound4::impact::dyn::CDynLib, 80
 - sound4::impact::dyn::CInstance, 109
 - sound4::impact::dyn::helper::CDynLoader, 93
 - sound4::impact::dyn::helper::DynFuncHolder< T >, 120
- IsReadOnly
 - MyPresetManager, 122
 - sound4::impact::CPresetLoader, 115
 - sound4::impact::dyn::CPresetLoader, 117
- JSON syntax, 52
- JSON syntax for internal setup, 55
- Load
 - sound4::impact::dyn::CDynLib, 81
 - sound4::impact::dyn::helper::CDynLoader, 93
- log_cb_t
 - sound4::impact, 68
 - sound4::impact::dyn, 71
- LogSeverity
 - sound4::impact, 68
 - sound4::impact::dyn, 71
- main
 - sound4.impact.cl-pipe-cxx.cpp, 129
 - sound4.impact.cl-pipe-dyn.cpp, 133
 - sound4.impact.cl-pipe.cpp, 139
- Metadata Management, 35
 - impact_FreeMetadataInfos, 35
 - impact_GetMetadataInfos, 35
 - impact_SetMetadata, 36
- MonoToStereo
 - sound4::impact::dyn::CDynLib, 87
- MonoToStereo_Planar
 - sound4::impact::dyn::CDynLib, 87
- MyLogger
 - sound4.impact.cl-pipe-cxx.cpp, 130
 - sound4.impact.cl-pipe-dyn.cpp, 134
 - sound4.impact.cl-pipe.cpp, 139
- MyPresetManager, 121
 - ~MyPresetManager, 122
 - Exists, 122
 - GetAll, 122
 - IsReadOnly, 122
 - MyPresetManager, 122
 - Read, 123
 - Remove, 123
 - Rename, 123
 - SetupPath, 123
 - Write, 123
- NewClient
 - sound4::impact::CInstance, 99
 - sound4::impact::dyn::CDynLib, 87
 - sound4::impact::dyn::CInstance, 109
- NewParameters
 - sound4::impact::dyn::CDynLib, 87
- none
 - Global setup, 21
- OnUpdateThreadStart
 - sound4::impact::CInstance, 99
 - sound4::impact::dyn::CInstance, 109
- OnUpdateThreadStop
 - sound4::impact::CInstance, 100
 - sound4::impact::dyn::CInstance, 110
- operator bool
 - sound4::impact::dyn::helper::CDynLoader, 94
 - sound4::impact::dyn::helper::DynFuncHolder< T >, 120
- operator T*
 - sound4::impact::dyn::helper::DynFuncHolder< T >, 120
- operator=
 - sound4::impact::CInstance, 100
 - sound4::impact::CInstance::CClient, 76
 - sound4::impact::dyn::CInstance, 110
 - sound4::impact::dyn::CInstance::CClient, 78
 - sound4::impact::dyn::helper::CDynLoader, 94
- OutputChannels
 - sound4::impact, 69
 - sound4::impact::dyn, 72
- OutputSampleSize
 - sound4::impact, 70
 - sound4::impact::dyn, 72
- PresetChange_Kind
 - sound4::impact, 68
 - sound4::impact::dyn, 71
- PresetManager_InformChange
 - sound4::impact::CInstance, 100
 - sound4::impact::dyn::CDynLib, 87
 - sound4::impact::dyn::CInstance, 110
- Process creation/destruction, 24
 - impact_ExitProcess, 24
 - impact_FreeParameters, 25
 - impact_FreeParameterValue, 25
 - impact_GetParameter, 25
 - impact_GetProcessChunkFrames, 25
 - impact_InitProcess, 26
 - impact_InitProcess2, 26
 - impact_InitProcess3, 26
 - impact_NewParameters, 28
 - impact_SetParameter, 28
 - impact_TerminateProcess, 28
- ProcessAnyAudio
 - sound4::impact::CInstance, 100
 - sound4::impact::dyn::CInstance, 110
- ProcessAudio
 - sound4::impact::CInstance, 101
 - sound4::impact::dyn::CDynLib, 88
 - sound4::impact::dyn::CInstance, 111
- ProcessAudio_Planar
 - sound4::impact::CInstance, 101
 - sound4::impact::dyn::CDynLib, 88
 - sound4::impact::dyn::CInstance, 111
- ProcessJson
 - sound4::impact::CInstance::CClient, 76
 - sound4::impact::dyn::CDynLib, 88

- sound4::impact::dyn::CInstance::CClient, 78
- ProcessLoop
 - sound4.impact.cl-pipe-cxx.cpp, 130
 - sound4.impact.cl-pipe-dyn.cpp, 134
 - sound4.impact.cl-pipe.cpp, 140
- Read
 - MyPresetManager, 123
 - sound4::impact::CPresetLoader, 115
 - sound4::impact::dyn::CPresetLoader, 118
- Remove
 - MyPresetManager, 123
 - sound4::impact::CPresetLoader, 116
 - sound4::impact::dyn::CPresetLoader, 118
- Rename
 - MyPresetManager, 123
 - sound4::impact::CPresetLoader, 116
 - sound4::impact::dyn::CPresetLoader, 118
- S16_BE
 - Audio managing (any audio), 42
- S16_LE
 - Audio managing (any audio), 42
- S16_NATIVE
 - Audio managing (any audio), 42
- S24_BE
 - Audio managing (any audio), 42
- S24_LE
 - Audio managing (any audio), 42
- S24_NATIVE
 - Audio managing (any audio), 42
- S32_BE
 - Audio managing (any audio), 42
- S32_LE
 - Audio managing (any audio), 42
- S32_NATIVE
 - Audio managing (any audio), 42
- Sample using C interface, 15
- Sample using C++ interface wrapper, 63
- Sample using C++ interface wrapper with dynamic library loading, 64
- SAMPLE_RATE
 - sound4.impact.cl-pipe.cpp, 139
- SampleFormat
 - sound4::impact, 69
 - sound4::impact::dyn, 71
- SampleRate
 - sound4::impact, 70
 - sound4::impact::dyn, 72
- SaveState
 - sound4::impact::dyn::CDynLib, 88
- SetLoggerCallback
 - sound4::impact::dyn::CDynLib, 88
- SetLogSeverity
 - sound4::impact::dyn::CDynLib, 88
- SetMetadata
 - sound4::impact::CInstance, 102
 - sound4::impact::dyn::CDynLib, 89
 - sound4::impact::dyn::CInstance, 112
- SetParam
 - sound4::impact::CInstance, 102
 - sound4::impact::dyn::CInstance, 112
- SetParameter
 - sound4::impact::dyn::CDynLib, 89
- SetPresetManager
 - sound4::impact::CInstance, 102
 - sound4::impact::dyn::CDynLib, 89
 - sound4::impact::dyn::CInstance, 112
- SetupPath
 - MyPresetManager, 123
- sound4, 67
- sound4.impact.cl-pipe-cxx.cpp, 129, 131
 - GetEnv, 129
 - main, 129
 - MyLogger, 130
 - ProcessLoop, 130
 - Usage, 130
- sound4.impact.cl-pipe-dyn.cpp, 132, 135
 - GetEnv, 133
 - main, 133
 - MyLogger, 134
 - ProcessLoop, 134
 - Usage, 134
- sound4.impact.cl-pipe.cpp, 138, 140
 - CHANNEL_COUNT, 138
 - CHUNK_SIZE, 139
 - main, 139
 - MyLogger, 139
 - ProcessLoop, 140
 - SAMPLE_RATE, 139
 - Usage, 140
- sound4.impact.cl.h, 143, 146
 - IMPACT_DECL, 146
 - IMPACT_HAS_CLOUDBUS, 146
 - IMPACT_HAS_WEBSERVER, 146
- sound4.impact.cl.hpp, 150, 152
 - fs_strdup, 151
- sound4.impact.cl_dyn.hpp, 159, 160
 - fs_strdup, 160
- sound4::impact, 67
 - ChunkFrames, 69
 - InputChannels, 69
 - InputSampleSize, 69
 - log_cb_t, 68
 - LogSeverity, 68
 - OutputChannels, 69
 - OutputSampleSize, 70
 - PresetChange_Kind, 68
 - SampleFormat, 69
 - SampleRate, 70
- sound4::impact::CInstance, 94
 - ~CInstance, 96
 - AddAudio, 96
 - CInstance, 95, 96
 - Create, 96
 - GetAudio, 97
 - GetBufferIn, 97

- GetBufferOut, 97
- GetChunkFrames, 98
- GetEstimatedDelay, 98
- GetMetadataInfos, 98
- GetParam, 99
- IsOk, 99
- NewClient, 99
- OnUpdateThreadStart, 99
- OnUpdateThreadStop, 100
- operator=, 100
- PresetManager_InformChange, 100
- ProcessAnyAudio, 100
- ProcessAudio, 101
- ProcessAudio_Planar, 101
- SetMetadata, 102
- SetParam, 102
- SetPresetManager, 102
- StartWebServer, 103
- Stop, 103
- StopWebServer, 103
- Terminate, 104
- sound4::impact::CInstance::CClient, 75
 - ~CClient, 76
 - CClient, 75
 - operator=, 76
 - ProcessJson, 76
- sound4::impact::CPresetLoader, 114
 - ~CPresetLoader, 115
 - CPresetLoader, 115
 - Exists, 115
 - GetAll, 115
 - IsReadOnly, 115
 - Read, 115
 - Remove, 116
 - Rename, 116
 - Write, 116
- sound4::impact::dyn, 70
 - ChunkFrames, 72
 - InputChannels, 72
 - InputSampleSize, 72
 - log_cb_t, 71
 - LogSeverity, 71
 - OutputChannels, 72
 - OutputSampleSize, 72
 - PresetChange_Kind, 71
 - SampleFormat, 71
 - SampleRate, 72
- sound4::impact::dyn::CDynLib, 79
 - AddAudio, 81
 - AddPadAudio, 81
 - AudioConvertFrom, 81
 - AudioConvertTo, 82
 - AudioMonoFromLiveStereo, 82
 - AudioMonoToLiveStereo, 82
 - CDynLib, 80
 - DeleteClient, 82
 - ExitProcess, 82
 - FreeJsonAnswer, 82
 - FreeMetadataInfos, 83
 - FreeParameters, 83
 - FreeParameterValue, 83
 - GetAudio, 83
 - GetAudioInputCount, 83
 - GetAudioOutputCount, 83
 - GetBufferIn, 84
 - GetBufferOut, 84
 - GetBytesFromFormat, 84
 - GetChannelCount, 84
 - GetChunkSizeInFrames, 84
 - GetEstimatedDelay, 84
 - GetFormatFromName, 85
 - GetFormatName, 85
 - GetMaxPacketFrame, 85
 - GetMetadataInfos, 85
 - GetOutputCount, 85
 - GetParameter, 85
 - GetPossibleChunkSizeInFrames, 86
 - GetProcessChunkFrames, 86
 - GetSampleRate, 86
 - GetVersion, 86
 - InitProcess, 86
 - InitProcess2, 86
 - InitProcess3, 87
 - IsOk, 80
 - Load, 81
 - MonoToStereo, 87
 - MonoToStereo_Planar, 87
 - NewClient, 87
 - NewParameters, 87
 - PresetManager_InformChange, 87
 - ProcessAudio, 88
 - ProcessAudio_Planar, 88
 - ProcessJson, 88
 - SaveState, 88
 - SetLoggerCallback, 88
 - SetLogSeverity, 88
 - SetMetadata, 89
 - SetParameter, 89
 - SetPresetManager, 89
 - StartUpdateThread, 89
 - StereoToMono, 89
 - StereoToMono_Planar, 89
 - StopUpdateThread, 90
 - TerminateProcess, 90
 - WaitUpdateThreadReady, 90
 - Webserver, 90
 - Webserver_Status, 90
 - Webserver_Stop, 90
 - Webserver_tcp, 91
 - Webserver_tcp2, 91
- sound4::impact::dyn::CInstance, 104
 - ~CInstance, 106
 - AddAudio, 106
 - CInstance, 105, 106
 - Create, 106
 - GetAudio, 107

- GetBufferIn, [107](#)
- GetBufferOut, [107](#)
- GetChunkFrames, [108](#)
- GetEstimatedDelay, [108](#)
- GetMetadataInfos, [108](#)
- GetParam, [109](#)
- IsOk, [109](#)
- NewClient, [109](#)
- OnUpdateThreadStart, [109](#)
- OnUpdateThreadStop, [110](#)
- operator=, [110](#)
- PresetManager_InformChange, [110](#)
- ProcessAnyAudio, [110](#)
- ProcessAudio, [111](#)
- ProcessAudio_Planar, [111](#)
- SetMetadata, [112](#)
- SetParam, [112](#)
- SetPresetManager, [112](#)
- StartWebServer, [113](#)
- Stop, [113](#)
- StopWebServer, [113](#)
- Terminate, [114](#)
- sound4::impact::dyn::CInstance::CClient, [77](#)
 - ~CClient, [78](#)
 - CClient, [77](#)
 - operator=, [78](#)
 - ProcessJson, [78](#)
- sound4::impact::dyn::CPresetLoader, [116](#)
 - ~CPresetLoader, [117](#)
 - CPresetLoader, [117](#)
 - Exists, [117](#)
 - GetAll, [117](#)
 - IsReadOnly, [117](#)
 - Read, [118](#)
 - Remove, [118](#)
 - Rename, [118](#)
 - Write, [118](#)
- sound4::impact::dyn::helper, [73](#)
 - DynFunc_t, [73](#)
 - DynLib_t, [73](#)
- sound4::impact::dyn::helper::CDynLoader, [91](#)
 - ~CDynLoader, [92](#)
 - CDynLoader, [92](#)
 - Close, [92](#)
 - GetSymbol, [93](#)
 - GetSymbol_safe, [93](#)
 - GetThisLibraryPath, [93](#)
 - IsOk, [93](#)
 - Load, [93](#)
 - operator bool, [94](#)
 - operator=, [94](#)
- sound4::impact::dyn::helper::DynFuncHolder< T >, [119](#)
 - DynFuncHolder, [119](#)
 - IsOk, [120](#)
 - operator bool, [120](#)
 - operator T*, [120](#)
- sound4::impact::dyn::helper::SampleFormat< float >, [125](#)
 - format, [125](#)
- sound4::impact::dyn::helper::SampleFormat< int16_t >, [126](#)
 - format, [126](#)
- sound4::impact::dyn::helper::SampleFormat< int32_t >, [127](#)
 - format, [128](#)
- sound4::impact::dyn::helper::SampleFormat< T >, [124](#)
- sound4::impact::helper, [74](#)
- sound4::impact::helper::SampleFormat< float >, [125](#)
 - format, [126](#)
- sound4::impact::helper::SampleFormat< int16_t >, [127](#)
 - format, [127](#)
- sound4::impact::helper::SampleFormat< int32_t >, [128](#)
 - format, [128](#)
- sound4::impact::helper::SampleFormat< T >, [124](#)
- SOUND4_INVALID_WEBSERVER_ID
 - Web server, [59](#)
- SOUND4_WEBSERVER_HTTP_OK
 - Web server, [59](#)
- SOUND4_WEBSERVER_HTTPS_OK
 - Web server, [60](#)
- StartUpdateThread
 - sound4::impact::dyn::CDynLib, [89](#)
- StartWebServer
 - sound4::impact::CInstance, [103](#)
 - sound4::impact::dyn::CInstance, [113](#)
- std, [74](#)
- StereoToMono
 - sound4::impact::dyn::CDynLib, [89](#)
- StereoToMono_Planar
 - sound4::impact::dyn::CDynLib, [89](#)
- Stop
 - sound4::impact::CInstance, [103](#)
 - sound4::impact::dyn::CInstance, [113](#)
- StopUpdateThread
 - sound4::impact::dyn::CDynLib, [90](#)
- StopWebServer
 - sound4::impact::CInstance, [103](#)
 - sound4::impact::dyn::CInstance, [113](#)
- Terminate
 - sound4::impact::CInstance, [104](#)
 - sound4::impact::dyn::CInstance, [114](#)
- TerminateProcess
 - sound4::impact::dyn::CDynLib, [90](#)
- Update Management, [36](#)
 - impact_StartUpdateThread, [37](#)
 - impact_StopUpdateThread, [37](#)
 - impact_WaitUpdateThreadReady, [37](#)
- Usage
 - sound4.impact.cl-pipe-cxx.cpp, [130](#)
 - sound4.impact.cl-pipe-dyn.cpp, [134](#)
 - sound4.impact.cl-pipe.cpp, [140](#)
- verbose

- Global setup, [21](#)
- verbose2
 - Global setup, [21](#)
- verbose3
 - Global setup, [21](#)
- verbose4
 - Global setup, [21](#)
- verbose5
 - Global setup, [21](#)
- WaitUpdateThreadReady
 - sound4::impact::dyn::CDynLib, [90](#)
- warning
 - Global setup, [21](#)
- Web server, [59](#)
 - impact_Webserver, [60](#)
 - impact_Webserver_Status, [61](#)
 - impact_Webserver_Stop, [61](#)
 - impact_Webserver_tcp, [62](#)
 - impact_Webserver_tcp2, [62](#)
 - SOUND4_INVALID_WEBSERVER_ID, [59](#)
 - SOUND4_WEBSERVER_HTTP_OK, [59](#)
 - SOUND4_WEBSERVER_HTTPS_OK, [60](#)
- Webserver
 - sound4::impact::dyn::CDynLib, [90](#)
- Webserver_Status
 - sound4::impact::dyn::CDynLib, [90](#)
- Webserver_Stop
 - sound4::impact::dyn::CDynLib, [90](#)
- Webserver_tcp
 - sound4::impact::dyn::CDynLib, [91](#)
- Webserver_tcp2
 - sound4::impact::dyn::CDynLib, [91](#)
- Write
 - MyPresetManager, [123](#)
 - sound4::impact::CPresetLoader, [116](#)
 - sound4::impact::dyn::CPresetLoader, [118](#)